
PVM-1350/1351Q/1354Q

SERVICE MANUAL



US Model Canadian Model

Chassis No. SCC-G61D-A

PVM-1351Q

Chassis No. SCC-G61C-A

PVM-1354Q

Chassis No. SCC-G61B-A

SPECIFICATIONS (PVM-1351Q/1354Q)

Video signal

Color system Resolution

PAL, SECAM, NTSC3.58, NTSC4.43 600 TV lines (PVM-1354Q) 450 TV lines (PVM-1351Q)

Aperture correction Frequency response 0dB - +6.0dBLINE 9.0MHz (-3 dB)

Synchronization

RGB 10.0 MHz (-3 dB) AFC time constant 1.0 msec.

Picture performance

Normal scan

7% over scan of CRT effective screen

Underscan

5% underscan of CRT effective screen

area

H. linearity V. linearity Convergence Less than 8.0% (typical) Less than 7.0% (typical)

Central area:

0.6 mm (typical) Peripheral area: 0.8 mm (typical) H: 1.0%, V: 1.5%

Raster size stability

High voltage regulation

CRT

SMPTE-C phosphor (PVM-1354Q)

P22 phosphor (PVM-1351Q)

Color temperature

6,500K/9,300K (+8MPCD), selectable USER (3200K-10000K, factory setting

is 6500K)

Inputs and Outputs

Inputs

Y/C IN: 4-pin mini DIN connector (See the pin assignment on the next

page.) VIDEO IN:BNC connector

1Vp-p ±6dB, sync negative

AUDIO IN: phono jack, -5dBs, more

than 47k ohms

R/R-Y, G/Y, B/B-Y IN: BNC

connector

R, G, B channels: 0.7 Vp-p, ±6dB Sync on green: 0.3 Vp-p, nega tive, 75

ohms terminated

R-Y, B-Y channels: 0.7 Vp-p, ±6 dB Y channel: 0.7 Vp-p, ±6dB

(Standard color bar signal of 75% chrominance)

EXT SYNC IN: BNC connector Composite sync 4 Vp-p, ±6 dB,

negative

Loop-through outputs

Y/C OUT: 4-pin mini DINconnector

VIDEO OUT: BNC connector, 75

ohms terminated

AUDIO OUT: phono jack R/R-Y, G/P, B/B-Y OUT: BNC connector, 75 ohms terminated EXT SYNC OUT: BNC comector, 75 ohms terminated

Remote input Speaker output REMOTE: 20-pin connector (See the pin assignment on the next page.)

Output level 0.8 W

- Continuedon page 2 -



TRINITRON® COLOR VIDEO MONITOR SONY

General

Approx. 99 Wh (incl. SDI) Power consumption

Approx. 90 Wh (without. SDI)

120 V AC, 50/60 Hz Power requirements

Operating temperature range 0 –35 °C

Storage temperature range -10 - +40 °C

0 - 90%

Humidity Dimensions

Mass

Accessory supplied

0 – 90% Approx. 346 × 340 × 411.5 mm (w/h/d) (13 ⁵/₈ × 13 ¹/₂ × 16 ¹/₄ inches) not incl. projecting parts and controls Approx. 16.7 kg (36 lb 14 oz). AC power cord (1) AC plug holder (1) Tally label (1) Cable with a 20-pin connector (1)

Cable with a 20-pin connector (1)


Pin assignment

Y/C IN connector (4-pin mini DIN)



Pin No.	Signal	Description
1	Y-input	1 Vp-p, sync negative, 75 ohms
2	CHROMA sub- carrier-input	300 mVp-p, burst Delay time between Y and C: within 0±100 nsec., 75 ohms
3	GND for Y-input	GND
4	GND for CHROMA-input	GND

REMOTE connector (20-pin)



Pin No.	Signal	Wire color	
1	Blue only	Brown	
2	H/V DELAY	Red	
3	MAIN/SUB*	Orange	
4	EXT SYNC	Yellow	
5	DEGAUSS	Green	
6	R ch ON/OFF*	Blue	
7	TALLY	Purple	
8	LINE B	Grey	
9	9 GND White 10 GND Black	White	
10		Black	
11	GND	Pink	
12	GND	Light Blue	
13	LINE A	Spiral Orange	
14	LINE/RGB	Spiral Yellow	
15	GND	Spiral Green	
16	L ch ON/OFF*	Spiral Blue	
17	REMOTE	Spiral Purple	
18	LINEC	Spiral Grey	
19	UNDER SCAN	Spiral Pink	
20	16:9	Spiral Light Blue	

^{(*} For digital audio control)

SPECIFICATIONS (PVM-1350)

Video signal

Color system Resolution Aperture correction NTSC

Frequency response

450 TV lines 0 dB - +6.0 dB LINE 9.0 MHz (-3 dB) RGB 10.0 MHz (-3 dB)

Synchronization

AFC time constant 1.0 msec.

Picture performance

Normal scan

7% over scan of CRT effective screen

H. linearity V. linearity

Less than 8.0% (typical) Less than 7.0% (typical) H: 1.0%, V: 1.5%

Raster sizé stability

High voltage regulation

P22 phosphor 6,500K

Color temperature

Inputs and Outputs

Inputs

Y/C IN: 4-pin mini DIN connector (See the pin assignment below.) VIDEO IN: BNC connector 1Vp-p ±6 dB, sync negative

AUDIO IN: phono jack, -5 dBs, more

than 47k ohms

R, G, B IN: BNC connector 0.7 Vp-p, ±6 dB

Sync on green: 0.3 Vp-p, negative, 75 ohms terminated

RGB SYNC IN: BNC connector Composite sync 4 Vp-p, ±6 dB,

negative

Loop-through outputs Y/C OUT: 4-pin mini DIN connector VIDEO OUT: BNC connector,

75 ohms terminated

Speaker output

AUDIO OUT: phono jack Output level 0.8 W

General

Power consumption Power requirements

Approx. 90 Wh 120 V AC, 50/60 Hz

Operating temperature range 0 – 35 °C

Storage temperature range -10 - +40 °C

Humidity

0 - 90%

Dimensions

Approx. $346 \times 340 \times 411.5 \text{ mm}$

(w/h/d)

 $(13^{5}/_{8} \times 13^{1}/_{2} \times 16^{1}/_{4} \text{ inches})$

not incl. projecting parts and controls Approx. 16.7 kg (36 lb 14 oz)

Mass Accessory supplied

AC power cord (1) AC plug holder (1)

Pin assignment

Y/C IN connector (4-pin mini DIN)




Pin No.	Signal	Description
1	Y-input	1 Vp-p, sync negative, 75 ohms
2	CHROMA sub- carrier-input	300 mVp-p, burst Delay time between Y and C: within 0±100 nsec., 75 ohms
3	GND for Y-input	GND
4	GND for CHROMA-input	GND

Design and specifications are subject to change without notice.

SAFETY CHECK-OUT (US Model Only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors
- Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
- Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- Check the line cord for cracks and abrasion.
 Recommend the replacement of any such line cord to the customer.
- Check the condition of the monopole antenna (if any).
 - Make sure the end is not broken off, and has the plastic cap on it. Point out the danger of impalement on a broken antenna to the customer, and recommend the antenna's replacement.
- Check the B+ and HV to see they are at the values specified. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
- Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.



LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers). Leakage current can be measured by any one of three methods

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- 3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)

HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)




TABLE OF CONTENTS

<u>Se</u>	ction	<u>Title</u>	Page	<u>Se</u>	<u>ction</u>	Title	<u>Page</u>
1.	GENE	RAL		6.	DIA	GRAMS	
	1-1. G	eneral of PVM-1351Q/1354Q ·····	6		6-1.	Block Diagrams (1) ·····	43
		eneral of PVM-1350 ·····				Block Diagrams (2) ······	
					6-2.	Frame Schematic Diagram	
2.	DISAS	SEMBLY				Circuit Boards Location	
	2-1. To	op Cover and Rear Cover Removal ······	20		6-4.	Printed Wiring Boards and Schematic I	Diagrams55
		erminal Board Removal ·····				• A Board (1/3)	
		cture Tube Removal ·····				• A Board (2/3)	
						• A Board (3/3)	
3.	SET-U	IP ADJUSTMENTS				• O Board	
	3-1. Pi	reparations	22			• G Board·····	80
		riting Model Data·····				• S Board	**
		cture Output·····				• J Board	
		anding Adjustment ······				• X Board	82
		onvergence Adjustment ·····				• H Board	82
		eflection Yoke Neck Rotation Adjustment ···				• C Board	
		2 Adjustment ·····			6-5.	Semiconductons	
		hite Balance Adjustment ······					0,
		lue-Only White Balance Adjustment ······		7.	EXF	PLODED VIEWS	
		ub Brt Adjustment ·····			7-1.	Chassis·····	91
		ocus Adjustment ·····			7-2.	Picture Tube ·····	92
4.	SAFE	TY RELATED ADJUSTMENT	29	8.	ELE	ECTRICAL PARTS LIST	93
5.	CIRCU	JIT ADJUSTMENTS					
	5-1. A	Board Adjustments	31				
		Board Adjustment ·····					

(CAUTION)

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAPTO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.

THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!

COMPONENTS IDENTIFIED BY SHADING AND MARK Δ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

(ATTENTION)

APRES AVOIR DECONNECTE LE CAP DE L'ANODE, COURTCIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTESUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.

ATTENTION!!

AFIN D'EVITER TOUT RISQUE D'ELECTROCUTION PROVENANT D'UN CHÁSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DÉPANNAGE.

LE CHÁSSIS DE CE RÉCEPTEUR EST DIRECTEMENT RACCORDÉ À L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS ÁLA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE MAPQUE À SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIECES CONT D'UNE IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÉCE EST INDIQUÉ DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIES DANS LE PRÉSENT MANUEL. SULVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOS ANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNE MENT EST SUSPECTÉ.

SECTION 1 GENERAL

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remein as in the manual.

1-1. GENERAL OF PVM-1351Q/1354Q

Features

HR (High Resolution) Trinitron picture tube

HR Trinitron tube provides a high resolution picture. Horizontal resolution is more than 600 (PVM-1354Q/1954Q) or 450 (PVM-1351Q) TV lines at the center of the picture.

Four color systems available

The monitor can display PAL, SECAM, NTSC3.58 and NTSC3.58* signals. The appropriate color system is selected automatically.

* A signal of NTSC_{4.43} is used for playing back NTSC recorded video cassettes with a video tape recorder/player especially designed for use with this system.

Blue only mode

In the blue only mode, an apparent monochrome display is obtained with all three cathodes driven with a blue signal. This facilitates color saturation and phase adjustments and observation of VCR noise.

Analog RGB/component input connectors

Analog RGB or component (Y, R-Y and B-Y) signals from video equipment can be input through these connectors.

Y/C input connectors

The video signal, split into the chrominance signal (C) and the luminance signal (Y), can be input through this connector, eliminating the interference between the two signals, which tends to occur in a composite video signal, assuring video quality.

Beam current feedback circuit

The built-in beam current feedback circuit assures stable white balance.

Comb filter

When NTSC video signals are received, a comb filter activates to increase the resolution, resulting in fine picture detail without color spill or color noise.

Automatic termination (connector with $\protect\ensuremath{\bigwedge}_{\protect\ensuremath{\bigwedge}}$ mark only)

The input connector is terminated at 75 ohms inside when no cable is connected to the loop-through output connectors. When a cable is connected to an output connector, the 75-ohms termination is automatically released.

Underscan mode

The signal normally scanned outside of the screen can be monitored in the underscan mode.

Note

When the monitor is in the underscan mode, the dark RGB scanning lines may appear on the top edge of the screen. These are caused by an internal test signal, rather than the input signal.

Horizontal/vertical delay mode

The horizontal and vertical sync signals can be checked simultaneously in the H/V delay mode.

External sync input

When the EXT SYNC selector is in the on position, the monitor can be operated on the sync signal supplied from an external sync generator.

Auto/manual degaussing

Degaussing of the screen can be performed automatically when the power is turned on, or manually by pressing the DEGAUSS button.

On-screen menus

You can set color temperature, CHROMA SET UP, and other settings by using the on-screen menus.

Five menu languages

You can select the menu language from among the five languages on the menu.


EIA standard 19-inch rack mounting

By using an MB-502B (for PVM-1354Q/1351Q) or SLR-103 (for PVM-1954Q) mounting bracket (not supplied), the monitor can be mounted in an EIA standard 19-inch rack. For details on mounting, see the instruction manual of the mounting bracket kit.

SDI (Serial Digital Interface) kit

By using SDI kit, the monitor can display SMPTE 259M 4:2:2 serial digital signal from a digital VTR. (ex. Sony 4:2:2 VTR) SDI kit: 4:2:2 digital video board Digital audio board

Location and function of parts and controls



1 Tally lamp

Lights up when the video camera connected to this monitor is selected, indicating that the picture is being recorded.

2 POWER switch and indicator

Depress to turn the monitor on. The indicator will light up in green.

3 REMOTE indicator

Lights up when you set USER PRESET to ON in the menu, or when you connect a supplied cable to REMOTE connector (No. 17 pin is ground). The controls on the front panel do not work when this indicator lights up.

4 VOLUME control

Turn this control clockwise or counterclockwise to obtain the desired volume.

5 CONTRAST control

Turn clockwise to make the contrast higher and counterclockwise to make it lower.

6 PHASE control

This control is effective only for the NTSC3.58 and NTSC443 color systems. Turn clockwise to make the skin tones greenish and counterclockwise to make them purplish.

7 CHROMA control

Turn clockwise to make the color intensity higher and counterclockwise to make it lower.

8 BRIGHT (brightness) control

Turn clockwise for more brightness and counterclockwise for less.

9 APERTURE control

Turn clockwise for more sharpness and counterclockwise for less.

Note

The APERTURE, CHROMA, PHASE control settings have no effect on the pictures of RGB signals.

10 MENU (EXIT) button

Press to make the menu appear. Press to return to $\hbar \varepsilon$ previous screen in the menu.

11 ENTER (SELECT) button

Press to decide a selected item in the menu.

12 **↑** (+)/ **↓** (-) buttons

Press to move the cursor (**>**) or adjust selected value in the menu.

2



13 16:9 selector

Press (light on) for the signal of 16:9 picture.

14 H/V DELAY selector

Press (light on) to observe the horizontal and vertical sync signals at the same time.

The horizontal sync signal is displayed in the left quarter of the screen; the vertical sync signal is displayed near the center of the screen.

15 UNDER SCAN selector

Press (light on) for underscanning. The display size is reduced by approximately 5% so that four corners of the raster are visible.

16 BLUE ONLY selector RESET button

Press (light on) to turn off the red and green signals. A blue signal is displayed as an apparent monochrome picture on the screen. This facilitates "chroma" and "phase*" control adjustments and observation of VCR noise.

 "Phase" control adjustment is effective only for the NTSC signals.

Press to reset the setting in the menu.

17 DEGAUSS button

Press this button momentarily. The screen will be demagnetized. Wait for 10 minutes or more before activating this button again.

18 EXT SYNC (external sync) selector

Keep this button in the off position (light off) to operate the monitor on the sync signal from the displayed video signal.

Keep this button in the on position (light on) to operate the monitor on an external sync signal fed through the EXT SYNC connector on the rear panel.

19 LINE/RGB input selector

Select the program to be monitored. Keep this button in the off position (light off) to feed a signal through the LINE A, LINE B or LINE C connectors. Keep this button in the on position (light on) to feed a signal through the RGB connectors.

20 C/SDI selector

When the LINE/RGB input selector is set to LINE (light off), press this button (light on) to feed a signal through the LINE C connectors.

When the LINE/RGB input selector is set to RGB (light on), press this button (light on) to feed the SDI signal (optional board is needed).

21 B/COMPONENT selector

When the LINE/RGB input selector is set to LINE (light off), press this button (light on) to feed a signal through the LINE B connectors.


When the LINE/RGB input selector is set to RGB (light on), press this button (light on) to feed the component signal.

22 A/RGB selector

When the LINE/RGB input selector is set to LINE (light off), press this button (light on) to feed a signal through the LINE A connectors.

When the LINE/RGB input selector is set to RGB (light on), press this button (light on) to feed the RGB signal.

Location and function of parts and controls



1 AC IN socket

Connect the supplied AC power cord to this socket and to a wall outlet.

2 LINE A, LINE B connectors

Two groups (A and B) of line input connectors for the composite video and audio signals and their loop-through output connectors.

To monitor the input signal fed through these connectors, keep the LINE/RGB selector in the LINE position (light off) and press the A/RGB or B/COMPONENT selector (light on) on the front panel.

VIDEO IN (BNC)

Connect to the video output of a video equipment, such as a VCR or a color video camera. For a loop-through connection, connect to the video output of another monitor.

VIDEO OUT (BNC)

Loop-through output of the VIDEO IN connector. Connect to the video input for a VCR or another monitor.

When the cable is connected to this connector, the 75-ohms termination of the input is automatically released, and the signal input to the VIDEO IN connector is output from this connector.

AUDIO IN (phono jack)

Connect to the audio output of a VCR or to a microphone via a suitable microphone amplifier. For a loop-through connection, connect to the audio output of another monitor.

AUDIO OUT (phono jack)

Loop-through output of the AUDIO IN jack. Connect to the audio input of a VCR or another monitor.

3 LINE C connectors

Y/C IN (4pin mini DIN)

Connect to the Y/C separate output of a video camera, VCR or other video equipment.

Y/C OUT (4pin mini DIN)

Loop-through output of the Y/C IN connector. Connect to the Y/C separate input of a VCR or another monitor. When the cable is connected to this connector, the 75-ohms termination of the input is automatically released, and the signal input to the Y/C IN connector is output from this connector.

AUDIO IN (phono jack)

Connect to the audio output of a VCR or a microphone (through a suitable microphone amplifier).

AUDIÖ OUT (phono jack)

Loop-through output of the AUDIO IN connector.

Connect to the audio input of a VCR or another monitor.

4 REMOTE connector (20pin)

Connect to the tally output of a control console, special-effect generator, etc. The tally lamp on the front pane 1 will be turned on and off by the connected equipment. This connector can be used for connecting a remote controller. For the pin assignment of this connector, see "Specifications" on page 10.

5 RGB/COMPONENT connectors

RGB signal or component signal input connectors and their loop-through output connectors.

To monitor the input signal fed through these connectors, keep the LINE/RGB selector in the RGB position (light on), and press the A/RGB or B/COMPONENT selector (light on) on the front panel.

R/R-Y IN, G/Y IN, B/B-Y IN (BNC)

When the EXT SYNC selector on the front panel is in the off position (light off), the monitor operates on the sync signal from the G/Y channel.

To monitor the RGB signal

Connect to the analog RGB signal outputs of a video camera.

To monitor the component signal

Connect to the R-Y/Y/B-Y component signal outputs of a Sony Betacam video camera.

R/R-Y OUT, G/Y OUT, B/B-Y OUT (BNC)

Loop-through outputs of the R/R-Y IN, G/Y IN, B/B-Y IN connectors

For RGB signal

Connect to the analog RGB signal inputs of a video printer or another monitor.

For component signal

Connect to the $R-Y/\overline{Y}/B-Y$ component signal inputs of a Betacam video recorder.

When the cables are connected to these connectors, the 75-ohms termination of the inputs is automatically released, and the signal inputs to the R/R-Y IN, G/Y IN, B/B-Y IN connectors are output from these connectors.

AUDIO IN (phono jack)

Connect to the audio output of video equipment when the analog RGB or component signal is input.

AUDIO OUT (phono jack)

Loop-through outputs of the AUDIO IN connector.

6 EXT SYNC (external sync) connectors

To use the sync signal fed through this connector, press the EXT SYNC selector (light on).

IN (BNC

When this monitor operates on an external sync signal, connect the reference signal from a sync generator to this connector.


OUT (BNC)

Loop-through output of the EXT SYNC IN connector. Connect to the external sync input of video equipment to be synchronized with this monitor.

When the cable is connected to this connector, the 75-ohms termination of the input is released, and the signal input to the IN connector is output from this connector.

Using on-screen menus

The flow chart shows the different levels of on-screen menus that you can use to make various adjustments and settings. The boxed number is for instructions on the next page.



Operating through menus


There are five buttons for menu operations on the front of the monitor. To display the main menu, first press MENU. The buttons you can use appear at the bottom of the menu screen.

Functions of the buttons

Button	To select menu item	To adjust menu item selected
MENU EXIT	return to the previous menu	return to the previous menu
ENTER SELECT	decide a selected item	select an item
† 	move the cursor (►) upwards	increase selected value
	move the cursor (►) downwards	decrease selected value
RESET		reset current adjustment value to the factory setting

(The above items in white type correspond to the marks in the menu.)

front of monitor



1 Main menu

Select an item and press ENTER to go to the following menu.

2 CHROMA SET UP menu

Set to ON to adjust the internal decoder for CHROMA and PHASE (NTSC signal only) after AUTO ADJUST (7). [OFF]

3 COLOR TEMP/BAL menu

Select the color temperature from among 6500K, 9300K and USER. USER is set to 6500K in the factory setting. You can adjust or change the color temperature in USER mode (a measuring instrument is needed). [6500K]

4 CAPTION VISION menu

The monitor can display the signal with Caption Vision. To display it, select the caption type in this menu.

[OFF

5 USER CONFIG 1 menu

Select an item to adjust. To go to the USER CONFIG 2 menu, select NEXT PAGE.

6 USER CONFIG 2 menu

Select an item to adjust. To go to the USER CONFIG 1 menu select PREVIOUS PAGE.

7 AUTO ADJUST screen

Select the color bar signal (full, SMPTE, EIA) and press ENTER to start auto adjusting for CHROMA SET UP (NTSC signal only).

8 ADJUST GAIN screen

Adjust GAIN in USER mode.

9 ADJUST BIAS screen

Adjust BIAS in USER mode.

10 COLOR TEMP RANGE menu

Select the color temperature range in USER mode. [5000K-10000K]

11 COLOR SYSTEM DISPLAY menu

Select the color system display mode. In AUTO, the kind of color system being used appears on the screen each time you change the signal input.

[AUTO]

12 358 TRAP FILTER menu

Color spill or color noise may be eliminated if you select ON (NTSC3.58 signal only). [OFF]

13 SUB CONTROL screen

You can finely adjust the controls on the front panel. CONTRAST, BRIGHT, CHROMA and PHASE control has a click at the center of its adjustment range. You can adjust the setting of the click position with this feature.

14 USER PRESET menu

You can preset each control to a desired level and set it. If you set USER PRESET to ON, the REMOTE indicator lights up and the controls on the front panel do not work. The monitor operates with the internal memory settings. For adjustment, select PRESET ADJUST. [OFF]

15 PRESET ADJUST screen

Adjust CONTRAST, BRIGHT, CHROMA, PHASE, VOLUME, APERTURE in USER PRESET.

16 V HOLD screen

Adjust the vertical hold if the picture rolls vertically. When you cannot read the display, select the input that is not connected.

[17] COMPONENT LEVEL menu

Select the component level from among three modes. N10/SMPTE for 100/0/100/0 signal

BETA 7.5 for 100/7.5/75/7.5 signal BETA 0 for 100/0/75/0 signal

[BETA 7.5]

18 NTSC SETUP LEVEL menu

Select the NTSC setup level from two modes. The 7.5 setup level is mainly used in north America. The 0 setup level is mainly used in Japan. [7.5]

19 ACC menu

Set ACC (Auto Color Control) circuit on or off. When the fine adjustment is needed, set ACC to OFF. Normally set it to ON. [ON]

20 LANGUAGE menu

You can select the menu language from among the five languages (English, German, French, Italian, Spanish) on the menu.

[ENGLISH]


([] indicates the factory setting position.)

7


Power sources

House current

Connect the AC power cord (supplied) to the AC IN socket and to a wall outlet.



To connect an AC power cord securely with an AC plug holder



To remove the AC power cord

Pull out AC plug holder by squeezing the left and right sides.

1-2. GENERAL OF PVM-1350

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remein as in the manual.

Features

Fine pitch Trinitron picture tube

The fine pitch Trinitron tube provides a high resolution picture. Horizontal resolution is more than 450 TV lines at the center of the picture.

Analog RGB input connectors

Analog RGB signals from video equipment can be input through these connectors.

Y/C input connectors

The video signal, split into the chrominance signal (C) and the luminance signal (Y), can be input through this connector, eliminating the interference between the two signals, which tends to occur in a composite video signal, assuring video quality.

Beam current feedback circuit

The built-in beam current feedback circuit assures stable white balance.

Comb filter

When NTSC video signals are received, a comb filter activates to increase the resolution, resulting in fine picture detail without color spill or color noise.

Automatic termination (connector with \swarrow_{r} mark only)

The input connector is terminated at 75 ohms inside when no cable is connected to the loop-through output connectors. When a cable is connected to an output connector, the 75-ohms termination is automatically released.

Blue only mode

In the blue only mode, an apparent monochrome display is obtained with all three cathodes driven with a blue signal. This facilitates color saturation and phase adjustments and observation of VCR noise.

Auto/manual degaussing

Degaussing of the screen can be performed automatically when the power is turned on, or manually by pressing the DEGAUSS button.

On-screen menus

You can set CHROMA SET UP and other settings by using the on-screen menus.


Five menu languages

You can select the menu language from among the five languages on the menu.

EIA standard 19-inch rack mounting

By using an MB-502B mounting bracket (not supplied), the monitor can be mounted in an EIA standard 19-inch rack. For details on mounting, see the instruction manual of the mounting bracket kit.

Location and function of parts and controls



1 POWER switch and indicator

Depress to turn the monitor on. The indicator will light up in green.

2 VOLUME control

Turn this control clockwise or counterclockwise to obtain the desired volume.

3 CONTRAST control

Turn clockwise to make the contrast higher and counterclockwise to make it lower.

4 PHASE control

Turn clockwise to make the skin tones greenish and counterclockwise to make them purplish.

5 CHROMA control

Turn clockwise to make the color intensity higher and counterclockwise to make it lower.

6 BRIGHT (brightness) control

Turn clockwise for more brightness and counterclockwise for less.

7 APERTURE control

Turn clockwise for more sharpness and counterclockwise for less.

Note

The APERTURE, CHROMA, PHASE control settings have no effect on the pictures of RGB signals.

8 MENU (EXIT) button

Press to make the menu appear. Press to return to the previous screen in the menu.

9 ENTER (SELECT) button

Press to decide a selected item in the menu.

10 **↑** (+)/ **↓** (-) buttons

Press to move the cursor (▶) or adjust selected value in the menu.

11 BLUE ONLY selector RESET button

Press (light on) to turn off the red and green signals. A blue signal is displayed as an apparent monochrome picture on the screen. This facilitates "chroma" and "phase" control adjustments and observation of VCR noise.

Press to reset the setting in the menu.

12 DEGAUSS button

Press this button momentarily. The screen will be demagnetized. Wait for 10 minutes or more before activating this button again.

13 Input select buttons


Press (light on) to select the program to be monitored.

A: for a signal fed through the LINE A connectors.

B: for a signal fed through the LINE B connectors.

C: for a signal fed through the LINE C connectors.

RGB: for a signal fed through the RGB connectors.



1 AC IN socket

Connect the supplied AC power cord to this socket and to a wall outlet.

2 LINE A, LINE B connectors

Two groups (A and B) of line input connectors for the composite video and audio signals and their loop-through output connectors.

To monitor the input signal fed through these connectors, press the A or B button (light on) on the front panel.

VIDEO IN (BNC)

Connect to the video output of video equipment, such as a VCR or a color video camera. For a loop-through connection, connect to the video output of another monitor.

VIDEO OUT (BNC)

Loop-through output of the VIDEO IN connector. Connect to the video input for a VCR or another monitor.

When the cable is connected to this connector, the 75-ohms termination of the input is automatically released, and the signal input to the VIDEO IN connector is output from this connector.

AUDIO IN (phono jack)

Connect to the audio output of a VCR or to a microphone via a suitable microphone amplifier. For a loop-through connection, connect to the audio output of another monitor.

AUDIO OUT (phono jack)

Loop-through output of the AUDIO IN jack. Connect to the audio input of a VCR or another monitor.

3 LINE C connectors

Y/C IN (4pin mini DIN)

Connect to the Y/C separate output of a video camera, VCR or other video equipment.

Y/C OUT (4pin mini DIN)

Loop-through output of the Y/C IN connector. Connect to the Y/C separate input of a VCR or another monitor. When the cable is connected to this connector, the 75-ohms termination of the input is automatically released, and the signal input to the Y/C IN connector is output from this connector.

AUDIO IN (phono jack)

Connect to the audio output of a VCR or a microphone (through a suitable microphone amplifier).

AUDIO OUT (phono jack)

Loop-through output of the AUDIO IN connector. Connect to the audio input of a VCR or another monitor.

4 RGB IN connectors

Connect to the analog RGB outputs of a video camera. To monitor the input signal fed through these connectors, press RGB button (light on) on the front panel.

R IN, G IN, B IN (BNC)

When you set RGB SYNC to SYNC ON G in the menu, the monitor operates on the sync signal from the G channel.

AUDIO IN (phono jack)


Connect to the audio output of video equipment when the analog RGB signal is input.

SYNC IN (BNC)

To use the sync signal fed through this connector, set RGB SYNC to EXT SYNC in the menu.

Using on-screen menus

The flow chart shows the different levels of on-screen menus that you can use to make various adjustments and settings. The boxed number is for instructions on the next page.



Operating through menus


There are five buttons for menu operations on the front of the monitor. To display the main menu, first press MENU. The buttons you can use appear at the bottom of the menu screen.

Functions of the buttons

Button	To select menu item	To adjust menu item selected
MENU EXIT	return to the previous menu	return to the previous menu
ENTER SELECT	decide a selected item	select an item
t	move the cursor (►) upwards	increase selected value
ļ	move the cursor (►) downwards	decrease selected value
RESET		reset current adjustment value to the factory setting

(The above items in white type correspond to the marks in the menu.)

front of monitor



1 Main menu

Select an item and press ENTER to go to the following menu.

2 CHROMA SET UP menu

Set to ON to adjust the internal decoder for CHROMA and PHASE after AUTO ADJUST (6). [OFF]

3 CAPTION VISION menu

The monitor can display the signal with Caption Vision. To display it, select the caption type in this menu.

[OFF]

4 USER CONFIG 1 menu

Select an item to adjust. To go to the USER CONFIG 2 menu select NEXT PAGE.

5 USER CONFIG 2 menu

Select an item to adjust. To go to the USER CONFIG 1 menu select PREVIOUS PAGE.

6 AUTO ADJUST screen

Select the color bar signal (full, SMPTE, EIA) and press ENTER to start auto adjusting for CHROMA SET UP.

7 COLOR SYSTEM DISPLAY menu

Select the color system display mode. In AUTO, the kind of color system being used appears on the screen each time you change the signal input. [AUTO]

8 V HOLD screen

Adjust the vertical hold if the picture rolls vertically. When you cannot read the display, select the input that is not connected.

9 RGB SYNC menu

Select SYNC ON G to operate the monitor on the sync signal from the displayed green signal.

Select EXT SYNC to operate the monitor on an external sync signal fed through the RGB SYNC connector.

[SYNC ON G]

10 NTSC SETUP LEVEL menu

Select the NTSC setup level from two modes. The 7.5 setup level is mainly used in north America. The 0 setup level is mainly used in Japan. [7.5]

11 LANGUAGE menu


You can select the menu language from among the five languages (English, German, French, Italian, Spanish) on the menu. [ENGLISH]

([] indicates the factory setting position.)


Power sources

House current

Connect the AC power cord (supplied) to the AC IN socket and to a wall outlet.



To connect an AC power cord securely with an AC plug holder




To remove the AC power cord


Pull out AC plug holder by squeezing the left and right sides.

SECTION 2 DISASSEMBLY


2-1. TOP COVER AND REAR COVER REMOVAL



2-2. TERMINAL BOARD REMOVAL




2-3. PICTURE TUBE REMOVAL




• REMOVAL OF ANODE-CAP


NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT, after removing the anode.

REMOVING PROCEDURES



direction indicated by the arrow @.





direction of the arrow ©.

HOW TO HANDLE AN ANODE-CAP

- Don't hurt the surface of anode-caps with sharp shaped material!
- Don't press the rubber hardly not to hurt inside of anode-caps! A material fitting called as shatter-hook terminal is built in the rubber.
- Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.







SECTION 3 SET-UP ADJUSTMENTS

3-1. PREPARATIONS (1)

Service Mode

This set is provided with a switch for service on the front panel that can be used to make various adjustments. The operation method of this switch is explained in detail below.

1. ENTERING THE SERVICE MODE

Simultaneously press the [ENTER] key and the [DEGAUSS] key shown on the display of the menu.

2. SERVICE MODE DISPLAY

(1)	(5)	(4)	(3)	(6)
(2)				

Range of Sevice Mode Display

- The service items are largely classified into 16 types displayed by titles.
- (2) The names of the service items or READ / WRITE guidance, etc., are displayed. The names are dispalyed to the left and the guidance to the right.
- (3) This is the serial number for each of the service items. 1-120.
- (4) This is the adjustment data for the servise items that are now stored in the RAM. Adjustments can be made by changing these values, but as long as nothing is written to the ROM the adjustment values will be erased by turning off the power or by reading, so please be careful.
- (5) When the adjustment data than is now displayed is identical with the data in the ROM, the cursor (▷) is displayed.
- (6) The present status is displayed.
 - [*]: Writing to the ROM. Make sure not to turn off the power while this display is on.
 - [?]: ROM reading error. In this case, an image is output with the standard adjustment data that the microcomputer itself possesses.
 - [¿]: Problem in the I2C bus.

3. FINISHING THE SERVICE MODE

Simultaneously press the [ENTER] key and the [DEGAUSS] key shown on the display of the menu.

4. EASY ON / OFF OF THE SERVICE MODE

If once entering the service mode after having turned on the power, easy ON / OFF is possible by once more pressing the A, B or C switch on the front panel (the LED lights) as long as the power is not turned off or as long as the service mode is not finished.

5. CHANGE OF POSITION OF THE SERVICE MODE DISPLAY

If the switch is continuously pressed when turning on in the above easy mode, the display position moves in the V direction. This method is used when the display is outside of the effective screen area.

6. CHANGE OF SERVICE ITEMS

The items are returned with the [MENU] key and forwarded with the [ENTER] key. When a key is continuously pressed, the operation will be repeated.

7. CHANGE OF SERVICE DATA

The service data is made larger with the $[\uparrow]$ key and smaller with the $[\downarrow]$ key. When continuously pressing the keys, the operation will be repeated.

8. READING OF SERVICE DATA

When reading data from the ROM to the RAM, press the [B /D] key once and check than the READ display is shown in the guidance, and then press the [B / O] key once again. The adjustment data that is written will return to its previous state, so please be careful.

9. WRITING OF SERVICE DATA

When writing data from the RAM to the ROM, press the [DEGAUSS] key once and check that the WRITE display is shown in the guidance, and then press the [DEGAUSS] key once again. Not only the displayed data will be written, but all data, so please be careful.

10. CARRYING OUT FACTORY RESETTING

In case the adjustment data has been destroyed for some reason, and you keep pressing the [B / O] key at the beginning of the above reading, the READ guidance will change to FACTRY RESET guidance in approximately 3 seconds so that the factory resetting can be carried out. By once again pressing the [B / O] key after this, resetting will be carried out ([*] will be displayed as status) and factory resetting will be executed. However, in case the data available at the time of shipment from the factory has been destroyed, or if the ROM has been replaced, etc., or if factory setting mentioned later on has been carried out, factory resetting is executed.

11. CARRYING OUT FACTORY SETTING

Make sure to make possible the above factory resetting by making a copy of the adjustment data when replacing the ROM. If you keep pressing the [DEGAUSS] key at the beginning of the above writing, the WRITE guidance will change into FACTORY RESET guidance after approximately 3 seconds. By once again pressing the [DEGAUSS] key after this, setting will be carried out ([*]will be dispalyed as status) and the data will be copied. By carrying out this operation, the selection items of the menu and the adjustment values will be reset to the standard conditions, so please be careful. If this operation is carried out once, it cannot be carried out again, but the FACTORY SET FLAG (No. 120) in the service mode can be set to 1.

SERVICE DATA STANDARD

SERVICE MAP Ver 5 . x (1-120)

NO.		ERVICE ITEM	MAX	14"	20"	NO.		SERVICE ITEM	MAX	14'	" 20"
1	NOR 50 DEF	H FREQUENCY	255	80	107	61	C/T1 ??00K	BIAS (RED)	1023		
2		VIDEO PHASE	255	141	127	62		BIAS (GREEN)	1023		
3		V SIZE	255	165	155	63		BIAS (BLUE)	1023		
4		V CENTER	255	122	116	64		GAIN (RED)	1023		
5	NOR 60 DEF	H FREQUENCY	255	90		65		GAIN (GREEN)	1023		
6		VIDEO PHASE		120		66		GAIN (BLUE)	1023		
7		V SIZE	255		161	67		B/O(RED)		120	
8		V CENTER			111	68		B/O(RED)		125	
	NOR DEF	H SIZE		111		69	C / T2 ??00K	3200K SW	233	123	
10		PIN PHASE		108		70	C/12::00K	BIAS (RED)			
11		PIN AMP		112		71			1023		
12		U/L PIN		126				BIAS (GREEN)	1023	_	
13		SEXY				72		BIAS (BLUE)	1023		
14			255	128		73		GAIN (RED)	1023		
		V LINEARITY	255	132	82	74		GAIN (GREEN)	1023		
15		V BOW	* 63	32	32	75		GAIN (BLUE)	1023		
16		V ANGLE	* 63	32	32	76		B/O(RED)	255		
	U/SDEF	V SIZE (50)				77		B/O(GREEN)	255	105	105
18		V SIZE (60)	255	116	131	78	W/B	SUB CON (4:3, NORMAL)	255	210	210
19		H SIZE	255	115	89	79		SUB CON (4:3, H/V DELAY)	255	122	122
20		PIN PHASE	255	118	112	80		SUB CON (16:9, NORMAL)	255	165	165
21		PIN AMP	255	74	96	81		SUB CON (16:9, H/V DELAY)			
22	16:9 NOR DEF	V SIZE (50)	255	81	89	82		SUB BRIGHT	255		
23		V SIZE (60)	255	85	100	83		USER B / O (RED)	255	120	
24		PIN PHASE	255	113	120	84		USER B / O (GREEN)		125	
25		PIN AMP	255	64	68	85	OTHER	OSD POSITION		129	
26		U/L PIN	255	132	136	86		V HOLD		128	
27	16:9 U/S DEF	V SIZE (50)	255	41	59	87		H BLANKING	255		
28		V SIZE (60)	255	35	55	88		V BLANKING (50)	255		
29	-	PIN PHASE				89		16: 9 BLANKING START(50)	255		
30		PIN AMP	255	47	55	90	<u> </u>	16:9 BLANKING END(50)		163	
	COMPONENT			140				V BLANKING (60)			
32	COMIT OF ABILITY	SUB CHROMA (NORMAL)		104		92		16:9 BLANKING START(60)		117	
33		SUB CHROMA (SMPTE)		168		93		16:9 BLANKING END(60)	255		
34		R-Y LEVEL		155		94		H DELAY	_	215	
	NTSC	BURST GATE PULSE WIDTH	255	22	22	95		V DELAY		165	
36	NISC	CRYSTAL	255	51	51	96		HP POSITION		101	
37		PHASE (NORMAL)	255			97				130	$\overline{}$
38				103 112				HP WIDTH (NORMAL)	255		
39		PHASE (ACC OFF)	255			98	CVCTT	HP WIDTH (H / V DELAY)	255	+	
40		B-Y PHASE		141			SYSTEM	SDI AUDIO	7		
\vdash		CHROMA (NORMAL)				100		358TRAP FILTER	1		_
41		CHROMA (ACC OFF)		20		101		ACC	1		
42	NITCO 442	R-Y LEVEL	255			102		CAPTION VISION	7		
	NTSC 443	CRYSTAL		65	_	103		COMPONENT LEVEL	3		
44		PHASE (NORMAL)	255			104		NTSC SETUP LEVEL	1		
45		PHASE (ACC OFF)	255			105		CHROMA SET UP	1		
46		B-Y PHASE	255			106		COLOR SYSTEM DISPLAY	3		
47		CHROMA (NORMAL)			_	107		COLOR TEMPERATURE	3		
48		CHROMA (ACC OFF)	255			108		USER PRESET	1		
49		R-Y LEVEL				109		LANGUAGE	7	C) (
	PAL	PHASE (NORMAL)		87		110		RGB SYNC	1		
51	·	PHASE (ACC OFF)	255			111		OPTION BOARD	7	C	
52		B-Y PHASE				112		AGING MODE	1	C	
53		CHROMA (NORMAL)			141	113		PAL-M	1	C	
54		CHROMA (ACC OFF)	255			114		MODEL	15	* *	* *
55		R-Y LEVEL				115		COLOR TEMP DISP 1	127		
	SECAM	CHROMA				116		COLOR TEMP DISP 2	127		
		R-Y LEVEL				117		REMOTE ADDRESS	127		-
56 57		K-1 LEVEL	1_200								
		COLOR BALANCE (R-Y)			116	118		RESERVED 1	-	0) (
57			255			118 119		RESERVED 1 RESERVED 2	1		

^{*} Among the data 8 bits (MAX255) only the upper 6 bits can be changed. ** PVM-1954Q, PVM-1350/1351Q/1354Q.

PREPARATIONS (2)

* When composite video or component signals are supplied, they must be supplied as below.

Signal		Signal Contents	Standard Level (Pedestal-White)
		100% WHITE	0.714V
	050)	75% WHITE	0.536V
COMPOSITE VIDEO	358NT 443NT	BURST (GREEN) (This item only P-P)	286mV (632mV)
(75%COLOR BAR)		100% WHITE	0.7V
	DAT	75% WHITE	0.525∨
	PAL SECAM	PAL BURST (GREEN) (This item only P-P)	300mV (664mV)
		100% WHITE Y	0.7V
		75% WHITE Y	0.525V
COMPONENT (75%COLOR	BETA 0	75% COLOR B-Y, R-Y (This item only P-P)	0.7V
BAR)		100% WHITE Y	0.7V
		75% WHITE Y	0.525V
	SMPTE	75% COLOR B-Y, R-Y (This item only P-P)	0.525V

* In this document, terms inside boxes _____ are names of service mode adjustments.

Example 60H-FREQ

- * After making adjustments in service mode, write the adjustment data before cutting off the power. If you cut off the power without writing, the results of your adjustments are all lost.
- * Standard inspection conditions

Unless specifically specified otherwise in this document, the following conditions are used for adjustments and inspections,

APERTURE

MIN

BRIGHT

50% (Center click)

CHROMA

50% (Center click)

PHASE

50% (Center click)

CONTRAST

80% (Center click)

VOLUME 50%

3-2. WRITING MODEL DATA

In service mode, write in the following model data at No. 114
 MODEL.

PVM-1350

7

PVM-1351Q/1354Q

4

2. In service mode, write in the following data at No. 115 COLOR TEMP DISP 1.

PVM-1350/1351Q/1354Q 65

3. In service mode, write in the following data at No. 116 COLOR TEMP DISP 2.

PVM-1350/1351Q/1354Q 93

3-3. PICTURE OUTPUT

- 1. Set the AC input voltage.
 - (1) Input the video and audio signals to the corresponding terminals on the connector panel.
 - (2) Set the sliduck AC voltage as shown on the right. (*1-1)


Model	Voltage		
PVM-1350/1351Q/1354Q	AC120 ± 3V (Distortion rate : 3% or less)		


3-4. LANDING ADJUSTMENT


- 1. Preparations
- To reduce the influence of geomagnetism, face the set's CRT screen east or west.
- Loosen the deflection yoke fixture and lower the deflection yoke to the rear.
- 3) Switch on the Power switch and degauss with the degausser.
- 4) Adjust the deflection yoke tilt.
- 2. Adjustment
- 1) CONT ····· MAX


BRT Position providing good vision


- 2) The rough adjustments of the white balance, G2, and convergence must be completed already.
- 3) Set green-only.
- 4) Adjust the purity knob so that the green comes to the center of the screen. Make the red and blue about even. Fig. 1
- 5) Switch to blue only, red only, and green only and verify each. Fig. 1, 2, and 3
- 6) Bring the deflection yoke gradually forward and adjust the deflection yoke so that the R and B at both sides of the screen become green. Fig. 2→3
- 7) If the deflection yoke comes too far forward, you will see the pattern shown in Figure 4. If that happens, lower the deflection yoke to the rear. Fig. $4 \rightarrow 3$
- 8) Switch the single color switch to B and verify the single color. Fig. 6
- 9) Switch the single color switch to R and verify the single color. Fig. 9
- 10) When one of the colors does not become the single color correctly, check by repeating Items 7 and 8 based on the single color not coming into adjustment.
 - If you can not obtain landing in the corners, paste on magnets.
- 11) Switch to an all-white signal and check the uniformity.
- 12) When the deflection yoke position is determined, fasten it with the fixture.














3-5. CONVERGENCE ADJUSTMENT

Input a dot pattern signal.
 CONT ······ Position providing good


CONT ····· Position providing good vision

BRT MIN

- 2. Align the horizontal R, G, and B dots at the center of the screen with the H-STAT VR. (*1)
 - *1: If the H-CENTER adjustment was after the H-STAT adjustment, re-adjust the H-STAT.

(The H-CENT VR changes the H-STAT too.)

- 3. Align the R, G, and B at the center of the screen with the V-STAT magnets. (*2)
 - *2: After the V-STAT adjustment, paint on the knobs to lock them.




X A Bad example

V-STAT magnet knobs While keeping the angles for A and B equal (I=I'), align the vertical convergence.

If the A and B knobs are not symmetrical (I=/I'), this has bad effects. The focus may deteriorate and beam striking may occur.


4. For HMC, use the 6-pole magnet to adjust the R and B dots to be symmetrical left and right about the G dot. (*1)

*1:




6-pole magnet

The HMC adjustment changes the opening of the 6-pole magnet.




Adjust the 6-pole magnet so that A=A'. You must maintain the relationship I≠I' while moving the magnet.

95. For VMC, use the 6-pole magnet to adjust the R and B dots to be symmetrical above and below the G dot. (*2)



- 6. Adjust by repeating the adjustments in Items 2 through 5. (*3)
 *3: The above adjustment may affect the landing, so after this adjustment, check the landing again.
- After the adjustment is complete, paint on the knobs to lock them.




3-6. DEFLECTION YOKE NECK ROTATION ADJUSTMENT


If there is misconvergence at both sides on the X or Y axis of the screen, turn the neck of the deflection yoke in the direction of the arrow to reduce the misconvergence for the entire CRT screen to within the tolerance.

1. Reverse misconvergence pattern


Turn the deflection yoke neck down.





Positive misconvergence pattern Turn the deflection yoke neck up.



Pattern when deflection yoke too far to the left









Pattern when deflection yoke too far to the right


2. Insert the three wedges in the deflection yoke and CRT furnel surface to fasten the deflection yoke.




3. The pattern below can not be corrected by turning the neck.



* Gun rotation
The beam is twisted at both sides on the X axis and Y axis.




* HCR large (small)
At both sides of the screen,
the G raster horizontal
component is wider
(narrower) than those of the
R and B rasters.





* VCR large (small)
At both sides of the screen,
the G raster vertical
component is wider
(narrower) than those of
the R and B rasters.

3-7. G2 ADJUSTMENT

- 1. Input a 525 monoscope signal.
- 2. Connect the oscilloscope to A board TP403.
- 3. Of the three reference pulses, measure the lowest one.
- 4. With the Screen VR, adjust so that left end of the waveform is : 1.35 V \pm 0.05







3-8. WHITE BALANCE ADJUSTMENT

For measuring equipment, use a color analyzer (for example from Minolta).

For the PVM-1350, Items 7, 8, 14, 15 and 16 are not necessary.

- 1. Input a 525 monoscope signal.
 - (Input from Line A or Line B, with no burst.)
- 2. Set:
 CONT 0%
 BRT...... 50%
- 3. On a 20-tone gray scale, adjust service mode SUB BRIGHT so that
- 0 and 5 IRE \rightarrow cut off 10 IRE \rightarrow slight glow
- 4. Input 525 all-white (no burst, composite signal).
- 5. Set CONT to 80%.
- 6. Adjust the all-white signal luminance so that the screen luminance is 3 NIT.
- 7. Press MENU and select COL TEMP/BAL.
- 8. Select 6500 K.
- Put the unit into service mode. (*1)
 *1 : Set 3200 K SW to 0 for both 9300K and 6500K.
- 10. Adjust to the standard values with C/T1 6500K BIAS
 (G must be fixed at "512".) (*2)
 *2: Adjust the cut-off to be 3 NIT.
- 11. Switch the all-white signal luminance to 100 IRE.
- 12. Adjust to the standard values with C/T1 6500K GAIN (G must be fixed at "700".)
- 13. Repeat Items 10, 11 and 12 until the adjustment is complete, then write the adjustment data.
- 14. Press MENU and select COL TEMP/BAL.
- 15. Select 9300 K.
- 16. In the same manner as in Items 10, 11, 12 and 13 make the C/T2 9300K BIAS and C/T2 9300K GAIN adjustments.

3-9. BLUE-ONLY WHITE-BALANCE ADJUSTMENT

For the PVM-1350, Items 3, 4, 5, 6, 7 and 8 are not necessary.

- Switch the user control SW Blue Only On (to set blue-only mode).
- Input an all-white signal (no burst composite signal). (*1)
 The luminance of the all-white signal must be 100 IRE.
 CONT 80%
- BRT..... 50%
- 3. Select COL TEMP/BAL.
- 4. Select 6500 K.
- 5. Adjust to the standard values with C/T1 6500K B/O (RED) and C/T1 6500K B/O (GREEN).
- 6. Select COL TEMP/BAL.
- 7. Select 9300 K.
- 8. Adjust to the standard values with C/T1 9300K B/O (RED) and C/T1 9300K B/O (GREEN).
- Check that the white balance is obtained when the all-white signal luminance is adjusted and the screen luminance is 8 NIT.

3-10 SUB BRT ADJUSTMENT


- 1. Input a 525 monoscope signal.
- 2. CONT MIN BRT..... CENTER (50%)
- 3. Put the unit into service mode and select SUB BRIGHT
- 4. Adjust SUB BRIGHT so that 10 IRE gives a slight glow and 10 IRE gives cut off.

3-11. FOCUS ADJUSTMENT

Note: PVM-1350, 1351Q and 1354Q are adjusted with RV707 on the C board.

PVM-1351Q, 1354Q are adjusted with the RV at the top of the FBT main nuit

- 1. Input a 525 monoscope signal.
- 2. Adjust the focus to optimize the focus on the characters "30" at the center of the screen.
- 3. Switch to an all-white signal and check the uniformity.



SECTION 4 SAFETY RELATED ADJUSTMENT

The following adjustments should always be performed when replacing the following components (marked with A, a on the schematic diagram).

+B detection...... ₹ R1535 Tertiary coil detection...... ₹ R1536

Part replosed() Hold Down Circuit...... A board IC500, D533, R1537, C592, R1536, C523, R1560, R551, C549, R518, C506, C512, D501, R506, R519, T501,

Beam Current Protector

Circuit...... A board R508, R515, R516, R517, C513, Q500, Q511

B+ Regulator Circuit..... A board R1535 ☐ G board C603,IC602

B+ MAX VOLTAGE CONFIRMATION (RV601)

Standard: 115.0~117.0 VDC

Check Condition: Input voltage: 130~132 VAC

Note: Use NF Power Supply or make sure that

distortion factor is 3% or less. Input signal: ALL White

Controls : BRT & CONT ⇒ Minimum

HOLD-DOWN CIRCUIT VOLTAGE CONFIRMATION

Check Condition: Input voltage: 130~132 VAC

Input signal: monoscope signal Controls : BRT & PIC ⇒ initial reset B+ voltage: Less than 117.0 V

(1) Hold down circuit (+B Actuation) a) When IABL = $600 \pm 50 \mu$ A, raster goes out at less than 130.5 V of +B voltage (TP502) by adjusting \triangle R690 and RV601.

Input signal: ALL white △ R690: 470-5.6k 1/4 W RN

b) When IABL = 40 \pm 20 μ A, raster goes out at less than 130.5 V of +B voltage (TP502) by adjusting \triangle R690 and RV601. Input signal: Dot


(2) Hold down circuit (Tertiary coil detection voltage) Confirmatory item: 110.0 V voltage should be applied to the (11) pin of IC500.


a) When IABL = $600 \pm 50 \,\mu$ A, raster goes out when applying less than DC 146.7 V voltage to the (11) pin (TP503) of IC500 from outside.


Input signal: ALL white

b) When IABL = 40 \pm 20 μ A, raster goes out when applying less than DC 147.0 V voltage to the (11) pin (TP503) of IC500 from outside.

Input signal: Dot








(CONDUCTOR SIDE)


— 29 —

SECTION 5 CIRCUIT ADJUSTMENTS

5-1. A BOARD ADJUSTMENT

A BOARD - COMPONENT SIDE -





I. Preparations

* When composite video or component signals are supplied from connector CN301, they must be supplied taking into account the effect of the Q board as indicated on the right.

The levels of the signals supplied must be within $\pm 2\%$ of the standard on the right.

Signal		Signal Contents	Standard Level (Pedestal-White)	Reduction Ratio	Connector Feed Level (Pedestal-White)
		100% WHITE	0.714V	93%	0.664V
	358NT	75% WHITE	0.536V	93%	0.498V
COMPOSITE VIDEO	443NT	BURST (GREEN) (This item only P-P)	286mV (632mV)	94% (94%)	269mV (594mV)
(75% COLOR BAR)		100% WHITE	0.7V	94%	0.651V
· · · · · · · · · · · · · · · · · · ·	PAL	75% WHITE	0.525V	94%	0.488V
	SECAM	PAL BURST (GREEN) (This item only P-P)	300mV (664mV)	94% (94%)	282mV (624mV)
		100% WHITE Y	0.7V	94.8%	0.664V
	1	75% WHITE Y	0.525V	94.8%	0.498V
COMPONENT	BETA0	75% COLOR B-Y, R-Y (This item only P-P)	0.7V	94.8%	0.664V
(75% COLOR BAR)		100% WHITE Y	0.7V	94.8%	0.664V
		75% WHITE Y	0.525V	94.8%	0.498V
	SMPTE	75% COLOR B-Y, R-Y (This item only P-P)	0.525V	94.8%	0.498V

* The function or input can be selected by writing the corresponding data from the table below into microcomputer (IC101) RAM address 0006h.

BIT	FUNCTION	DATA
0-3	LINE A/RGB	1
	LINE B/COMPONENT	2
	LINE C/SDI	3
	LINE/RGB	4
1	EXT SYNC	5
1	DEGAUSS	6
ŀ	BLUE ONLY	7
ļ	UNDER SCAN	8
	H/V DELAY	9
	16:9	10
4-7	MENU	1
	SELECT	2
1	UP	3
	DOWN	4

* In this d	ocument, tern	ns inside	boxes	are	names	of
service n	iode adjustme	nts.				
Example	60H-FREQ					

* CONT 80% is the center click position for the user control.

II. Deflection System Adjustment


1. ADJUSTING THE HORIZONTAL OSCILLATION FREQUENCY

- * For the PVM-1350, Items 6 and 7 are not necessary.
- 1. Input a 525 monoscope signal.
- 2. Set:

CONT 80%

BRT 50%

- 3. Put the unit into service mode.
- Drop A board IC507 Pin 1 to ground with a 100 μ/16V electrolytic capacitor. (Ground must use CN505 Pin 3.)
 Or plug the H-FREQ tool into CN505.
- 5. Adjust 60H-FREQ so that the diagonal lines on the screen become vertical lines. (Fig. 1)
- 6. Input a 625 monoscope signal.
- 7. Adjust 50H-FREQ so that the diagonal lines on the screen become vertical lines. (Fig. 1)






Fig. 1

2-1. H-BLK Adjustment

- 1. Input a 525 monoscope signal.
- 2. Set:

CONT 80%

BRT ---- 50%

- 3. Put the unit into service mode.
- 4. Observe the anode of D516 or TP300 with the oscilloscope and adjust H-BLK to obtain the waveform in Fig. 2.




Fig. 2

2-2. H-BLK Adjustment (PVM-1350 only)

- 1. Put the unit into service mode.
- 2. Input an adjustment value of 70 for H-BLK.


3-1. PICTURE PHASE Adjustment (PVM-1351Q/1354Q only)

- 1. Input a 525 monoscope signal.
- 2. Put the unit into under scan mode.
- 3. Set:

CONT ····· Min.

BRT Max.

- 4. Put the unit into service mode.
- 5. Use U/S H SIZE to adjust the size of the monoscope white frame to be about 1 cm to the inside of the limits of the effective screen.
- 6. Turn RV501 (H-CENT) and adjust so that B=B'.
- 7. Adjust 60 VIDEO PHASE so that the signal region comes to the center (A=A') of the deflection region. (Fig. 3)



- 8. Input a 625 monoscope signal.
- 9. Adjust 50 VIDEO PHASE in the same manner.

3-2. PICTURE PHASE Adjustment (PVM-1350 only)

- 1. Input a 525 monoscope signal.
- 2. Put the unit into service mode.
- 3. Input an adjustment value of 123 for 60 VIDEO PHASE
- 4. Input an adjustment value of 137 for 50 VIDEO PHASE
- Roughly adjust H-SIZE so that the horizontal size is 15.75 frames.
- 6. Turn RV501 (H-CENT) and adjust so that the left and right over scan amounts are equal.

4-1. V-BLK Adjustment (PVM-1351Q/1354Q only)

- 1. Input a 525 monoscope signal.
- 2. Put the unit into under scan mode.
- 3. Set:

CONT ····· Min.

BRT·····Max.

- 4. Put the unit into service mode.
- 5. Adjust V BLK (60) so that before 0.5H of the white frame on the top of the monoscope is barely unblocked.
- End under scan mode and put the unit into Normal 16:9 mode.
- 7. Adjust 16:9 BLK START (60) and 16:9 BLK END (60) so that the vertical direction frame count is 11.75 for the light emitting section of the screen and at the same tine the top and bottom block amounts are the same.

Note: This must be done before the 16:9 V-SIZE adjustment.

- 8. Input a 625 monoscope signal.
- 9. Adjust V BLK (50) in the same manner as in 5 above.

1010. Adjust 16:9 BLK START (50) and 16:9 BLK END

(50) in the same manner as in 7 and 8 above so that the vertical direction frame count is 11.2 for the light emitting section of the screen and at the same time the top and bottom block amounts are the same.

4-2. V-BLK Adjustment (PVM-1350 only)

- 1. Put the unit into service mode.
- 2. Use 60 V-SIZE and reduce the image size so that the upper and lower blanking can be seen.
- 3. Use 60 V-BLK and adjust so that the white frame of the upper part becomes ½.

5. VERTICAL DEFLECTION SECTION Adjustment

- * PVM-1350 has no 16: 9 mode.
- * PVM-1350 has no 625 mode.

Normal V. Size Standards

		525	625	
4:3		11.75 ± 0.2 frames	11.2 ± 0.2 frames	
16:9	14"	154 ± 2mm	4	
	20 "	217 ± 3mm	-	

- 1. Input a 525 monoscope signal.
- 2. Set:

CONT 80%

BRT50%

- 3. Put the unit into service mode.
- 4. Adjust the size to 12 frames with NOR 60 V SIZE

Adjust the vertical linearity with V LIN

Adjust the vertical centering with 60 V CENT.

Note: The V.CENT adjustment must be re-evaluated after the V.LIN adjustment.

Adjust the size to the standard value with NOR 60 V SIZE .

- 5. Put the unit into 16:9 mode.
- 6. Adjust in the same manner with 16: 9 NOR V SIZE (60)
- 7. Put the unit into normal scan mode.
- 8. Input a 625 monoscope signal.
- Roughly adjust NOR 50V SIZE so that the size is 11 frames.
 Adjust the vertical centering with 50 V CENT.

Note: The V.CENT adjustment must be re-evaluated after the V.LIN adjustment.

Adjust the size to the standard value with NOR 50 V SIZE.

- 10. Put the unit into 16:9 mode.
- 11. Adjust in the same manner with 16: 9 NOR V SIZE (50)

6. HORIZONTAL DEFLECTION SECTION ADJUSTMENT NORMAL SCAN Adjustment

- * PVM-1350 hasno 625 mode.
- * PVM-1350 hasno 16: 9 mode.
- 1. Input a 525 monoscope signal.
- 2. Set

CONT 80%

BRT50%

- 3. Put the unit into service mode.
- 4. Roughly adjust NOR H SIZE so that the size is 15.75 frames.
- 5. Adjust the horizontal deflection section with


NOR PIN AMP, NOR PIN PHASE, NOR U/L PIN, SEXY, V BOW and V ANGLE.

(While adjusting the pincushion distortion and bow distortion with V-ANGL and BOW, adjust so that the horizontal and vertical of the screen are straight lines.)

- 6. Put the unit into 16:9 mode.
- 7. Adjust with 16:9 NOR PIN AMP,
 16:9 NOR PIN PHASE, and 16:9 NOR U/L PIN in the same manner as in Item 5.

Normal H.Size Standards

	525	625
4:3	15.75 ± 0.2 frames	15.0 ± 0.2 frames
16:9	15.75 ± 0.2 frames	15.0 ± 0.2 frames



7. HORIZONTAL DEFLECTION SECTION Adjustment (UNDER SCAN adjustment) (PVM-1351Q/1354Q only)

Standard value

	525	625
U/S H-SIZE V-SIZE	252 ± 2mm 188 ± 2mm	**************************************
16:9 U/S V-SIZE	142 ± 2mm	-

8. H/V DELAY Adjustment

- 1. H-DELAY adjustment
 - 1) Input a 525 monoscope signal.

2) Set:

CONT 80%

BRT 50%

- 3) Put the unit into H/V DELAY mode.
- 4) Put the unit into service mode.
- 5) Connect the oscilloscope probe to IC503 Pin 7, then adjust H DELAY so that the waveform is as in Fig. 5.
- 2. V-DELAY Adjustment
 - 1) Input a 525 monoscope signal.


2) Set:

CONT 80%

BRT 50%


- 3) Put the unit into H/V DELAY mode.
- 4) Put the unit into service mode.
- 5) Connect the oscilloscope probe to IC502 Pin 7, then adjust V DELAY so that the waveform is as in Fig. 6.
- 3. Picture verification (PVM-1351Q/1354Q only)

Verify that the picture is as in Fig. 7.



9. OSD POSITION Adjustment

- 1. Input a 525 color bar signal.
- Connect the oscilloscope probes to TP300 (H-BLK) and IC104 Pin 14.
- 3. Adjust OSD POSITION so that the gap between the rising edge of the H-BLK waveform and the right edge character (the right edge of the " " " for service mode OSD POSITION) is: 57 μS ± 0.2 μS



10. WRITING THE ADJUSTMENT

1. Write the adjustment results into memory.

Note: If you cut off the power before writing, the results of your adjustments are all lost.

III. SIGNAL SYSTEM ADJUSTMENT

1. NORM AL AND H/V DL SUB CON ADJUSTMENT

- * PVM-1350 has neither 16: 9 nor H/V-DL.
- 1. Input a vertical white line signal.

Note: Use a vertical white line signal (525 no burst, H width 3μ S, 100IRE).


2. Set:

CONT 80%

- BRT.....50%
- 3. Connect the oscilloscope probe to A board CN401 Pin 3.
- 4. Put the unit into service mode.
- 5. Provisionally input an adjustment value of 69 for SUB BRT.
- 6. Adjust the pedestal or the distance between the sync tip and white with SUB CON (4:3 NOR), SUB CON (4:3 H/V DELAY), SUB CON (16:9 NOR), and SUB CON (16:9


| H/V DELAY)|.
| SUB CON (4:3 NOR).
| SUB CON (16:9 NOR) | (Fig. 9)
| SUB CON (4:3 H/V DELAY) | (Fig. 9)

SUB CON (16:9 H/V DELAY)



		14"		
	20″	PVM-1354Q	PVM-1350/ 1351Q	
4:3	1.55	1.50	1.40	
	Vp-p	Vp-p	Vp-p	
16:9	1.40	1.33	1.24	
	Vp-p	Vp-p	Vp-p	

(Fig. 10).




SUB-CON 4: 3, H/V-DL SUB-CON 16: 9, H/V-DL

İ		"	14"		
		20″	PVM-1354Q	PVM-1350/ 1351Q	
	4:3	1.55 Vp-p	1.50 Vp-p	1.40 Vp-p	
	16:9	1.40 Vp-p	1.33 Vp-p	1.24 Vp-p	

2-1. SUB PHASE Adjustment (PVM-1351Q/1354Q only)

- Input a component color bar (R-Y) and EXT SYNC (Beta 0 level signal).
- 2. Put the unit into Ext Sync mode.
- 3. Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 4. Put the unit into service mode.
- 5. Adjust SUB PHASE to minimize the output waveform (15 mVp-p max.) (Fig. 11)




2-2. SUB PHASE Adjustment (PVM-1350 only)

- 1. Input a NTSC color bar signal.
- 2. Connect between L309 and ground and between TP507 and a 5V line (L320 line).
- 3. Put the unit into service mode.
- 4. Adjust SUB PHASE to minimize the output waveform (15 mVp-p max.) (Fig. 11)

3-1. SUB CHROMA Adjustment (PVM-1351Q/1354Q only)

- 1. Input a component color bar (R-Y, Y, B-Y). (Beta 0 level signal).
- 2. From the menu, make the Component Level Beta 0.
- 3. Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 4. Put the unit into service mode.
- 5. Using SUB CHROMA NORMAL, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 12)



Adjust so that the levels of the first peak and the fourth peak are the same.


Fig. 12

3-2. SUB CHROMA Adjustment (PVM-1350 only)

- 1. Put the unit into service mode.
- 2. Input an adjustment value of 98 for SUB CHROMA NORMAL. (Fig. 12)

4. R-Y LEVEL ADJUSTMENT (PVM-1351Q/1354Q only)

- 1. Input a component color bar (R-Y, Y, B-Y). (Beta 0 level signal).
- 2. From the menu, make the Component Level Beta 0.
- 3. Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 4. Put the unit into service mode.
- 5. Using R-Y LEVEL COMPONENT, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 13)




Adjust so that B=D above (20 mV max.) Check that the difference between D and C is no greater than 30 mV

SUB CHROMA N10/SMPTE Adjustment (PVM-1351Q/ 1354Q only)

- Input a component color bar (R-Y, Y, B-Y). (SMPTE level signal).
- 2. From the menu, make the Component Level N10/SMPTE.
- 3. Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 4. Put the unit into service mode.
- In the same manner as in 4-5, adjust SUB CHROMA N10/SMPTE.

6. BURST GATE PULSE WIDTH Adjustment

- 1. Input an NTSC color bar.
- Connect the oscilloscope probes to TP301 (COMP-SYNC) and Q363 or IC305 Pin 1. (Be careful! IC305 Pin 1 is a high-impedance line.)
- 3. Put the unit into service mode.
- Adjust BGP WIDTH so that the output waveform has the relationship shown in Fig. 14.




7. VXO Adjustment

- 1. X'tal 358
- 1) Input an NTSC color bar.
- 2) Connect the frequency counter to IC305 Pin 21.
- 3) Put the unit into service mode.
- 4) Connect the circuit on the right to IC305 Pin 1.
- 5) Adjust CRYSTAL 358 so that the counter reading meets the standard below. (You can also just adjust for where the color flicker stops.)

X'tal 358

Standard level 3.579545 ± 20 Hz



(For connecting to Pin 1, have the four diodes as close to Pin 1 as possible to reduce the length of the wires.)


- 2. X'tal 443 (PVM-1351Q/1354Q only)
- 1) Input a 443 NTSC color bar.
- 2) Connect the frequency counter to IC305 Pin 21.
- 3) Put the unit into service mode.
- 4) Connect to IC305 Pin 1 in the same manner as in 1-4).
- 5) Adjust Crystal 443 in the same manner as in 1-5).

X'tal 443

Standard level 4.433619 ± 20 Hz

8. NTSC COLOR DEMODULATION Adjustment

- * The adjustment in 8-1-3) is not necessary for PVM-1351Q/ 1354Q.
- * The adjustment in 8-1-4) is not necessary for PVM-1350.
- 1. NT 358 PHASE (NORMAL)
- 1) Input an NTSC color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Supply 4 VDC to IC305 Pin 4.
- 4) Put the unit into H/V delay mode.
- 5) Put the unit into service mode.
- Adjust PHASE NTSC 358 NOR so that the output waveform burst section is a straight line. (Fig. 15)




- 2. NT358 PHASE (ACC OFF) (PVM-1351Q/1354Q only)
 - 1) Switch ACC Off with the menu.
 - Adjust in the same manner as in 8-1 above, but adjust with PHASE NTSC 358 ACC OFF. (Fig. 15)

3. NT358 B-Y PHASE


The phase adjustment must be carried out before the chroma adjustment.

- Input an NTSC color bar.
 (Input only the R-Y component. Have B-Y and Y off.)
- 2) Connect the oscilloscope probe to TP305.
- 3) Put the unit into service mode.
- 4) Adjust B-Y PHASE NTSC 358 so that the color components form a straight line.
- 4. NT358 CHROMA (NORMAL)
- 1) Input an NTSC color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 3) Put the unit into service mode.
- 4) Using CHROMA NTSC 358 NOR, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 16)




Adjust so that the levels of the first peak and the fourth peak are the same.

- 5. NT 358 CHROMA (ACC OFF) (PVM-1351Q/1354Q only)
- 1) Switch ACC Off with the menu.
- 2) Adjust CHROMA NTSC 358 ACC OFF in the same manner as 8.-4 above. (Fig. 16)
- 6. NTSC 358 R-Y LEVEL
- 1) Input an NTSC358 color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 3) Put the unit into service mode.
- 4) Using R-Y LEVEL NTSC 358, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 17)




Adjust so that B=D above (20 mV max.) Check that the difference between B and C is no greater than 60 mV.

- 7. NTSC 443 PHASE (NORMAL) (PVM-1351Q/1354Q only)
- * The adjustment in 8-7-3) is not necessary for PVM-1351Q/1354Q.
- 1) Input an NTSC 443 color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Supply 4 VDC to IC305 Pin 4.
- 4) Put the unit into H/V delay mode.
- 5) Put the unit into service mode.
- 6) Adjust PHASE NTSC 443 NOR so that the output waveform burst section is a straight line. (Fig. 18)




- 8. NTSC 443 PHASE (ACC OFF) (PVM-1351Q/1354Q only)
- 1) Switch ACC Off with the menu.
- 2) Adjust PHASE NTSC 443 ACC OFF in the same manner as in 7-5). above. (Fig. 20)
- NTSC 443 B-Y PHASE (PVM-1351Q/1354Q only)
 NTSC 443 CHROMA NOR
- 1) Input an NTSC 443 color bar.
- 2) Connect the oscilloscope probe to TP402.
- 3) Put the unit into service mode.
- 4) Adjust B-Y PHASE NTSC 443 and CHROMA NTSC 443

 NOR so that the tracking is normal and the tops of the waveform line up. (Fig. 19)



- 10. NTSC 443 CHROMA (ACC OFF) (PVM-1351Q/1354Q only)
- 1) Switch ACC Off with the menu.
- 2) Adjust CHROMA NTSC 443 ACC OFF in the same manner as 9-4). (Fig. 22)



- 11. NTSC 443 R-Y LEVEL (PVM-1351Q/1354Q only)
- 1) Input an NTSC 443 color bar.
- 2) Connect the oscilloscope probe to TP401.
- 3) Put the unit into service mode.
- 4) Adjust R-Y LEVEL NTSC 443 in the same manner as 6-4). (Fig. 17)
- 12. PAL PHASE (NORMAL) (PVM-1351Q/1354Q only)
- 1) Input a PAL SP color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Put the unit into service mode.
- 4) Adjust PHASE PAL NOR so that the B-Y anti-PAL signal waveform is 0. (Fig. 21)




Fig. 21

13. PLL PHASE (ACC OFF) (PVM-1351Q/1354Q only)


the average is 0.

- 1) Switch ACC Off with the menu.
- 2) Adjust PHASE PAL ACC OFF in the same manner as 12-4).

14. PAL B-Y PHASE (PVM-1351Q/1354Q only)

- 1) Input a PAL SP color bar.
- 2) Connect the oscilloscope probe to TP305.
- 3) Put the unit into service mode.
- 4) Adjust B-Y PHASE PAL so that the B-Y anti-PAL signal waveform is 0. (Fig. 22)

(R-Y OUT)




* Varies every H, although slightly, so adjust so that the average is 0.

Fig. 22

15. PAL CHROMA (NORMAL) (PVM-1351Q/1354Q only)


- 1) Input a PAL color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 3) Put the unit into service mode.
- 4) Adjust CHROMA PAL NOR so that the tops of the waveform line up. (Fig. 23)



16. PAL CHROMA (ACC OFF) (PVM-1351Q/1354Q only)

- 1) Switch ACC Off with the menu.
- Adjust CHROMA PAL ACC OFF in the same mariner as 15.-4). (Fig. 23)

- 17. PAL R-Y LEVEL (PVM-1351Q/1354Q only)
- 1) Input a PAL color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 3) Put the unit into service mode.
- 4) Adjust R-Y LEVEL PAL so that the tops of the waveform line up as in the diagram below. (Fig. 24)



9. SECAM Adjustmnet

* This must be done after the deflection adjustment.

Note: Varies with H-FREQ, H-BLK, VIDEO-PHASE, ANGLE, BOW, H-DELAY, etc.

1. HP EIDTH (NORMAL) ADJUSMTNET (PVM-1351Q/1354Q only)


The board adjustment in 9.-1. is a rough adjustment and this may also be managed with the IC317 Pin 10 pulse width.

- 1) Input a SECAM color bar.
- 2) Put the unit into under scan mode.
- 3) Put the unit into service mode.
- 4) Adjust HP WIDTH NOR so that the color of the color section at the top left of the screen almost disappears.
- 2. HP POSITIOM ADJUSMTNET (PVM-1351Q/1354Q only)

Note: 9.-2. is the same as above. This adjustment can be managed with the phase relationship between the start of the pulse at IC317 Pin 10 and the input video signal.

- 1) Input a SECAM color bar.
- 2) Put the unit into H/V delay mode.
- 3) Put the unit into service mode.
- 4) Adjust HP POSITION as in the diagram on the right.
- 3. HP WIDTH (H/V -DL) ADJUSMTNET (PVM-1351Q/1354Q only)
- 1) Input a SECAM color bar.
- 2) Put the unit into H/V delay mode.
- 3) Put the unit into service mode.


 Adjust HP WIDTH H/V DELAY as in the diagram below.
 Note: Check the HP POSITION and if it is off, repeat 2 and 3.




- 4. SECAM COL BALANCE (PVM-1351Q/1354Q only)
- 1) Input a SECAM color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Put the unit into service mode.
- Adjust SECAM COLOR BALANCE R-Y so that the non-color section forms a straight line.
- 5) Connect the oscilloscope probe to TP305.
- Adjust SECAM COLOR BALANCE B-Y so that the non-color section forms a straight line.
- 5. SECAM CHROMA (PVM-1351Q/1354Q only)
- 1) Input a SECAM color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 3) Put the unit into service mode.
- 4) Adjust CHROMA SECAM so that the tops of the waveform line up as in the diagram below. (Fig. 25)

IC404 30 pin

Adjust so that the B and D peaks are the same.



- 6. SECAM R-Y LEVEL (PVM-1351Q/1354Q only)
- 1) Input a SECAM color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 3) Put the unit into service mode.
- 4) Adjust R-Y LEVE SECAM so that the tops of the waveform line up as in the diagram below. (Fig. 26)




10. Writing the adjustment results

1. Write the adjustment results into memory.

5-2. G BOARD ADJUSTMENT

G BOARD - COMPONENT SIDE -




- 1. Checking the output lines
- 1) Input a color bar signal.
- 2) Adjust RV601 so that the +B voltage is 115 \pm 0.1 V.
- 3) Check that the output lines meet the standards below.


	<u> </u>
15V	$16.0 \pm 1.0 $ V
5V(A)	$5.0 \pm 0.3V$
5V(B)	$5.0 \pm 0.5 V$
7V	$7.2 \pm 0.5 V$
– 15V	$-16.3 \pm 1.0V$


MEMO	
	•••••
	•
	·. <u>-</u>


SECTION 6 DIAGRAMS






























AL REMOTE OPTION CN308

6-3. CIRCUIT BOARDS LOCATION



6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W

- All resistors are in ohms.
- : nonflammable resistor.
- : fusible resistor.
- : internal component.
- : panel designation, and adjustment for repair.
- · All variable and adjustable resistors have characteristic curve B. unless otherwise noted.
- The components identified by in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value
- originally used. · When replacing components identified by ... make the
- necessary adjustments indicated. If results do not meet the specified value, change the component identified by $oldsymbol{\Xi}$ and repeat the adjustment until the specified value is achieved. (Refer to R690 adjust on Page 29 and 30.)
- When replacing the part in below table, be sure to perform the related adjustment.

Part replaced (☑)	Adjustment (►)
C506, C512, C513, C523, C549, C592, D501, D533, IC500, IC507, Q500, Q511,R506, R508, R515, R516, R517, R518,R519, R551, R1535, R1536, R1537, R1560, T501	R1535, R1536 (HOLD-DOWN)

- All voltages are in V.
- Voltage are dc with respect to ground unless otherwise noted.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production

tolerances. • : B + bus

• ---: B - bus.

• signal path.

 No mark: with PAL colour-bar signal sreceived or common voltage.

For the respective voltage ratings in SECAM, NTSC 3.58, NTSC 4.43.

S-VIDEO, and ANALOG RGB modes, see the table

Reference information

RESISTOR : RN METAL FILM SOLID : RC NONFLAMMABLE CARBON : FPRD : FUSE NONFLAMMABLE FUSIBLE NONFLAMMABLE WIREWOUND : RW NONFLAMMABLE METAL OXIDE : RS NONFLAMMABLE CEMENT : RB : LF-8L MICRO INDUCTOR CAPACITOR : TA TANTALUM STYROL : PS POLYPROPYLENE : PT

MYLAR METALIZED POLYESTER : MPS


METALIZED POLYPROPYLENE BIPOLAR : ALB


HIGH TEMPERATURE : ALT HIGH RIPPLE : ALR


Note: The components identified by shading and mark

A are critical for safety. Replace only with part number specified.


Note: Les composants identifiés par une trame et par une marque A sont d'une importance critique pour la sécurité. Ne les remplacer que par des pièces de numéro spécifié.







6-3. CIRCUIT BOARDS LOCATION



6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W

- All resistors are in ohms.
- : nonflammable resistor.
- : fusible resistor.
- △ : internal component.
- : panel designation, and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- The components identified by
 ☐ in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
- When replacing components identified by ... make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by A and repeat the adjustment until the specified value is achieved.
- (Refer to R690 adjust on Page 29 and 30.) . When replacing the part in below table, be sure to perform the related adjustment.

Part replaced (☑)	Adjustment (☑)
C506, C512, C513, C523, C549, C592, D501, D533, IC500, IC507, Q500, Q511,R506, R508, R515, R516, R517, R518,R519, R551, R1535, R1536, R1537, R1560, T501	R1535, R1536 (HOLD-DOWN)

- All voltages are in V.
- Voltage are dc with respect to ground unless otherwise noted.
- · Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- : B + bus. • - B - bus.
- signal path.
- No mark ; with PAL colour-bar signal sreceived or common

voltage.

• For the respective voltage ratings in SECAM, NTSC 3.58, NTSC 4.43, S-VIDEO, and ANALOG RGB modes, see the table

Reference information

Heterence i	ntormatic	on
RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RW	NONFLAMMABLE WIREWOUND
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER


METALIZED POLYPROPYLENE : MPP

: ALB BIPOLAR : ALT HIGH TEMPERATURE HIGH RIPPLE : ALR


Note: The components identified by shading and mark n are critical for safety. Replace only with part number specified.


Note: Les composants identifiés par une trame et par une marque A sont d'une importance critique pour la sécurité. Ne les remplacer que par des pièces de numéro spécifié.

A BOARD IC303 CXA1214F



A BOARD IC305 M51279FF





) SCHEMATIC DIAGRAMS

ed. pF: μμF ivtics. one for rating

repair. cteristic curve

sic schematic or each set in ion. with the value

1, make the not meet the ed by 🖸 and s is achieved.

to perform the

ment (🔀)

5, R1536 D-DOWN)

- All voltages are in V.
- Voltage are dc with respect to ground unless otherwise noted.
- · Readings are taken with a color-bar signal input.
- · Voltage variations may be noted due to normal production tolerances.
- ---: B bus.
- signal path.
- No mark: with PAL colour-bar signal sreceived or common voltage.
- For the respective voltage ratings in SECAM, NTSC 3.58, NTSC 4.43, S-VIDEO, and ANALOG RGB modes, see the table

Reference information


RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	; RW	NONFLAMMABLE WIREWOUND
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR

- METALIZED POLYESTER METALIZED POLYPROPYLENE : MPP
- BIPOLAR : ALB
- : ALT HIGH TEMPERATURE : ALR HIGH RIPPLE


Note: The components identified by shading and mark A are critical for safety. Replace only with part number specified.


Note: Les composants identifiés par une trame et par une marque A sont d'une importance critique pour la sécurité. Ne les remplacer que par des pièces de numéro spécifié.


A BOARD IC303 CXA1214P




A BOARD IC305 M51279FP








: Pattern from the side which enables seeing.



CONDUCT	OR SIDE			0515		D400	<u> </u>	
IC		Q345	D-8	Q517	C – 4 C – 4	D408 D410	B-5 C-5	
IC101	A - 9	Q349	E-9	Q519	B-4	D410	B-6	
IC102	B - 10	Q350	D-8	Q520 Q522	B-4 E-5	D411	C-5	
IC108	B-8	Q351	D-8	Q522 Q524	A-5	D421	C-5	
IC200	A - 5	Q352	D-8	1	A-4	D422 D425	C-5	
IC303	E-9	Q361	F-8	Q525	A-3	D425 D426	C-6	
IC404	D-6	0363	G-9	Q526	A-3	i	1 1	
IC505	E-4	Q364	D-8	510	D.E.	D427	B-6	
IC507	D-4	Q367	E-8	DIC	DE	D500	G-5	
10001	J = 4	Q368	E-8	D101	B-10	D501	G-2	
		Q369	E-8	D102	B-9	D502	E-2	
TRANS	SISTOR	Q375	D-8	D103	B-9	D503	C-2	
Q101	A - 9	0401	B-6	D107	B-9	D504	D-2	1
Q111	C - 10	Q402	B-6	D200	A – 4	D505	E-1	
Q113	A - 7	Q403	B-6	D301	G-8	D506	D-2	i
Q201	A-6	Q405	C-6	D302	F-9	D507	G-5	
Q301	G-8	Q407	C-7	D303	F-7	D508	G-5	
Q302	G-10	0409	D-7	D304	G-7	D509	G-5	
Q303	G-6	Q417	C-6	D307	G-8	D510	F-5	
Q304	G-6	Q418	B-5	D309	G-8	D512	D-2	
Q305	G-8	0419	C-6	D310	G-8	D513	E-5	
Q306	G-7	Q420	C-6	D311	G-9	D514	E-4 F-1	
Q307	G-8	Q421	B-5	D315	E-8	D515	F-5	
Q309	G-8	0422	B-5	D317	D-9	D516 D517	D-4	
Q310	G-7	Q423	C-5	D320	D-9	D517	E-5	
Q312	G-8	Q424	C-5	D322	D-9	D518	C-4	
Q313	G-8	Q428	D-6	D323	C-9	D519	1	
Q315	G-8	Q431	B-5	D324	E-9		A-4 A-2	1
Q318	G-8	Q434	C-5	D325	D-8	D523 D524	C-2	ļ
Q319	F-7	Q439	C-6	D326	E-9	D524 D525	C-2	
Q321	G-8	Q443 Q444	C-5 B-5	D333	D-8	D525	B-4	
Q323	G - 10	Q444 Q500	F-2	D337	E-8	D526	B-4	
Q325	F-8		D-2	D344	D-8	D528	A-1	
Q326	F-6	Q501 Q502	D-3	D345	E-7	D528	A-2	
Q327	F-6	Q502 Q503	B-3	D346	E-7	D530	A-1	
Q328	G-9	Q503 Q505	E-5	D347	E-7	D530	A-4	
Q329	G-9	Q505 Q506	B-4	D353	D-8	D532	A-4	
Q330	F-9	Q507	E-5	D354	B-7	D532	G-1	
Q331	F-9	Q508	C-4	D355	C-7	D533	B-4	
Q332	G-10	Q509	G-5	D363	E-8	D536	A-5	
Q333	D-9	Q509 Q511	F-2	D364	E-8	5555	^ ~	
Q334	F-9	Q511	A - 1	D401	B-7			
Q336	E-10	4	1	D404	D-6	VARI	ABLE	
Q337	E-10	Q513	A - 1	D405	B-5		STOR	1
Q338	C-9	Q514	B-4 B-2	D407	D-7			1
0339	D-8	Q515	B-2	1	1	RV501	B-2	1



: Pattern from the side which enables seeing. - A BOARD -(Conductor Side) B-6 C - 5 C - 5 C-5 C-6 B-6 G-5 G - 2 E - 2 C - 2 D - 2 E - 1 D -- 2 G-5 G - 5 G-5 F-5 D - 2 E - 5 E - 4 F - 1 F-5 D - 4 E - 5 C - 4 A - 4 D A - 2 C - 2 C - 2 B - 4 B - 3 A - 1 A - 2 A - 1 A - 4 A - 4 G - 1 B - 4 SONY A - 5 Α VARIABLE RESISTOR RV501 B - 2

UCTOR SIDE

E - 9

E - 4

D - 4

C - 10

A - 6

G - 8

G - 10

G-6

G - 8

G - 7

G - 8

G - 8

G - 8

G-8

G - 8

G - 8

G-8

G - 10

F - 6

F-6

G - 9

G - 9

F - 9

G - 10

D - 9

E - 10

E - 10

C - 9

NSISTOR

IC

D - 8

E-9

D-8

D-8

D - 8

F - 8

G - 9

D - 8

E - 8

E - 8

E - 8

D - 8

B - 6

B - 6

B-6

C-6

C - 7

D - 7

C - 6

B - 5

C - 6

C - 6

B - 5

B - 5

C - 5

C - 5

D-6

B - 5

C = 5

C-6

C - 5

B - 5

F - 2

D - 2

D - 3

E - 5

B - 4

E-5

G - 5

F – 2

A - 1

B - 4

B - 2

0345

Q349

0350

Q351

Q352

Q361

Q363

Q364

Q367

Q368

Q369

Q375

Q401

Q402

Q403

Q405

0407

Q409

Q417

Q418

Q419

Q420

Q421

Q422

Q423

Q424

Q428

0431

Q434

Q439

Q443

Q444

Q500

Q501

Q502

Q503

Q505

Q506

Q507

Q508

Q509

Q511

Q512

Q513

Q514

Q515

0517

Q519

Q520

Q522

Q524

Q525

Q526

D101

D102

D103

D107

D200

D301

D303

D304

D309

D310

D311

D315

D317

D320

D322

D323

D324

D325

D326

D333

D337

D344

D345

D346

D347

D353

D354

D355

D363

D364

D401

D404

D405

D407

C - 4

B - 4

E - 5

A - 4

B - 10

B - 9

B - 9

B - 9

A - 4

G - 8

F - 7

G – 7

G - 8

G-8

G - 8

G-9

E - 8

D - 9

D - 9

C - 9

E-9

D-8

E - 9

E - 8

D - 8

E - 7

E - 7

D - 8

B - 7

C - 7

E - 8

E - 8

B - 7

B - 5

DIODE

D408

D410

D411

D421

D422

D425

D426

D427

D500

D501

D502

D503

D504

D505

D506

D507

D508

D509

D510

D512

D513

D514

D515

D516

D517

D518

D519

D523

D524

D525

D526

D528

D529


D531


D532


D533

D534

D536







. A BOARD WAVEFORMS

	· A BOARD WAV	EFORMS	
	1) 4.3 Vp-p(H)	2 5.6 Vp-p (10MHz)	3 4.8 Vp-p(V)
	PAL 0.3 Vp-p (H) SECUM 0.32 Vp-p (H)	4 19 1 19 1 19 1 19 NTSC3.58.4.43 0.28 Vp-p (H) 5-V1060 0.35 Vp-p (H)	© 10.45 Vp-p (H) 50.45 Vp-p (H)
	5 ~~1/1/1/1/1/1/1/4 NT5C3.52 VP-P (H) NT5C4.63 VP-P (H)	(5) -4/Ml/Ml/Ml/4 5-71969 0.45 Vp-p (H)	6 PAL 0.57 Vp-p (H) SECAN 0.45 Vp-p (H)
	6 γ/	PAL 2.4 Vp-p (H) SECUM 2.3 Vp-p (H)	THISCS.58 Vp-p (H) NTSCS.43 2.1 Vp-p (H) NTSC4.43 2.2 Vp-p (H)
	7 	⑦	® MMMMM AMALOG ROS AMALOG ROS O. E Vp-p (H)
i i	9 ANALOG PGB 0.6 Vp-p (H)	10 	2.6 Vp-p(H) SECAN 2.5 Vp-p(H)
HERE	NTSC3.58 2.4 Vp-p (H) 2.5 Vp-p (H)	5-VIDED (H)	(H)
The second second	4.6 Vp-p (V)	1.8 Vp-p(H) 1.9 Vp-p(H)	H: 1.7 Vp -p (H) 1.7 Vp -p (H)
	(H) 0-9 (H)	13 1000 1000 1000 1000 1000 1000 1000 1	3.7 Vp-p(H)
	()		Fat Val

A BOARD

A BUARD								
Ref	LOCATION	PVM-1350	PVM- 1351Q/1354Q					
C174	H - 3	-	47P					
C496	H - 10	-	82P					
CN104	A-1	· -	3P					
CN105	1-1	-	12P					
D114	H-4	- :	MA110					
D426	J-11	-	RD4.7SB					
L105	F-3	-	100 µ H					
Q102	1-3	-	2SA1037K					
Q103	1-3	-	2SA1037K BMXIT110					
Q104 Q105	E-7 8-5	_	DTA144EK					
R107	H-4	_	4.7K					
R122	D-3	- 100	0					
R124	D-3	- - - 150K	•					
R126	G-5	_	•					
R127	D-3	-	0					
R130	8-3	150K	120K					
R133	H-3	-	56K					
R135	1-5	-	33K					
R145	D-4	-	0					
R147	E-4		•					
R152	J-6	-	•					
R156	E-4	-						
R158	G-7	-	0					
R168 R169	E-7	-	33K 270K					
R171	E-6 E-7	I -	180					
R172	G-4	1 -	. 0					
R174	B-4	_						
R184	8-5	l -						
R186	1-5	-						
R194	1-5	-						
R404	H - 10	j -	150					
R1101	D-6	-	0					
R1111	H-3	-	4.7K					
R1112	H-4	-	4.7K					
R1114 R1115	H-3	-	1K 1K					
R1116	1-3		12K					
R1117	1-3	1 -	6.8K					
R1119	1-3	_	62K					
R1120	1-4	l -	47K					
R1126	H-4	-	470					
R1127	1-6	-						
R1130	F-3	-	1K					
R1133	H-3		6.8K					
R1137	A-2	-	10K					
R1138	A-2	-	22K					
R1161	A - 2		1M					
R1182	A-2	-	470K					
R1167 R1168	E-3 E-3	1 -	100K					
R1169	E-3	-	100K					
R1170	E-2	-	47K					
R1173	1-6	-	0					
R1414	H - 12	2.2K	3.3K					
R1423	G - 12	2.2K	3.3K					
R1433	J-11	-	33K					
R1434	H - 10	0	580					
R1435	H - 10	-	1.8K					
R1444	H - 12	2.2K	3.3K					

A BOARD * MARK

PAL SECAN NISS		···					
		PAL	SECAM	NTSC 3.58		S-VIDEO	
B						+	
99	6	4.1	3.4	0	0.1	0	0
Color							
19)		
38 5.0 5.0 0.0 0.0 0.0 0.0 88 0.1 0.0 0.1 0.1 0.4 0.1 89 0.5 0.0 0.0 0.0 0.0 80 0.1 0.0 0.1 0.1 4.9 0.1 81 5.0 5.0 5.0 5.0 5.0 5.5 92 42 41 44 65 62 63 63 93 44 44 0.1 0.1 0.1 94 42 44 0.1 0.1 0.1 95 42 41 44 0.1 0.1 95 42 41 44 0.1 0.1 96 40 40 44 0.1 0.1 96 40 41 0.1 0.1 97 42 41 0.1 0.1 98 40 41 0.1 0.1 99 40 50 50 50 50 50 99 40 50 50 50 50 99 40 50 50 50 50 90 50 25 55 53 38 12 99 36 30 29 122 39 44 90 51 60 40 40 40 29 44 90 60 60 60 60 60 90 22 23 22 122 22 22 90 90 90 90 90 90 90				·			
St.							
Section Sect			+				
							
19							
Section							
32 42 0.1 43 42 4							
Section Sect				+			
99							
9				1.0	€8		1.9
Section Sect							
CODE							
19				+			
C105							
9	IC105 ③						
19							
Section Sect	(3)	5.4	5.4	5.4		6.6	8.1
The color of the							
				2.4	2.4		
O							
0							
0	0	3.1	3.1	2.5			
19							
CiOT	. 3	3.6	3.5	4.8	13.6	4.3	9.5
		2.3	2.3	2.2	1	2.1	0
□ □ □ □ □ □ □ □ □ □							
© 2.9 2.9 2.9 2.6 2.9		2.9	2.9	2.9	2.9	2.1	2.9
0	(8)						
3 32 32 54 53 53 54 3 45 46 50 50 50 37 50 45 46 50 50 50 37 50 45 45 45 45 45 44 44							
Clos	• •	3.2	3.2	5.4	5.4	5.3	5.4
Ci090							
□ 11.9 11.9 11.9 11.9 11.9 0.1 11.9 0.1 11.9 11.9 0.1 11.9 11.9 0.1 11.9 11.9 0.1 11.9 11.9 0.1 11.9 1							4.4
11.9							
		11.9	11.9	0.1	0	- 0.1	11.8
9 5.8 5.8 5.8 5.8 6.2 -5.8 0							
⊕ 0 7.9 7.9 7.9 7.8 7.9 ⊕ 3.7 3.7 3.5 3.5 3.5 3.6 ⊕ 0.2 0 0.1 <th< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td></th<>							
C111							
COLID O.3							
0							
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	0	5.0	5.0	5.0	5.0		5.0
CAUS (0) 2.9 2.9 0 2.9 1.29 0 2.9 1.29 0 2.9 1.29 0 2.9 1.29 0 0 0 1.27 1.2 0.8 0.8 0.8 0.9 0<							
Q 1.2 / 1.2 0.8 0.8 1.2 / 0.9 Q 1.4 / 1.3 0.9 0.9 1.3 / 0.0 Q 0.8 / 0.5 0.6 0.0 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6 <td>0</td> <td>2.9</td> <td>2.9</td> <td>2.9</td> <td>0</td> <td>2.9</td> <td>: 2.9</td>	0	2.9	2.9	2.9	0	2.9	: 2.9
□ 1.4 1.3 0.9 0.9 1.3 1.0 □ 0.8 0.8 0.9 0.9 1.8 1.4 □ 0.6							
\$\begin{array}{c c c c c c c c c c c c c c c c c c c		1.4				1.3	
0		0.0					
		0.0					
9		0.5		0.0	66 .	0.6	U
□ 0.6 0.6 0.6 0.6 0.6 0 0.6 □ 0.6 0.6 0.6 0.6 0 0.6 □ 0.6 0.7 0.8 0.8 0.8 0 □ 0.8 0.9 0.9 0.9 0.9 0.9 □ 0.5 0.5 0.5 0.5 0.5 0.5 0.5 □ 0.5 0.5 0.5 0.5 0.5 0.5 0.5 □ 0.7 0.7 0.7 0.7 0.7 □ 0.8 0.9 0.1 0.9 0.9 0.9 □ 0.8 0.9 0.1 0.9 0.9 0.9 □ 0.8 0.9 0.1 0.9 0.9 0.9 □ 0.8 0.9 0.9 0.9 0.9 0.9 □ 0.8 0.9 0.9 0.9 0.9 0.9 □ 0.8 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 □ 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9	(8)	1.0	0.6 1.0	1.0	10	0.8	1.1
	(B) (9)	1.0 "	0.6 1.0 1.5	1,0	! O	0.8	1.1 1.6
① 4.9 4.9 4.9 4.9 4.7 5.1 5.8 5.6	(e) (e) (f)	1.0 1.6 1.4 0.9	0.6 1.0 1.5 1.4	1.0 1.1 1.0 1.0	! 0 ! !! ! 0	0.8 1.4 1.2 0.8	1.1 1.6 1.5
⊕ 5.6 5.6 5.6 5.6 5.6 5.6 5.6 5.6 5.6 9.6 9.0 0.1 0 0 0 4.4 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.1 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.1 4.2 4.0 4.2 1.4 4.2 4.0 4.2 1.4 1.4 4.2 4.0 4.2 1.5 4.7 7.6 7.7 7.6 4.0 4.1 4.1 4.2 4.2 4.2 4.2 4.2 4.2 4.2	® 9 9	1.0 1.6 1.4 0.9	0.6 1.0 1.5 1.4 1.0 0.6	1.0 1.1 1.0 1.0 0.6	10 11 10 10	0.8 1.4 1.2 0.8	1.1 1.6 1.5 1.1
⑤ 0 0.1 0 0 0 ← 1.4 4.4 ⑥ 3.8 4.0 4.1 4.2 4.0 1.3 6.8 9.0 7.7 7.9 ⑥ 7.1 2 6.8 8.0 3.0 7.7 7.9 ⑥ 1.4 1.3 1.2 1.1 1.2 1.4 ⑥ 7.0 7.3 8.1 7.8 7.8 7.8 ⑥ 7.6 7.8 7.7 7.8 4.8 7.7 ⑥ 7.6 7.8 7.7 7.8 4.8 7.7 ⑥ 1.2 1.2 1.0 4.0 1.2 1.3 ⑥ 7.2 7.2 7.2 7.2 7.2 7.2 6.5 6.6 6.6 6.6 6.6 6.6 6.6 6.6 6.6 6.6 6.5 6.6 5.5 0 (2.05 0) 1.6 1.5 1.1 1.3 1.4 1.5	(8) (9) (9) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	1.0 " 1.6 " 1.4 " 0.9 " 0.6 " 3.0 " 4.9 "	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9	1.0 1.1 1.0 1.0 0.6 3.0 4.9	1 0 1 fi 1 0 1 0 0 6 3.0 4.9	0.8 1.4 1.2 0.8 0 4.5 4.7	1.1 1.6 1.5 1.1 0.6 0
№ 7.1 mole 6.6 8.0 30 7.7 7.9 № 1.4 mole 1.3 1.2 1.1 1.2 mole 1.4 7.8 7.8 7.8 7.8 7.8 7.8 7.8 7.8 7.8 7.7 7.8 mole 8.0 mole 7.2 mole 8.0 mole 7.2 mole 8.0 mole 7.2 mole	(9) (9) (0) (1) (1) (2404 (0) (0) (0)	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6	10 11 10 10 66 30 49	0.8 1.4 1.2 0.8 0 4.5 4.7	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8
66 1.4 : 1.13 1.2 1.1 1.2 : 1.4 69 7.0 : 7.3 8.1 78 78 : 78 78 66 1.4 : 1.3 1.2 1.4 : 1.2 : 1.5 68 7.8 : 78 78 7.7 78 = 80 · 7.7 7.7 68 6.9 : 7.1 7.8 : 7.7 78 = 80 · 7.7 7.6 : 7.6 7.6 60 1.2 : 1.2 1.0 : 0 1.2 : 1.3 1.3 1.7 7.6 : 7.6 7.6 60 1.2 : 1.2 : 1.0 : 0 0 1.2 : 1.3 1.3 7.2 : 7.2 7.2 : 6.9 : 7.7 7.6 : 7.6 7.6 : 7.6 7.6 : 7.6 : 7.6 7.6 : 7.6 : 7.6 : 7.6 : 7.6 : 7.6 : 7.2 7.2 : 6.9 : 7.7 : 7.2 : 2 : 6.9 : 7.7 : 7.2 :	(a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 5.6	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6	0 11 0 0 0 6 3.0 4.9 5.6 5.6	0.8 1.4 1.2 0.8 0 4.5 4.7 5.6 5.6	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.6
(株) 1.4 × 1.3	(9) (9) (1) (1) (1) (1) (4) (4) (4) (4) (6) (7) (8) (8) (8)	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 0 3.8	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 4.7 5.6 5.6	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4
68 7.8 7.8 7.7 7.8 80 7.7 68 6.9 7.1 7.8 7 7.6 7.6 7.7 69 1.2 1.2 1.0 40 1.2 1.3 6 7.2 7.2 7.2 7.2 6.9 7.7 69 6.6 6.6 6.6 6.6 6.5 1.1 1.3 1.4 1.5 60 1.6 1.5 1.1 1.3 1.4 1.5 60 1.4 1.4 0.9 0.0 1.2 1.5 9 1.2 1.2 0.9 0.0 1.1 1.2 1.5 9 1.2 1.2 0.9 0.0 1.1 1.2 1.4 9 1.2 1.2 0.9 0.0 1.2 1.4 9 0.5 0.5 0.6 1.0 0.3 0.2 1.1 1.3 1.0 0 1.2	(A) (A) (B) (B) (B) (B) (B) (B) (B) (B) (B) (B	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 0 3.8	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 0 4.1 8.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 4.7 5.6 0 4.0 7.7	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.6 7.9
\$\$ 6.9 7.1 7.8 7.7 7.6. 7.6 \$\$ 1.2 1.2 1.0 1.0 10 1.2 1.3 \$\$ 7.2 7.2 7.2 7.2 2.2 6.9 7.7 \$\$ 6.9 6.6 6.6 6.6 6.6 6.6 5.5 0.6 \$\$ 6.0 6.6 6.6 6.6 6.6 6.5 5.5 0.6 \$\$ 1.4 1.4 0.9 0 1.2 1.5 1.5 \$\$ 1.4 1.3 1.0 0 1.2 1.4 \$\$ 1.3 1.3 1.0 0 1.2 1.4 \$\$ 0.1 3 1.3 1.0 0 1.2 1.4 \$\$ 0.5 0.5 0.5 0.6 1.0 0.3 0.3 0.3 \$\$ 0.5 0.5 0.5 0.6 1.3 0.3 0.3 0.2 \$\$ 1.2 1.2 0.8 11 1.2 1.3 \$\$ 1.4 1.3 1.0 0 3.1 1.2 1.4 \$\$ 0.5 0.5 0.5 0.6 1.3 0.3 0.3 0.2 \$\$ 1.2 1.2 0.8 11 1.2 1.3 \$\$ 1.4 1.3 1.0 0 0.3 0.5 \$\$ 0.5 0.5 0.5 0.6 1.3 0.3 0.3 0.2 \$\$ 1.2 1.2 0.8 11 1.2 1.3 \$\$ 0.1 1.4 1.3 1.0 1.3 1.3 1.4 \$\$ 0.1 2 1.2 0.8 12 1.2 1.3 \$\$ 0.1 4.0 1.3 1.0 1.3 1.3 1.4 \$\$ 0.1 2 1.2 0.8 12 1.2 1.3 \$\$ 0.1 4.0 1.3 1.0 1.3 1.3 1.4 \$\$ 0.1 2 1.2 0.8 12 1.2 1.3 \$\$ 0.1 4.0 1.3 1.0 1.3 1.3 1.4 \$\$ 0.1 2 1.2 0.8 12 1.2 1.3 \$\$ 0.1 4.0 1.3 1.0 1.3 1.2 1.5 \$\$ 0.1 4.8 5.1 4.8 8 4.5 5.1 \$\$ 0.0 0.9 9 0.8 1.1 \$\$ 0.0 0.9 1.0 0.0 0.8 1.1 \$\$ 0.0 0.0 0.0 0.0 0.8 1.1 \$\$ 0.0 0.0 0.0 0.0 0.0 0.8 1.1 \$\$ 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 \$\$ 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 \$\$ 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 \$\$ 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0	(A) (A) (A) (B) (B) (B) (B) (B) (B) (B) (B) (B) (B	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 5.6 0 3.8 7.1 1.4 7.0	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2	10 11 0 0 0 0 6 30 49 56 56 0 42 30 42 30	0.8 1.4 1.2 0.8 0 4.5 4.7 5.6 5.6 0 4.0 7.7 1.2	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.5 7.9 1.4
68 7.2 7.2 7.2 7.2 8.3 7.2 69 7.2 7.2 7.2 1.2 6.9 7.2 49 6.6 6.6 6.6 6.6 5.5 0 IC405 ① 1.6 1.5 1.1 1.3 1.4 1.5 ⊕ 1.4 1.4 0.9 0.0 1.2 1.5 ⊕ 1.4 1.4 0.9 0.0 1.1 1.2 ⊕ 1.4 1.3 1.0 0 1.2 1.4 ⊕ 1.3 1.3 1.0 0 1.2 1.4 ⊕ 0.5 0.5 0.6 1.0 0.3 0.2 ⊕ 0.5 0.5 0.6 1.0 0.3 0.2 ⊕ 0.5 0.5 0.5 1.3 0.3 0.2 ⊕ 1.2 1.2 1.3 1.2 1.3 ⊕ 1.2 1.2 0.8	(a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 0 3.8 7.1 1.4	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.1 1.3 7.3	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 7.7	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 0 4.5 4.7 1.1 5.6 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.5 0.6 0 6.1 5.8 4.4 3.6 7.9 1.4 7.8 1.5
№ 7.2 × 7.2 7.2 7.2 6.9 7.0 49 6.6 66 66 65 65 55 0 (C405 ○) 1.6 1.5 1.1 1.3 1.4 × 1.5 1.5 1.1 1.3 1.4 × 1.5 1.5 1.1 1.3 1.4 × 1.5 1.5 1.1 1.2 1.5 1.5 1.1 1.3 1.4 × 1.2 1.5 0.0 1.2 1.5 0.0 1.2 1.5 0.0 1.2 1.4 1.2 1.5 0.0 0.0 1.1 1.2 1.4 0.0 1.2 1.4 0.0 1.2 1.4 0.0 0.0 1.2 1.4 0.0 0.0 0.3 0.2 1.4 0.0 0.3 0.2 0.2 1.4 1.4 1.3 1.0 0.0 0.3 0.2 0.2 1.1 1.2 1.3 1.4 1.3 1.0 0.3 1.2 1.3 1.4 1.3 1.0 1.3 1.2 <td>@ 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9</td> <td>1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 0 3.8 7.1 1.4 7.0 1.4 7.8 6.9</td> <td>0.6 1.0 1.5 1 4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.3</td> <td>1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 7.7</td> <td>10 11 10 10 66 3.0 4.9 56 56 0 4.2 3.0 4.2 3.0 1.1 7.8</td> <td>0.8 1.4 1.2 0.8 0 4.5 4.7 5.6 5.6 4.0 7.7 1.2 8.0 7.6</td> <td>1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.5 7.9 1.4 7.8 1.5 7.7</td>	@ 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 0 3.8 7.1 1.4 7.0 1.4 7.8 6.9	0.6 1.0 1.5 1 4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.3	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 7.7	10 11 10 10 66 3.0 4.9 56 56 0 4.2 3.0 4.2 3.0 1.1 7.8	0.8 1.4 1.2 0.8 0 4.5 4.7 5.6 5.6 4.0 7.7 1.2 8.0 7.6	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.5 7.9 1.4 7.8 1.5 7.7
	(a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	1.0 16 1.4 0.9 0.6 3.0 4.9 5.6 0 3.6 7.1 - 1.4 7.0 1.4 6.9 1.2	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.1 3.7 3.7 1.3 7.3 1.3 7.8 7.1	1.0 1.1 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 7.7 7.8	10 11 10 66 30 49 56 56 0 42 30 1,1 78 11 17 18	0.8 1.4 1.2 0.8 0 4.5 4.7 5.6 0 4.0 7.7 1.2 7.8 1.2 80	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.5 1.4 7.8 1.5 7.7 7.6 1.3
⊕ 1,4 1,4 0.9 0.0 1,2 1.5 ⊕ 1,2 1,2 1,2 0.9 0.0 1,12 1,5 ⊕ 1,4 1,3 1,0 0.7 1,2 1,4 ⊕ 1,3 1,3 1,0 0 1,2 1,4 ⊕ 0,5 0,5 0,6 1,0 0,3 0,2 ⊕ 0,5 0,5 0,6 1,0 0,3 0,2 ⊕ 0,5 0,5 0,6 1,0 0,3 0,2 ⊕ 0,5 0,5 0,6 1,0 0,3 0,2 ⊕ 1,2 1,2 1,2 1,4 1,2 1,3 ⊕ 1,2 1,2 1,2 1,2 1,2 1,3 ⊕ 1,2 1,2 1,3 1,0 1,3 1,2 1,3 ⊕ 1,2 1,2 0,8 2 1,2 1,2 1,2 1,2	@ 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	1.0 1.6 1.4 1.4 1.4 1.4 1.4 1.4 1.4 1.4 1.4 1.4	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.8 7.1 1.3 7.8 7.1	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 7.7 7.8 1.0 7.2 7.2	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 0.8 0 4.5 5.6 5.6 0 7.7 1.2 80 7.6 1.2	1.1 1.6 1.5 1.1 0.6 0 0 1.1 5.8 5.8 4.4 3.5 7.9 1.4 7.6 1.5 7.7 7.6
(a) 1.4 1.3 1.0 0 1.2 1.4 (b) 1.3 1.3 1.0 0 1.2 1.4 (c) 1.3 1.3 1.0 0 1.2 1.4 (c) 0.5 0.5 0.5 0.6 1.0 0.3 0.3 0.2 (c) 0.5 0.5 0.5 0.5 1.3 0.3 0.2 0.2 (c) 1.2 1.2 1.2 1.3 0.3 1.3 1.3 1.4 1.2 1.3 0.9 1.3 1.3 1.4 1.2 1.3 0.9 1.2 1.2 1.2 0.8 1.1 1.2 1.3 0.9 1.2 1.2 1.2 0.8 1.2 1.2 1.3 0.9 1.4 1.3 1.0 1.3 1.4 1.5 1.3 0.9 1.4 1.3 1.0 1.3 1.4 1.5 1.5 1.4 1.5 1.5 1.4 1.5 1.5 1.4 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5	@ 9 9 9 9 9 9 9 9 8 8 8 8 8 8 8 8 8 8 8	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 0.3 1.4 7.0 1.4 7.8 6.9 1.2 7.2 6.6	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.1.3 7.3 7.1 1.2 7.2 7.2 6.6	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 7.7 7.8 1.0 7.2 6.6	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 5.6 5.6 0 4.0 7.7 1.2 7.8 1.2 8.0 7.6 1.2 8.0 7.6 1.2	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.5 7.9 1.4 7.8 1.5 7.7 7.6 1.3 7.2 7.2
\$\begin{array}{c c c c c c c c c c c c c c c c c c c	@ 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	1.0 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.5 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.5 ° 1.5 ° 1.6 ° 1.6 ° 1.6 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.6 ° 1.6 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.6 ° 1.6 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.5 ° 1.6 ° 1.6 ° 1.4 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 11 11 11 11 1	0.8 1.4 1.2 0.8 0 4.5 5.6 5.6 0 7.7 1.2 8.0 7.6 1.2 8.3 6.9 5.5 1.4	1.1 1.6 1.5 1.1 0.6 0 61 5.8 5.6 4.4 3.5 7.9 1.4 7.7 7.6 1.3 7.7 7.7 6 1.3 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2
⊕ 0.5 0.5 0.6 1.3 0.3- 0.2 ⊕ 1.2 1.2 0.8 1 1.2 1.3 1.4 ⊕ 1.4 1.3 0.9 1.3 1.3. 1.4 ⊕ 1.2 1.2 0.8 1.2 1.2 1.3 ⊕ 1.4 1.3 1.0 1.3 1.2 1.5 ⊕ 1.4 1.3 1.0 1.3 1.2 1.5 ⊕ 0.4 8 5.1 4.6 4.8 4.5 5.1 ⊕ 0.0 0.9 1.0 0.0 0.8 1.1 ⊕ 0.1 0.0 1.1 1.1 0.8 4.5 5.1 ⊕ 1.0 1.0 1.1 1.1 0.8 5.5 5.1 ⊕ 1.0 1.0 1.1 1.1 0.8 5.5 5.1 ⊕ 1.0 1.2 1.2 0.9 1.2	(A)	1.0 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.2 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.4 ° 1.2 ° 1.4 ° 1.4 ° 1.2 ° 1.4 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.4 ° 1.2 ° 1.2 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2	1.0 1.1 1.0 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 7.7 7.8 1.0 7.2 7.2 6.6 1.1 1.0 6.6 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0.8 0.7 5.6 5.6 0 7.7 1.2 80 7.6 1.2 80 7.5 1.4 1.2 1.1 1.2 1.1 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.1 1.6 1.5 1.1 0.6 0 0 1.1 5.8 5.8 4.4 3.5 7.9 1.4 7.6 1.5 7.7 7.6 1.3 7.7 7.6 1.3 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2
⊕ 1.2 1.2 0.8 11 1.2 1.3 ⊕ 1.4 1.3 0.9 1.3 1.3 1.4 ⊕ 1.2 1.2 0.8 1.2 1.2 1.3 ⊕ 1.2 1.2 0.8 1.2 1.2 1.3 ⊕ 1.2 1.2 0.8 1.2 1.2 1.3 ⊕ 1.4 1.3 1.0 1.3 1.2 1.5 ⊕ 0.8 0.9 9 0.6 1.2 ⊕ 1.0 0.9 1.0 0.0 0.8 1.1 ⊕ 1.0 0.9 1.0 0.0 0.8 1.1 ⊕ 1.0 0.9 1.0 0.0 0.8 1.1 ⊕ 1.0 0.9 1.0 0.0 0.8 1.1 ⊕ 1.0 1.0 1.1 1.1 0.0 0.8 1.1 ⊕ 1.1 2.1	(2405 (a)	1.0 ° 1.6 ° 1.4 ° 1.3 ° 1.6 ° 1.4 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7	1.0 1.1 1.0 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 1.2 8.1 1.2 8.1 1.2 7.7 7.8 1.0 7.2 7.2 7.2 6.5 1.1 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9	10 11 10 10 10 10 10 10 10 11 11 11 11 1	0.8 1.4 1.2 0.8 0 4.5 5.6 0 1.2 1.2 8.0 1.2 8.3 1.2 8.3 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.5 7.9 1.4 7.8 1.3 7.7 7.6 1.3 7.2 0 0 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1
№ 1.2 1.2 0.8 1.2 1.3 № 1.4 1.3 1.0 1.3 1.2 1.3 № 1.4 1.3 1.0 1.3 1.2 1.5 № 0.0 0.8 0.9 9 0.6 1.0 № 1.0 0.9 1.0 0.0 0.8 1.1 № 1.0 1.0 1.1 1.1 0.8 1.1 № 1.0 1.0 1.1 1.1 0.8 1.1 № 1.1 1.1 0.9 4.9 4.9 5.1 № 1.1 1.1 0.9 4.9 4.9 5.1 № 0.4 -0.1 0.5 0.3 0.4 0.5 № 0.4 -0.1 0.5 0.3 0.4 0.5 № 2.0 1.8 2.0 2.0 2.0 2.0 № 1.1.7 10.7 11.6	(A)	1.0 1.6 1.4 1.4 1.4 1.5 1.4 1.4 1.5 1.4 1.4 1.5 1.6 1.6 1.6 1.6 1.6 1.6 1.6 1.6 1.6 1.6	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 5.6 5.6 5.6 7.7 1.2 8.0 7.6 1.2 1.3 6.9 5.5 1.4 1.2 1.1 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 0 1.5 5.8 5.8 4.4 7.8 1.5 7.7 7.6 1.5 7.7 7.6 1.5 7.7 7.6 1.5 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2
⑤ 1.4 1.3 1.0 1.3 1.2 1.5 (C406 ① 48 5.1 46 1.8 45 5.1 ⑤ 0.8 0 0.9 9 9.6 1.0 ⑥ 1.0 0.9 1.0 0.0 0.8 1.1 ⑥ 1.0 1.0 1.1 1.1 0.8 1.1 ② 1.1 0.1 0.1 1.1 0.1 0.8 1.1 ② 1.1 0.1 0.1 0.0 0.8 1.1 ② 1.1 0.1 0.0 0.8 1.1 ② 0.1 1.2 1.9 4.9 4.9 5.1 1.4 1.2 0.9 2 1.2 1.3 (C407 ① 1.2 1.2 0.9 2 1.2 1.3 (C407 ① 1.2 1.2 0.9 2 1.2 1.3 (D40 ② 0.6 0 0.7<	@ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @	1.0 1.6 1.4 0.9 0.6 3.0 4.9 5.6 0 3.8 7.1 2 1.4 7.0 1.4 7.0 1.4 7.8 6.9 1.2 7.2 6.6 1.6 1.4 1.3 0.5 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.2 1.2 1.4 1.3 0.5 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 7.2 7.2 7.2 1.4 1.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7.2 7	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 11 11 11 11 1	0.8 1.4 1.2 0.8 0 4.5 5.6 0 4.5 5.6 0 7.7 1.2 7.8 1.2 8.0 7.6 1.2 1.1 1.2 1.1 1.2 1.2 1.1 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.6 7.9 1.4 7.8 1.5 7.7 7.6 1.3 7.2 7.7 7.0 0 1.5 1.1 1.1 0.6 0.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1
(a) 0.8	@ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @	1.0 ° 1.6 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.3 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.5 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 0.5 1.3 1.3 0.5 0.5	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 4.7 1.1 2 1.2 1.2 1.2 1.2 1.2 1.3 0.3 0.3 0.3 1.2 1.3 1.3 1.2 1.3 1.3 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.1 1.6 1.5 1.1 0.6 0 0 1.1 5.8 5.8 5.8 4.4 3.5 7.9 1.4 7.7 7.6 1.3 7.7 7.7 9 1.5 1.1 9 1.5 1.1 9 1.5 1.1 9 1.5 1.1 9 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5
(a) 0.8	(A)	1.0 ° 1.6 ° 1.4 ° 1.6 ° 1.4 ° 1.5 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0.8 0.8 0.8 0.6 5.6 0.7 1.2 7.8 1.2 80 7.6 1.2 6.3 6.9 5.5 1.4 1.2 1.2 1.2 1.2 1.2 1.3 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.6 7.9 1.4 7.8 1.5 7.7 7.6 1.3 7.7 7.6 1.3 1.2 1.4 1.4 1.5 1.1 1.5 1.1 1.5 1.1 1.5 1.1 1.5 1.5
⊕ 5.1 5.1 4.9 4.9 4.9 5.5 (C407 ⊕ 1.2 1.2 0.9 1.2 1.2 1.3 ⊕ 0.4 -0.1 0.5 0.3 0.4 0.5 ⊕ 1.4 1.3 1.0 3 1.2 1.4 ⊕ 0.6 0 0.7 0.5 0.5 0.7 ⊕ 2.0 1.8 2.0 2.0 2.0 2.0 ⊕ 11.7 10.7 11.6 1.3 11.7 11.2 ⊕ 5.5 5.5 5.5 1.5 5.4 9.5 ⊕ 5.5 5.5 5.5 5.5 5.4 9.5 ⊕ 1.4	(4) (5) (5) (6) (6) (6) (6) (7) (7) (7) (7) (7) (7) (7) (7) (7) (7	1.0 ° 1.6 ° 1.4 ° 1.5 ° 1.4 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.4 ° 1.3 ° 0.5 ° 1.2 ° 1.4 ° 1.4 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 7.2 7.2 7.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.1 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 7.7 7.8 1.0 7.2 6.5 1.1 0.9 1.0 1.0 0.6 0.8 0.9 0.8 0.8 0.9 0.8 0.8 0.9 0.8 0.8 0.9 0.8 0.8 0.9 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0.8	10 11 10 10 10 10 10 10 11 11 11 11 11 1	0.8 1.4 1.2 0.8 0 4.5 5.6 0 1.7 1.2 1.2 1.2 1.1 1.2 1.2 0.3 1.2 1.3 1.2 1.2 1.3 1.2 1.3 1.3 1.3 1.3 1.4 4.5	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 7.8 1.4 7.7 7.6 1.3 7.7 7.6 1.3 7.2 1.4 1.5 1.5 1.1 1.4 1.5 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1
C407 (0) 1.2 1.2 0.9 2 1.2 1.3	(4 \cdot \cd	1.0 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.5 ° 1.5 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.5 ° 1.2 ° 1.4 ° 1.5 ° 1.2 ° 1.4 ° 1.5 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0.8 0.8 0.8 0.8 0.7 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.3 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.1 1.6 1.5 1.1 0.6 0 0 1.1 5.8 5.8 4.4 3.5 7.9 1.4 7.6 1.5 7.7 7.6 1.3 7.7 7.6 1.3 1.2 1.4 1.4 1.4 1.5 1.1 1.5 1.1 1.5 1.1 1.1 1.5 1.1 1.5 1.5
⊕ 0.4 -0.1 0.5 0.3 0.4 0.5 ⊕ 1.4 1.3 10 3 1.2 14 ⊕ 0.6 0 0.7 1.5 0.5 0.7 ⊕ 2.0 18 2.0 2.0 2.0 2.0 ⊕ 11.7 10.7 11.6 1.3 11.7 11.2 ⊕ 5.5 5.5 5.5 5.5 5.5 5.4 9.5 ⊕ 1.4 1.4 1.0 3 1.2 1.5 ⊕ 1.4 1.4 1.0 3 1.2 1.5 ⊕ 1.4 1.4 1.0 3 1.2 1.5 ⊕ 1.4 1.4 1.0 3 1.2 1.5 ⊕ 0.6 -0.1 0.7 6 0.5 0.7 ⊕ 0.6 -0.1 0.7 2.0 0 2.0 2.0 ⊕ 2.0<	(2405) (2406) (2	1.0 ° 1.6 ° 1.4 ° 1.0 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 6.6 1.1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 1.3 0.5 1.4 1.2 1.3 1.3 0.5 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.1 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 8.1 1.2 7.7 7.8 1.0 7.2 6.6 1.1 0.9 1.0 0.6 0.5 0.8 0.9 1.0 0.6 0.8 0.9 1.0 0.6 0.8 0.9 0.8 0.9 0.8 0.9 0.9 0.1 0.1 0.0 0.1 0.0 0.0 0.0 0.0 0.0 0.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 6.6 0 4.5 5.6 0 4.0 7.7 1.2 7.8 1.2 8.0 7.6 1.2 8.1 1.2 1.2 1.3 1.2 1.3 1.2 4.5 0.6 0.8	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.8 4.4 3.5 7.9 1.4 7.8 1.5 7.7 7.6 1.3 7.7 7.6 1.3 1.4 1.4 1.5 1.1 1.1 1.5 1.1 1.1 1.1 1.1 1.1 1.1
60 0.6 0 0.7 1.5 0.5 0.7 ⊕ 2.0 1.8 2.0 0.0 2.0 2.0 2.0 ⊕ 11.7 10.7 11.6 1.3 11.7 11.2 ⊕ 5.5 5.5 5.5 5.5 5.5 5.4 9.5 ⊕ 5.5 5.5 5.5 5.5 5.4 9.5 ⊕ 0.5 5.5 5.5 5.5 5.4 9.2 ⊕ 0.6 -0.1 0.1 6 0.5 0.2 1.5 ⊕ 0.6 -0.1 0.1 6 0.5 0.2 0.2 ⊕ 2.0 1.7 2.0 0 2.0 1.0 ⊕ 2.0 1.7 2.0 0 2.0 1.0 ⊕ 2.0 1.7 2.0 0 2.0 1.0 ⊕ 2.0 1.7 2.0 0 2.0 1.0 <td>(24 05 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0</td> <td>1.0 ° 1.6 ° 1.4 ° 1.0 ° 1.4 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.4 ° 1.3 ° 1.5 ° 1.2 ° 1.4 ° 1.3 ° 1.5 ° 1.2 ° 1.4 ° 1.3 ° 1.5 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.5 °</td> <td>0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 0.5 1.3 1.3 0.5 1.1 1.2 1.3 0.5 0.1 1.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0</td> <td>1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0</td> <td>10 11 10 10 10 10 10 10 10 11 10 10 10 1</td> <td>0.8 1.4 1.2 0.8 0 4.5 6.6 5.6 0 7.7 1.2 80 7.6 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2</td> <td>1.1 1.6 1.5 1.1 0.6 0 0 1.5 1.5 1.5 1.5 7.7 7.6 1.3 7.7 7.6 1.5 7.7 7.6 1.5 1.5 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1</td>	(24 05 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1.0 ° 1.6 ° 1.4 ° 1.0 ° 1.4 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.4 ° 1.3 ° 1.5 ° 1.2 ° 1.4 ° 1.3 ° 1.5 ° 1.2 ° 1.4 ° 1.3 ° 1.5 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.5 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 0.5 1.3 1.3 0.5 1.1 1.2 1.3 0.5 0.1 1.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 11 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 6.6 5.6 0 7.7 1.2 80 7.6 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 0 1.5 1.5 1.5 1.5 7.7 7.6 1.3 7.7 7.6 1.5 7.7 7.6 1.5 1.5 1.1 1.1 1.1 1.1 1.1 1.1 1.1 1.1
(a) 2.0 1.8 2.0 2.0 2.0 2.0 2.0 3.	(40 to 10 to	1.0 ° 1.6 ° 1.4 ° 1.6 ° 1.4 ° 1.5 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.5 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0.7 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 6.1 5.8 5.6 4.4 7.8 7.7 7.6 1.3 7.7 7.6 1.3 7.7 7.7 7.6 1.3 1.2 1.4 1.4 1.5 1.2 1.4 1.5 1.1 1.5 1.1 1.5 1.1 1.5 1.5 1.5 1.5
18	ම ම ම ම ම ම ම ම ම ම ම ම ම ම ම ම ම ම ම	1.0 ° 1.6 ° 1.4 ° 1.0 ° 1.4 ° 1.5 ° 1.2 ° 1.2 ° 1.2 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.2 ° 1.4 ° 1.3 ° 1.5 ° 1.2 ° 1.4 ° 1.5 ° 1.5 ° 1.2 ° 1.4 ° 1.5 ° 1.5 ° 1.2 ° 1.4 ° 1.5 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 7.2 1.3 1.3 0.5 1.3 1.3 0.5 1.3 1.3 0.5 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.1 1.0 0.6 3.0 4.9 5.6 5.6 0 4.1 8.0 1.2 8.1 1.2 7.7 7.8 1.0 7.2 6.6 1.1 0.9 1.0 0.6 0.8 0.9 1.0 0.6 0.8 0.9 1.0 0.6 0.8 0.9 0.8 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 6.6 0 4.5 5.6 0 4.0 7.7 1.2 7.8 1.2 1.2 1.2 1.3 1.2 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.3 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.1 1.6 1.5 1.1 1.6 1.5 1.1 1.5 1.5 1.2 1.3 1.4 1.3 1.5 1.1 1.5 1.1 1.5 1.5 1.1 1.5 1.5 1.1 1.1
	(4) (4) (5) (5) (6) (6) (6) (6) (7) (7) (7) (7) (7) (7) (7) (7) (7) (7	1.0 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.5 ° 1.2 ° 1.4 °	0.6 1.0 1.5 1.4 1.0 0.6 1.0 1.5 1.4 1.0 0.6 1.3 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 0.5 0.5 1.3 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6 0.6	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 6.6 5.6 0 7.7 1.2 80 7.6 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 0 1.1 1.5 1.6 1.5 1.6 1.6 1.6 1.6 1.7 1.7 1.6 1.7 1.7 1.7 1.7 1.7 1.7 1.7 1.7 1.7 1.7
\$\frac{4}{3} \	(4) (4) (4) (4) (4) (4) (4) (4) (4) (4)	1.0 ° 1.6 ° 1.4 ° 1.6 ° 1.4 ° 1.7 ° 1.4 ° 1.7 ° 1.4 ° 1.2 ° 1.4 ° 1.4 ° 1.4 ° 1.5 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 1.0 0.8 0.8 0.8 0.8 0.8 0.7 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 0 6.1 5.8 5.8 4.4 7.8 7.7 7.6 1.3 7.7 7.6 1.3 7.7 7.7 7.6 1.3 1.2 1.4 1.4 1.5 1.1 1.5 1.1 1.5 1.1 1.5 1.1 1.5 1.5
CO 20 17 2.6 0 20 2.6	(2405 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1.0 ° 1.0 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 7.2 7.2 7.2 1.3 1.3 0.5 0.5 1.4 1.3 0.5 0.5 1.3 1.3 0.5 0.5 0.5 1.3 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8 1.4 1.2 0.8 0 4.5 6.6 0 4.5 5.6 0 4.0 7.7 1.2 8.0 7.6 1.2 8.0 1.1 1.2 1.2 1.2 1.3 1.2 1.2 1.3 1.2 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.3 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.1 1.6 1.5 1.1 1.6 1.5 1.1 1.5 1.5 1.2 1.3 1.4 1.3 1.5 1.1 1.5 1.5 1.1 1.5 1.5 1.1 1.5 1.5
0408 (0) 31 25 29 1 37 54 64 67 41 28 35 1 45 41 67 67 67 67 67 67 67 6	(404 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1.0 ° 1.6 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.4 ° 1.5 ° 1.2 ° 1.4 °	0.6 1.0 1.5 1.4 1.0 0.6 1.0 1.5 1.4 1.0 0.6 1.3 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.3 1.3 0.5 0.5 1.4 1.2 1.3 0.5 0.5 1.3 0.5 0.5 1.3 0.5 0.5 1.3 0.5 0.5 1.3 0.5 0.5 1.3 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 11 11 11 1	0.8 1.4 1.2 1.0 0.8 0.8 0.8 0.8 0.8 0.7 1.7 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2 1.2	1.1 1.6 1.5 1.1 0.6 0 0 1.1 1.5 1.1 1.5 1.7 1.6 1.5 1.7 1.6 1.5 1.7 1.7 1.6 1.5 1.7 1.7 1.6 1.7 1.7 1.7 1.7 1.7 1.7 1.7 1.7
0408 (0) 31 25 29 1 37 54 64 64 64 64 64 64 64	(4) (4) (4) (4) (4) (4) (4) (4) (4) (4)	1.0 ° 1.6 ° 1.4 ° 1.6 ° 1.4 ° 1.5 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 ° 1.5 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10	0.8 1.4 1.2 1.0 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0	1.1 1.6 1.5 1.1 1.6 1.5 1.1 1.6 1.5 1.1 1.5 1.5 1.1 1.5 1.5 1.1 1.5 1.5
04.00 fb 0 6.8 9.0 14 0 0.5 09 0 0.5 0.4 13 0.3 10 0 5.9 5.9 5.0 1 5.9 5.9 1 5.9 5.9 6.3 10 5.9 5.9 1 5.9 5.9 6.3 10 5.9 5.9 10 0.1 1.8 0.5 2 0.1 0.1	(240 de constitution of the constitution of th	1.0 ° 1.6 ° 1.4 ° 1.6 ° 1.4 ° 1.5 ° 1.2 ° 1.4 ° 1.2 ° 1.3 °	0.6 1.0 1.5 1.4 1.0 0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 0.5 1.5 1.4 1.2 1.3 0.5 1.2 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 10 10 10 1	0.8	1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.1
69 0 26 C4 3 03 12 51 59 59 50 1 52 50 61 59 59 63 6 59 89 5 59 53 60 59 89 40 59 53 6 59 89 40 0.1 18 0.5 2 0.1 0.1	C	1.0 ° 1.0 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.8 7.1 1.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 0.5 0.5 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10	0.8	1.1 1.6 1.5 1.1 1.6 0.6 0 0 1.1 1.5 1.6 1.6 1.6 1.7 1.6 1.6 1.6 1.6 1.6 1.6 1.7 1.7 1.7 1.7 1.7 1.7 1.7 1.7
59 59 63 6 59 89 5 59 59 63 6 59 89 5 59 59 53 6 59 59 10 0.1 18 05 2 01 0	(4) (4) (4) (4) (4) (4) (4) (4) (4) (4)	1.0 ° 1.6 ° 1.4 ° 1.6 ° 1.4 ° 1.5 ° 1.6 ° 1.4 ° 1.2 ° 1.4 ° 1.4 ° 1.2 ° 1.4 ° 1.2 ° 1.4 °	0.6 1.0 1.5 1.4 1.0 0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 1.3 0.5 1.2 1.3 0.5 1.2 1.3 0.5 1.2 1.3 0.5 1.2 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.2 1.3 1.3 0.5 1.4 1.7 1.7 1.7 2.9 1.8 8.8	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10	0.8 1.4 1.2 0.8 0 4.5 5.6 1.6 5.6 1.7 7.7 1.2 1.2 1.2 1.2 1.3 1.2 1.2 1.3 1.2 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.3 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.1 1.6 1.5 1.1 1.6 0.6 0 0 1 5.8 5.8 5.8 4.4 1.5 7.7 7.6 0 1.3 7.7 7.6 1.3 7.7 7.6 1.3 7.2 1.4 1.3 1.5 1.2 1.4 1.3 1.5 1.3 1.5 1.3 1.5 1.3 1.5 1.3 1.5 1.3 1.5 1.3 1.5 1.3 1.5 1.3 1.5 1.3 1.3 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5
15.9 33 35 0 31 3 15 0.1 18 25 2 0.1 V	(4) (4) (4) (4) (4) (4) (4) (4) (4) (4)	1.0 ° 1.0 °	0.6 1.0 1.5 1.4 1.0 0.6 1.0 1.5 1.4 1.0 0.6 1.3 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.3 1.3 0.5 1.5 1.4 1.2 1.3 1.3 0.5 0.5 0.5 1.3 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 11 11 11 1	0.8 1,4 1,4 1,5	1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.1
	C	1.0 ° 1.0 °	0.6 1.0 1.5 1.4 1.0 0.6 3.0 4.9 5.6 5.6 0.1 4.0 6.6 1.3 7.3 1.3 7.8 7.1 1.2 7.2 7.2 7.2 6.6 1.5 1.4 1.2 7.2 7.2 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 1.3 0.5 0.5 1.4 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10	0.8 1.4 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3	1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.6 1.1 1.1
The state of the s	(404 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1.0 ° 1.0 °	0.6 1.0 1.5 1.4 1.0 0.6 1.0 1.5 1.4 1.0 0.6 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	1.0 1.1 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0	10 11 10 10 10 10 10 10 10 10 11 11 11 1	0.8 1.4 1.2 0.8 0 4.5 5.6 1.6 5.6 1.7 7.7 1.2 1.2 1.2 1.2 1.2 1.3 1.2 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.2 1.3 1.3 1.2 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3 1.3	1.1 1.6 1.5 1.1 1.6 1.5 1.1 1.6 1.5 1.1 1.5 1.

	PAL	SECAM	NTSC	NTSC	S-VIDEO	ANALOG
	1	<u> </u>	3.58	4.43		RGB
IC:10 ①	3.5	1 40	4.0	40	0	3.9
(*)	3.0	3.1	2.4	3.1	0	40
9	13	0.7	1.4	1.6	2.3	1.5
(4)	3.5	3.6	3.0	3.8	3.9	3.9
	0.5	: 1.3	1.1	1.1	3.1	1.7
ું	40	40	4.0	3.9	0	0
(﴿	0	2.0	1.9	1.8	2.5	1.4
13	2.0		2.3	2.0	18	3.0
	4:		3.9	3.8	42	4.1
1C411 ①						
O	1 :6		1.9	1.8	2.5	1.3
(1)	1 2.0		2.2	2.1	1.8	3.0
C412 5	0.∻	. 0.5	: 0.4	1 0.4	! 5.9	0.5
اچَ.	8.9	8.9	8.9	3.9	8.9	9.3
3)	9.0	1 89	9.0	8.9	8.9	€.3
12	5.C	6.0	6.0	6.0	5.0	0
	1 64		0.4	0.4	5.9 *1	0.5
	7.9		1 8.0		2.1	6.9
						0.5
	1 0	5.5	5.5	5.5		
5)	5.5		5.5	5.5	5.4	9.5
	3.1	3.1	3.1	3.1	! 0	5.1
3	3 1	31	3.1	3.1	60	5.1
	79		8.0	7.9	6.3	6.9
	109		10.9	10.9	10.7	10.9
C132 5	3:		8.1		0	8.1
	1 11.5	11.5		11.5	11.3	11.5
	-02	! 0		0	0	- 0.2
Q107 B	5.0	5.0	5.0	5.0	5.0	0.1
C	1 0	0	0	0	0	5.0
	2.5	2.5			29	2.5
2.30 0	25	2.5	2.5		2.9	2.5
Q1:1 B		5.0				4.9
<u>C1:: 5</u>			0			
<u> </u>	0.4	1 04	0		0.4	0.4
0113 C		1 4.3	4.2		3.8	4.0
0401 3	 	0.8	1.5	1.6	1.2	1.0
C	7.5	5.5	5.0	5.2	8.4	10.0
Ę	1.4	1 1.5	3.2	3.4	3.1	. 1.0
Q402 B	0.5	0.5	0.5	0.5	2.4	0.5
. C	9.5	7.7	8.1	7.4	10.4	6.9
		1.6	3.2	3.3	3.2	1.0
	5.3	4.1		5.2	5.3	· 5.2
G404 B		<u> </u>	4.9			
Ε		6.3	6.0	6.1	6.1	5.2
Q405 B	1.3	1.3	1.2	1.1	1.2	1.4
Q406 B	0.7	0.7	0	0.7	0.7	0.7
С	1.5	1.5	1.0	1.5	1.4	. 1.6
Q407 B	0	0	0	0	0	0.6
C	6.6	6.6	6.6	6.6	5.4	0
Q408 B	5.3	4.7	4.9	5.0	5.2	5.2
E			5.9		6.0	
	6.0	6.2		6.1		6.1
Q409 B	1.9	1.6	1.6	1.6	1.7	1,6
E	2.0	2.2	2.2	2.2	23	. 2.2
Q411 C	1.4	1.4	0.9	1.3	1.3	1.4
Q412 B	1.3	1.3	1.0	1.3	1.1	-1.4
E	2.0	1.9	1,7	1.9	1.8	2.0
0413 G	2.0	- 15.1	1.6	- 2.2	1.8	-21
5	2.0	1.9	- 4.3	0	22	2.0
		1.9	1.7	1.9		20
S	2.0				1.8	
Q417 B	1.4	1.4	1.2	1.2	1.2	1.4
Q418 C	2.1	2.1	1.7	1.7	1.7	. 2.0
Q419 B	1.4	1.4	1.2	1.1	1.2	1.5
5	2.0	1.9	1.7	1.7	1.8	2.0
C420 B	1.2	1.2	1.0	1.0	1.2	. 1.3
====	1.8	1.8	1.6	1.6	1.8	1.9
0422 0	2.1	2.1	1.7	1.7	1.8	2.0
0423 8	0.5	0.3	0.4	0.4	0.4	0.2
C425 C	4.5	4.5	4.5	4.5	4.7	4.5
		0.8	0.7	0.7	0.7	0
C-25 C	0.6					
	0.1	0.8	0.4	0.4	0.1	0.1
			- 1.2	0.4 - 1.2	0.1	0.4
Q429 B E	0.1	0.8				
Q429 B E	0.1	0.8 - 2.3 - 3.8	- 1.2	- 1.2	0.4	0.4
0429 B E 0432 B C	0.1 0 - 0.3 11.9	0.8 - 2.3 - 3.8 11.6	- 1.2 - 3.4 11.8	- 1.2 - 2.7 11.8	0.4 - 0.1 12.0	0.4 - 3.9
Q429 B E Q432 B C Q433 B	0.1 0 - 0.3 11.9 0	0.8 - 2.3 - 3.8 11.6 - 0.1	- 1.2 - 3.4 11.8 0	-1.2 -2.7 11.8	0.4 - 0.1 12.0	0.4 - 3.9 11.5 2.7
0429 B E 0432 B C 0433 B	0.1 0 - 0.3 11.9 0 3.0	0.8 - 2.3 - 3.8 11.6 - 0.1 3.0	- 1.2 - 3.4 11.8 0 3.0	-1.2 -2.7 11.8 0 3.0	0.4 - 0.1 12.0 0 4.5	0.4 3.9 11.6 2.7
0429 8 E C C C C C C C C C C C C C C C C C C	0.1 0 - 0.3 11.9 0 3.0 - 0.1	0.8 - 2.3 - 3.8 11.6 - 0.1 3.0 0	- 1.2 - 3.4 11.8 0 3.0 0	-1.2 -2.7 11.8 0 3.0 0	0.4 - 0.1 12.0 0 4.5 - 0.1	0.4 - 3.9 11.5 2.7 0
O429 8 E C O432 8 C C O433 8 C C O434 8 C C	0.1 0 - 0.3 11.9 0 3.0 - 0.1 3.6	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7	-1.2 -3.4 11.8 0 3.0 0 4.5	-1.2 -2.7 11.8 0 3.0 0 4.8	0.4 - 0.1 12.0 0 4.5 - 0.1 2.9	0.4 - 3.9 11.6 2.7 0 0.4 0
O429 8 E O432 B C O433 B C O434 B C O434 B C O434 B C O438 B C O43	0.1 0 -0.3 11.9 0 -0.1 3.0 -0.1 3.6 -0.4	0.8 - 2.3 - 3.8 11.6 - 0.1 3.0 0 4.7 - 2.9	- 1.2 - 3.4 11.8 0 3.0 0	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4	0.4 - 0.1 12.0 0 4.5 - 0.1	0.4 - 3.9 11.5 2.7 0
O429 8 E C O432 8 C C O433 8 C C O434 8 C C	0.1 0 - 0.3 11.9 0 3.0 - 0.1 3.6	0.8 - 2.3 - 3.8 11.6 - 0.1 3.0 0 4.7 - 2.9	-1.2 -3.4 11.8 0 3.0 0 4.5	-1.2 -2.7 11.8 0 3.0 0 4.8	0.4 - 0.1 12.0 0 4.5 - 0.1 2.9	0.4 - 3.9 11.6 2.7 0 0.4 0
Q429 8 E	0.1 0 -0.3 11.9 0 -0.1 3.0 -0.1 3.6 -0.4	0.8 - 2.3 - 3.8 11.6 - 0.1 3.0 0 4.7 - 2.9	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7	0.4 -0.1 12.0 0 4.5 -0.1 2.9 0	0.4 - 3.9 11.5 2.7 0 0.4 0 - 2.4 11.7
Q429 8 E E G G G G G G G G G G G G G G G G G	0.1 0' - 0.3 11.9 0 3.0 - 0.1 3.6 - 0.4 11.7 2.0	0.8 - 2.3 - 3.8 11.6 - 0.1 3.0 0 4.7 - 2.9 11.4 1.9	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7	0.4 -0.1 12.0 0 4.5 -0.1 2.9 0 11.5	0.4 - 3.9 11.6 2.7 0 0.4 0 - 2.4 11.7 2.0
Q429 8 E E G G G G G G G G G G G G G G G G G	0.1 0 - 0.3 11.9 0 3.0 - 0.1 3.6 - 0.4 11.7 2.9 2.5	0.8 - 2.3 - 3.8 11.6 - 0.1 3.0 0 4.7 - 2.9 11.4 1.9	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8 2.4	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4	0,4 -0.1 12.0 0 4.5 -0.1 2.9 0 11.5	0.4 - 3.9 11.6 2.7 0 0.4 0 - 2.4 11.7 2.0 2.5
O429 8 E O432 8 C O433 8 C O434 8 C O438 8 C O438 8 C O448 8 C O44	0.1 0' -0.3 11.9 0 3.0 -0.1 3.6 -0.4 11.7 2.9 2.5 2.5	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7 -2.9 11.4 1.9 2.5 2.5	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8 2.4 2.5	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4 2.5	0.4 - 0.1 12.0 0 4.5 - 0.1 2.9 0 11.5 1.8 0 2.4	0.4 - 3.9 11.6 2.7 - 0 0.4 0 - 2.4 11.7 2.0 2.5 2.7
Q429 B E C Q432 B C C Q433 B C C Q434 B C C Q434 B C C Q438 B C C Q438 B C C Q439 B C C C C Q439 B C C C C C Q439 B C C C C C C C C C C C C C C C C C C	0.1 0.3 11.9 0 3.0 -0.1 3.6 -0.4 11.7 2.0 2.5 2.5	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7 -2.9 11.4 1.9 2.5 -3.8 -3.8 -3.8 -13.0	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8 2.4 2.5 1.7	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4 2.5 -4.6	0.4 -0.1 12.0 0 4.5 -0.1 2.9 0 11.5 1.8 0 2.4 0	0.4 - 3.9 11.6 2.7 - 0 0.4 0 - 2.4 11.7 2.0 2.5 2.7 - 0.7
O429 8 E O432 8 C O433 8 C O434 8 C O438 8 C O438 8 C O448 8 C O44	0.1 0' -0.3 11.9 0 3.0 -0.1 3.6 -0.4 11.7 2.9 2.5 2.5	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7 -2.9 11.4 1.9 2.5 2.5	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8 2.4 2.5	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4 2.5	0.4 - 0.1 12.0 0 4.5 - 0.1 2.9 0 11.5 1.8 0 2.4	0.4 - 3.9 11.6 2.7 - 0 0.4 0 - 2.4 11.7 2.0 2.5 2.7
0429 B E C O432 B C C O433 B C C O434 B C C O434 B C C O436 B C C O436 B C C O436 B C C C O436 B C C C O446 B C C C O446 B C C C C O446 B C C C C C C C C C C C C C C C C C C	0.1 0.3 11.9 0 3.0 -0.1 3.6 -0.4 11.7 2.0 2.5 2.5	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7 -2.9 11.4 1.9 2.5 -3.8 -3.8 -3.8 -13.0	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8 2.4 2.5 1.7	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4 2.5 -4.6	0.4 -0.1 12.0 0 4.5 -0.1 2.9 0 11.5 1.8 0 2.4 0	0.4 - 3.9 11.6 2.7 - 0 0.4 0 - 2.4 11.7 2.0 2.5 2.7 - 0.7
Q429 B E C Q432 B C C Q433 B C C Q434 B C C Q438 B C C Q439 B C C Q439 B C C Q439 B C C Q440 B C C C C C C C C C C C C C C C C C C	0.1 0 - 0.3 11.9 0 0 3.0 - 0.1 3.6 - 0.4 11.7 2.9 2.5 2.5 - 1.7	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7 -2.9 11.4 1.9 2.5 -13.0 1.9 1.9 1.9 1.9 1.9 1.9 1.9 1.9	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8 2.4 2.5 1.7 -8.1	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4 2.5 -4.6 1.9	0.4 -0.1 12.0 0 4.5 -0.1 2.9 0 11.5 1.8	0.4 - 3.9 11.5 2.7 0 0.4 0 - 2.4 11.7 2.0 2.5 2.7 - 0.7 2.0 2.1 - 0.7 2.0 2.1
0429 B E O432 B C O433 B C O434 B C O438 B C O438 B C O439 B C O443 B O443 B C O443 B	0.1 0' -0.3 11.9 0 3.0 -0.1 3.6 -0.4 11.7 2.0 2.5 2.5 2.5 2.5 2.5 2.5 2.5	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7 -2.9 11.4 1.9 2.5 -3.0 -3.0 1.5 -3.0 1.5 -3.0 1.6 -3.0	-1.2 -3.4 11.8 0 3.0 0 4.5 -3.1 11.7 1.8 2.4 2.5 1.7 -8.1 1.6	-1.2 -2.7 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4 2.5 -4.6 1.9 1.9	0.4 -0.1 12.0 0 4.5 -0.1 2.9 0 11.5 1.8	0.4 - 3.9 11.5 2.7 0 0.4 0 - 2.4 11.7 2.0 2.5 2.7 - 0.7 2.0
Q429 B E Q432 B C Q432 B C Q433 B C Q434 B C Q438 B C Q438 B C Q438 B C Q448 B C Q44	0.1 0' -0.3 11.9 0 3.0 -0.1 3.6 -0.4 11.7 2.0 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5	0.8 -2.3 -3.8 11.6 -0.1 3.0 0 4.7 -2.9 11.4 19 2.5 -13.0 19 19 19 13	-1.2 -3.4 11.8 0 0 3.0 0 4.5 -3.1 11.7 1.8 2.4 2.5 1.7 -8.1 1.6	-1.2 -27 11.8 0 3.0 0 4.8 -2.4 11.7 1.7 2.4 2.5 -4.6 1.9 1.1	0.4 -0.1 12.0 0 4.5 -0.1 2.9 0 11.5 0 1.8 1.8 1.8	0.4 - 3.9 11.5 2.7 0 0.4 0 - 2.4 11.7 2.0 2.5 2.7 - 0.7 2.0 2.1

Schematic diagram

Schematic diagram

	TION	PVM-1350	PVM- 1351Q/1354Q
	- 3	-	DTZ6.2
	3 - 5 J - 7	-	MA151WK 1S2835
	G - 7	MA110	-
	A - 8	-	MA100
	J - 10 J - 10	-	MA157 MA157
	1-14	-	ISV230TP HR3
	C - 11	-	MA151WK
	B-11	_	1SV230TP HR3 MA110
	1 - 15	-	MA110
	J - 16 B - 13	-	MA110
/ 19	H - 15	-	MA110 MA110
41	A - 12	-	DTZ3.6A
344	E-12 J-9	-	MA151WK
)348 D349	J-0	_	MA157 MA157
D350	J - 0		MA157
D351	J-9	-	MA157
D352 D353	K-9	_	MA157 MA157
D354	K-9	-	MA157
D355	K - 9	-	MA157
D362 D363	8 - 12 8 - 12	_	RD10S81 RD10S81
D364	B - 12	-	1S2835
D365	B - 6	-	MA110
FL300 FL401	B - 3 B - 4	-	0
IC301	H-5	-	BA7655AF
IC303	H-14 C-6	- MM1148XFF	CXA1214P MM1149XFF
IC313 IC315	B - 12	- mmi 146AFF	XRU40538F
IC316	8-2	-	MM1148XFF
IC317	B - 9 B - 3	-	MC14588F
JR306 L301	J-13	-	15µH
L302	1 - 15	-	15µH
L303	1 – 14 H – 15	<u>.</u> .	39 µH 15 µH
L306	G - 14	-	39 µH
L307	H - 13	- - -	15µH
L317	C-9 B-3	-	18mmH 100µH
Q302	G-2	-	2SA1037K
Q306	D-3	-	2SC2412K
Q310 Q314	C-3 D-4	-	2SA1037K DTA144EK
Q317	G-7	2SC2412K	-
Q323 Q324	1-6 E-6	-	DTC144EK DTC144EK
Q324 Q328	H-7		25K94
Q332	H-8	-	DTC144EK
Q333 Q334	C - 8 I - 12	-	2SC2412K 2SA1037K
Q335	8-8	-	2SC2412K
Q336	I - 13	-	2SK94
Q337 Q339	I - 13 C - 10	-	2SC2412K 2SA1037K
Q348	I = 15	-	2SC2412K
Q347	G - 15	-	DTC144EK
Q348 Q349	I – 16 H – 16	-	2SA1037K 2SA1037K
Q355	B - 3	-	2SC2412K
Q358	C-11	-	DTC144EK
Q357 Q358	1-8 H-3	- 1	2SC2412K 2SC2412K
Q358 Q359	H-3	-	2SC2412K 2SA1037K
Q362	E - 12	-	2SC2412K
Q366 Q367	8 - 13 8 - 13		2SA1037K 2SA1037K
Q368	B - 13	-	25A1037K
Q369	B - 12	-	DTA144EK
O-TO BE MO	44.00		

O:TO BE MOUNT -: NOT MOUNT

O:TO BE MOUNT
-: NOT MOUNT

-: NOT MOUNT					
Ref	LOCATION	PVM-1350	PVM- 1351Q/1354Q		
R301	D-9	-	100		
R303	E-9	-	100		
R305	K - 13	-			
R306	K - 13	1 -			
R311	K-7	-	1.8K		
R319	1-5	-	6.8K		
R332	J-7	-	100K		
R333	J-7	-	100K		
R337	J-15	-	10K		
R338	J - 15	-	56K		
R339	J-13	-	8.2K		
R340	J-14	-	47K		
R341	J - 15	-	8.2K		
R343	J - 14	-	82K		
R344	J - 13	-	. 120K		
R347	J - 13	-	4.7K		
R348	1-12	-	180		
R349	J-7	-	62K		
R351	J-7	-	3.3K		
R352	1-15	-	10K		
R353	1-13	-	1K		
R355	i – 13	-	2.7K		
R356	J – 14	-	39K		
R357	J-7	-	1M		
R358	1-13	-	1.5K		
R359	i – 15	-	4.7K		
R360	l – 13	-	390		
R361	J-1	-	100		
R362	1 – 12	-	5.6K		
R363	1 - 13	-	470K		
R364	1-14	-	470K		
R367	1 - 15	-	1.2K		
R368	H - 12	-	1K		
R371	H - 16	-	8.8K		
R372	H-12	-	1.5K		
R373	H-2	-	580		
R374	G-2	-	680		
R375	H - 15	-	1.5K		
R379	H - 16	-	6.8K		
R380	G-2	-	4.7K		
R381	H-7	-	39K		
R383	H - 15	-	3.3K		
R364	H - 15	-	10K		
R385	H - 13	-	4.7K		
R389	G-2	-	560		
R391	H - 14	-	470K		
R395	G - 2		580		
R396	G - 14	-	470K		
R1301	G - 13	· -	150		
R1302	G - 13	-	150		
R1303	G - 14	-	390		
R1315	B - 2	÷ -	100		
R1321	D - 3	-	820		
R1322	D-3	-	2.2K		
R1324	D-3	-	3.3K		

301 (D) (C) 302 (t) (D) (D) 303 (E) (B) (B) (B) (B) (B) (B) (B) (B) (B) (B	2.8 2.9 2.9	0				PG6	1	PAL	SECAM	NTSC 3.58	NTSC 443	S-VICEO	RGB
302 (b) (c) (d) (d) (d) (d) (d) (d) (d)	2.9		2.9	30	30	2.3	10326 to	6.2	6.2	62	52	52	59
103 Tr 103 Tr 16 16 19 304 (b)		0	1.8	: 7	1 1.7	3.5	:3	62	5.2	52	5.3	6.2	5.9
0 303 Tr 18 19 49 304 (b)		2.9	2.9	0.3	2.9	2.9	14	6.2	62	62	5.2	5.2	5.9
303 T 16 16 19 304 (b)	5.3	51	4.5	45	4.5	15	40350 💮	6.5	6.5	54	5.3	5	5.9
18 19 304 (b)	10.5	8.4)	0	C	Ú	(2)	62	62	62	5.3	60	54
45 304 (b)	23	2.6		2.2	2.6	2.9	1	6.2	62	6.2	5.3	60	6.4
304 (d)	01	4.2	0.6	0.6	0.6	01	0300 B	2.5	2.5	2.2	2.2	2.2	2.2
	3.9	2.9	3.1	3.1	3.3	39	C	10.2	10.2	10.4	10.5	10.4	10.5
	2.2	2.5	2.2	2.2	2.2	2.2	E	19	1.9	1.6	1.5	15	16
	7.3	72	94	94	26	9.4	C201 &	: 8.6	85	82	8.3	95	9.8
10		73	2.5 2.5	25		25	Ω303 €	5.7	5.7	5.7	57	5.5	57
16	1.3	10	22	2.5	25	2.5	0304 8		6.3	63	5.4	62	6.3
15	25	25	2.2	2.2	2.3	2.2	5	57	5.7	5.7	5.7	5.5	57
	28	2.9	2.8	0	28	2.2	0305 13	86	85	8.2	€3	85	98
305 (1)	25	1.1	2.5	24	24	28	5	79	7.9	7.5	7.7	79	91
70	41	1.1	41	41			0307 5	1.4	1.4	1.1	1.2	1,4	2.7
3,	0.4	02		0	4.2	45	0309 в	1.4	14	11	1.2	1.4	25
			3					0.1	0.1	0.2	0:	0.1	0
12	2.6	26	25 08	2.4	2.5	27	<u> </u>	0.7	1.8	1.7	18	0	:8
- *				0.8	0.9	0.9	0312 C	8.2	82	86	8.3	9.3	8.1
75	2.1	2.7	1.9	1.9	1.9	2.7	0313 3		82	8.5	8.3	8.2	8.1
06 (b)	8.1	8.1	8.1	8.1	8.1	0	ξ	8.8	8.8	9.3	9.0	8.9	87
(3)	0	0	0	01	0.1	1 4 4	0314 8		64	11.9	11.9	119	11.9
309 (3)	36	0	3.6	3.6	3.6	36	C	0	11.9	0	0	0	0
<u>(a)</u>	0	0	0	0	0	44	Q315 B	3.3	3.2	2.9	3.1	3.2	3.3
310 (i)	52	6.2	6.2	6.2	6.2	5.9	E		3.9	3.5	3.8	3.8	4.0
0	6.3	6.3	62	6.2	6.2	5.9	0318 9	12.1	12.0	11.7	11.9	12.1	12.1
11	5.9	5.9	6.0	6.3	5.9	5.9	С	1.0	1.0	1.2	1.0	1.0	0.9
311 (1)	0	6.2	6.2	6.2	6.2	62	Q322 B	2.4	2.4	2.3	2.3	56	2.4
(3)	6.2	6.2	6.2	6.2	6.2	5.9	E		1.8	1.8	1.8	5.0	1.8
•	6.2	6.3	6.3	6.2	6.2	5.9	O323 B	5.0	5.0	0	0	0	0
6	3.3	3.3	2.9	2.9	2.9	0	C	0	0	3.5	3.5	3.5	3.6
10	59	5.9	59	6.2	5.8	5.9	0324 8	4.1	4.2	0	0	0	0
13	04	0.4	0.4	0.4	0.5	0.7	c	0	0	0.8	0.8	0.8	0.9
112 (3)	3.6	0	3.6	3.6	3.6	3.6	Q328 B	2.2	2.2	2.2	2.2	2.0	1.3
(a)	0	0	0	12.0	0.1	45	C	2.8	2.8	2.8	2.8	0	. 0
113 ①	0	6.3	0	6.3	6.3	6.3	Q329 D	2.1	2.1	2.2	2.4	0	2.2
114 ②	0	3.0	7.6	0	3.0	0	G	0	0	1.6	0	2.9	2.8
0	0	0	0	0	29	0.1	Q332 B	4.9	5.0	0	4.9	0	10
115 ①	0.4	0.4	0.4	0.4	0.4	0.6	C	0	0	4.4	0	4.3	4.4
•	0.6	0	0.6	0.6	0.6	0.6	O333 B	1.7	1.7	1.9	1.8	- 1,7	11.7
(6)	94	9.3 -	- 9.3	9.2	93 -	.9.4	€	1.5	15	1.7	. 1.5 ;	. 15	1.4
0	2.5	2.5	2.5	2.5	2.5	7.2	Q336 G	4.7	4.6	4.6	4.7	42-	4.8
0	04	0.4	0.4	0.4	0.4	0.6	.0	4.3	4.3	4.3	4.3	4.5	4.3
15	04	0.4	0.4	0.4	0.4	0.6	O339 B	12.3	12.5	12.5	12.4	12.5	12.3
17 @	2.0	0	2.0	2.1	2.0	120	0347 B	0.1	4.2	0.1	0.1	0.6	0.1
•	12.0	0	12.0	12.0	12.0	12.0	С	9.4	0.1	9.4	9.4	9.4	9.4
9	10.7	10.6	10.6	10.6	10.5	10.7	0.349 B	2.8	2.7	2.7	2.7	2.2	2.8
13)	9.4	9.4	9.4	9.4	9.1	94	E	3.4	3.3	3.4	3.4	2.8	3.4
18 (5)	11.5	11.5	0	11.4	11.4	11.4	Q354 B	12.0	0.6	0	0	0	: 0
20 ①	6.3	6.3	6.3	6.3	6.3	0	. E	12.0	0.4	0	0	0	-0.2
0	3.0	0	0	3.1	0	0 -	Q358 E	2.2	2.2	0	2.2	2.2	2.2
<u> </u>	0	0	0	0	3.3	0	0360 1	6.2	6.2	6.2	6.3	6.1	6.4
210	0	0.1	0.1	0	2.9	0 -	3	6.2	6.2	6.2	6.3	6.0	
<u> </u>	0	0	0	0	0.1	27	5	1.3	4.7	5.0	5.0	5.3 5.0	3.8
22 🕲	5.8	5.9	6.0	6.3	5.9	5.9	Q361 B	4.9	0				0.8
23 🕲	6.2	6.3	6.2	6.2	6.2	5.9	C 0363 C	0.1	9.0	9.0	0	0.1	14.9
0	0	5.6	5.6	5.6	5.6	5.6	0362 C	9.0			9.5	9.2	
24 (5)	6.2	6.2	6.2	6.2	6.2	5.9	0364 C	3.3	3.3	2.9	2.9	-2.8	2.9
26 ①	5.9	5.9	6.0	6.3	5.9	5.9	· 0365 B	0.4	0	0.3	0.3	0.4	0.4
2	5.9	5.9	5.9	6.2	. 5.8	5.9	Q369 B	0.8	0.9	0.8	0.8	0.9	4.9
3	5.9	5.9	5.9	6.2	5.8	5.9	0372 B	0	0	0	0	0	4.9
5	1.7	1.9	1.6	1.6	2.1	2.1	C	11,7	11.7	11.8	11.8	11.7	.0
6	2.4	1.0	2.3	2.3	2.3	4.6	Q374 B	ገዐ.4	10.3	10.1	10.3	10.7	6.4
0	0	- 0.1	10.8	0	- 0.1	0	С	. 0	0	0	0	6.2	. 6.7
®	6.3	6.3	6.3	6.3	6.2	5.9	Ε	6.4	6.4	6.3	6.3	6.1	6.7
9	6.3	6.3	6.3	6.3	6.2	5.9	Q375 B	10.7	10.8	10.7	10.7	10.7	5.9
13	6.3	6.3	6.2	6.2	6.2	5.9	C	0	0	0	0	63	6.4

Ref	LOCATION	PVM-1350	PVM- 1351Q/1354Q
R1326	D-3	-	10K
R1327	B - 12		10K
R1358	C-5	-	8.2K
R1362	8-4	-	11K
R1364	8 - 5	- 1	10K
R1382	E-8	-	10K
R1398 R2302	A-9 A-6	•	6.8K
R2303	8-8	-	68K
R2304	8-8		220K
R2305	A - 8	_	33K
R2310	A-8	-	82K
R2313	8-9	-	1K
R2314	C-9	-	560
R2316	C - 10	0	6.8K
R2319	C - 10	-	68K
R2321	C-10	-	2.2K
R2322	C - 10	-	4.7K
R2324	C - 10	1 -	10K
R2333 R2340	C - 10 D - 7	0	47K 10K
R2343	C-11	1]	22K
R2361	C-11	_	120K
R2363	D-12	-	4.7K
R2365	B-11	-	33K
R2368	E - 13	l -	4.7K
R2385	H-9	_	10K
R2388	H - 9	-	10K
R2387	J - 8	-	10K
R2388	H - 11	-	10K
R2392	8-3	-	10K
R2393	B - 3	-	10K
R3305	E - 10 F - 10	-	3.3K
R3306 R3309	C - 14	_	3.9K 10K
R3314	C - 12		100
R3315	C - 12	4.7K	-
R3316	G-7	4.7K	-
R3316	G-7	4.7K	-
R3319	G-7	4.7K	-
R3320	A - 12	-	33К
R3321	G-7	12K	-
R3322	G-7	10K	-
R3334	E - 12	-	10K
R3335 R3339	B - 9 K - 12	-	470K
H3339 R3340	K-12 K-13	_	68K 120K
R3344	I - 13	_	120K 22K
R3345	1-13	_	220
R3355	A - 12	-	47K
R3356	B - 13	_	1.2K
R3357	8 - 13	-	1.2K
R3358	8 - 13	-	1.2K
R3359	A - 12	-	22K
R3360	8 - 12	-	10K
R3361	8 - 12	-	47K
R3362	B - 13	-	1K
R3363	8 - 13	-	1K
R3364 R3361	C - 11	-	10K
R3381	1-6 H-6	-	470
R3382	H - 6	-	820 6 8K
R3384	1-4	_	3.3K
R3385	H - 2	_	2.2K
R3386	H-3	-	2.2K
T300	1-12	1	COII

				1351Q/1354Q
	C300	K - 12		0.01
	C309	K – 12	-	0.01
	C310	K-7	-	0.01 / 25V
	C317 C319	J - 15 I - 15	-	15P -
	C320	1-13		0.01
	C322	1 - 12	_	120P
	C323	I - 15	_	15P .
	C324	I - 16	· -	22P
	C325	J-7	-	10
	C327 C328	1 – 12 J – 2	· ·	0.1 / 25V
	C329	J-15	_	0.01 100P
	C330	1 - 13		47P
	C331	I – 15	-	15P
	C332	l – 13	-	0.1
	C333	I - 15	-	0.01
	C334	1 – 13		0.001
	C335 C336	1 – 14 1 – 13	-	0.001 47 / 25V
	C337	1 - 13	_	0.01
	C338	1 – 14	-	120P
ı	C339	H - 15	-	15P
	C340	1-8	· -	0.01
	C341	H - 14	-	120P
- 1	C342	H = 14 H = 14	-	0.0058
- 1	C344 C345	H - 14	_	0.001
- 1	C346	H - 14	_	1
- 1	C347	H - 13	-	47P
- 1	C348	G - 14	-	0.1 / 25V
l	C351	H - 12	-	47 / 25V
- 1	C357 C389	G-4 E-9		0.01 47 / 25V
ı	C1301	D-9	_	47 / 25V
- 1	C1303	G-7	0.1 / 25V	-
	C1304	C-2	-	47 / 25V
	C1308 .	C-2	-	0.01
	C1309	D-3	-	180P
	C1310	C-3	- 1	0.01 0.01
	C1312	C-3	_	0.01 47 / 25V
l	C1325	B-5	- - -	0.01
j	C1341	A-8	-	0.001
- 1	C1343	A - 8	-	68P
- 1	C1346	8 - 8	-	47 / 25V
j	C1347	8 - 8 8 - 8	-	0.01
- 1	C1348 C1349	A - 9	_	270P 100P
- 1	C1350	C-0	_	0.01
- 1	C1351	C-0	-	1
1	C1352	C - 10	-	0.015
	C1362	C-11	-	82P
- 1	C1364 C1369	B - 11 I - 13	-	470P 27P
- 1	C1370	G - 14	_	27P
- 1	C1378	B - 4	-	15P
- 1	C1380	1 - 13	-	22P
- 1	C1381	H - 13	- 1	22P
	C1382	G - 10 F - 10	- 1	100 / 10V
- 1	C1383 C1384	H-4	- 1	47 / 25V
	C1385	1-5	_ 1	0.1 / 25V 0.01
- 1	C1386	1-5	-	0.01
	C1387	1-4	-	0.01
	C1393	1 13	-	100P
	CN303	L-9	- 1	12P
	CP300 CP301	C-3	-	0
	CP301 CP302	J-2	_	0
I	CP303	A-3	-	-
L			L	
	TO BE MOU			


PVM-1351Q/1354Q


LOCATION


PVM-1350


• A BOARD WAVEFORMS


• A BOARD WAVE	FORMS	
16	10	\bigcirc
	Att Att	Promy
1.0 Vp-p (H)	0.94 Vp-p (H)	0.85 Vp-p (
3-V10E0 0.94 Vp-p (H)	3-VIDEO	5-V [8E0]
20	0.6 Vp-p(H)	0.6 Vp-p (
		* .
0.2 Vp-p(H)	NTSC3.58 0.24 Vp-p(H) NTSC4.43 0.12 Vp-p(H)	-
ව	2)	2)
B		111 11 11 11 11 11 11 11 11 11 11 11 11
0.27 Vp-p(H)	SECAM 0.17 Vp-p (H)	0.24 Vp-p (5-vi0eo 0.27 Vp-p (
20 June	20 Jume L	(3) F
PAL 0.4 Vp-p (H) SECAM	MTSC3.58 0.37 Vp-p(H)	5-VIDEO
0.36 Vp-p (H)	4.0 Vp-p (.H)	0.4 Vp-p (
MALOG RGB (H)	1.0 Vp-p (H)	PAL 0.26 Vp-p (1
(3)	3	3
	D-400-4	
0.2 Vp-p (H)	NTSC3.58.4.43 0.23 Vp-p (H)	0.18 Vp-p (I
8	2) managar	②-17 3.2
F (Y2-2 (H)	PAI	NTSC3.58. 4.43 S-VIDEO
5.4 Vp-p(H)	1.0 Vp-p(H)	(2)-17
Myny	My property	7000 000
0.8 Vp-p(H) мтэсз.58 0.85 Vp-p(H)	NTSC4.43 0.73 Vp-p (H) 5-VIDEO 0.9 Vp-p (H)	ANALOG RGB 0.7 Vp-p()
3	③ <u>'</u>	3
		_ Jan Jan
0.7 Vp-p(H)	ANALOS RGB	5-V10E0:
3	ر نر	33
ANALOG RGB 1.4 Vp-p (H)	3-V10EQ :::	ANALOG RGB (134)
_	13.Vp-p(H)	1.4 Vp-p (H
39 100400401		
1.3 Vp-p (H)	ANALOG RGB 1.4 Vp-p(H)	0.3 Vp-p (H
§ .	③ ∴ ∴	3
	B+BB+BB+	B-189-4
0.1 Vp-p (H)	о. 15 Vp-p (H)	NT9C4.43 0.3 Vp-p (}
3 9	33)	3
S-VIĐEO	PAL	SECAM
5-V18E0 0.2 Vp-p (H)	~ - - 1	0.1 Vp-p (H
_	0.3 Vp-p(H)	
€8	(3) VP-P(H)	3
€8 **** ****	39 1-41-4	
(15c3.58 0.07 Vp-p (H)	(36) ************************************	3-V1060
(Sc. 55 0.07 Vp-p (H)	39 1-43-4	3-V1060 0.07 Vp-p(H
_	(36) ************************************	3-V1060 0.07 Vp-p(H





























(C . BUFFER)
(Y . BUFFER)
(V . B . BUFFER)
VIDEO IN BUFFER
(V . A . BUFFER)
16: 5 COIET








9

10





sure to connect the connector 703 for safety.

BOARD * MARK

	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDEO	ANALOG RGB
701 B	2.0	1.9	1.73	1.8	1.8	2.0
E	1.4	1.3	1.1	1.1	1.2	1.4
702 B	2.0	1.9	1.7	1.7	1.8	2.0
E	1.5	1.3	1,1	1.1	1.2	1.4
703 B	1.9	1.8	1.6	1.6	1.8	1.9
E	1.3	1.2	1.0	1.0	1.2	1.3
704 B	143.6	148.0	153.9	153.4	144.9	143.8
С	129.0	134.3	135.4	134.5	31.2	111.5
Ε	139.7	144.4	150.3	149.6	140.4	140.1
705 B	141.7	145.8	154.9	154.2	145.0	141.8
C	124.9	130.2	132.3	130.4	60.4	106.6
E	138.3	142.3	151.3	150.5	140.7	138.5
706 B	149.7	151.5	150.4	159.8	144.9	148.6
С	134.5	138.3	141.2	141.1	103.2	114.7
E	146.2	148.0	157.1	156.4	140.8	145.0
707 C	143.8	148.0	154.0	153.4	144.9	143.7
708 C	141.9	145.9	155.2	154.3	145.0	141.8
709 C	149.8	151.5	160.6	159.9	144.9	148.5
710 B	172.8	173.1	174.3	173.9	167.0	173.5
E	160.9	164.0	162.9	162.2	154.0	161.2
711 8	172.8	173.2	174.3	173.9	167.0	173.5
С	150.5	161.0	162.3	161.8	154.1	161.3
712 B	172.9	173.2	174.0	174.2	1,67.0	173.5
Ε	161.6	163.6	164.1	164.8	154.5	161.4
713 B	172.8	173.2	173.9	173.9	166.8	173.5
С	184.2	184.5	184.7	184.6	176.6	183.8
E	173.3	173.6	174.3	174.3	167.2	173.9
714 C	173.6	173.7	174.5	174.4	167.4	174.1
715 B	146.7	148.6	157.6	157.0	140.3	145.7
С	149.5	151.5	160.6	159.9	144.9	148.5
Ε	146.1	148.0	157.2	156.5	140.7	145.0
716 B	139.2	143.3	152.5	151.5	140.7	139.4
С	141.7	145.8	155.2	154.2	145.1	141.8
Ε	138.2	142.3	151.4	150.5	140.6	138.4
717 B	140.9	145.4	151.7	150.8	140.6	141.2
С	143.6	148.0	154.1	153.4	144.9	143.8
E	139.8	144.4	150.5	149.6	140.4	140.0


D701	PROTECT 1
D702	PROTECT 2
D703	PROTECT 3
D704	PROTECT 4
D705	PROTECT 5
D706	PROTECT 6
D707	PROTECT 7
D708	PROTECT 8
D709	PROTECT 9
D713	PROTECT 10
D715	PROTECT 11
D716	PROTECT 12
D717	PROTECT 13
Q701	B DRIVE
Q702	G DRIVE
Q703	R DRIVE
Q704	8 BUFF
Q705	G BUFF
Q706	R BUFF
Q707	B OUT
Q708	G OUT
Q709	R OUT
Q710	IK SW 1
Q711	IK SW 2
Q712	IK SW 3
Q713	V. BLK OUT
Q714	V. BLK INT
Q715	TRACE SW 1
Q716	TRACE SW 2
0717	TRACE SW 3






- H BOARD -


- Q BOARD -




(PVM-1351Q/1354Q only)


- X BOARD -









- G BOARD -






- H BOARD -




(PVM-1351Q/1354Q only)

- X BOARD -








S-VIDEO ANALOG RGB

60.4 106.6 140.7 138.5 144.9 148.6


144.9 143.5 103.2 114.7 140.8 145.0 144.9 143.7 145.0 141.8

144.9 148.5 167.0 173.5 154.0 161.2


140.3 145.7 144.9 148.5



- Q BOARD -




- H BOARD -




(PVM-1351Q/1354Q only)


- X BOARD -




- J BOARD -



- S BOARD -




- C BOARD -




Schematic diagram

← C board

6-5. SEMICONDUCTONS





SECTION 7 EXPLODED VIEWS

NOTE:

 Items with no part number and no description are not stocked because they are seldom required for routine service.


- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark \triangle are critical for safety. Replace only with part number specified.


Les composants identifies pa une trame et une marque A sont critiques pour la securite Ne les remplacer que par une piece portant le numero specifie

7-1. CHASSIS

▲: +BVTP3 × 8 7-685-646-79 ●: +BVTP3 × 12 7-685-648-79 ■: +BVTP4 × 16 7-685-663-79 Δ: +PS4 × 8 7-682-661-09



REF. NO. PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION -
2 4-391-825-01 3 4-847-802-11 4 *A-1297-195-A *A-1297-196-A 5 A 1-453-163-11 6 *4-043-690-01 7 *4-043-689-01 8 A 1-532-746-11	COVER ASSY, TOP RIVET, NYLON SCREW (OS), CASE, CLAW A BOARD, COMPLETE (PVM-1351Q/135 A BOARD, COMPLETE (PVM-1350) TRANSFORMER ASSY, FLYBACK BRACKET, MAIN BRACKET, G FUSE, GLASS TUBE (4.0A/125V) G BOARD, COMPLETE	54Q)	11 12 13 14 15 16	4-043-688-01 4-043-688-11 *4-043-678-01 4-043-687-01 4-386-618-01	TERMINAL BO ARD ASSY, I/I TERMINAL BO ARD ASSY, I/I PANEL, CONNECTOR (PVM-1: PANEL, CONNECTOR (PVM-1: TERMINAL, GROUND COVER, REAR RIVET, T TYPE S BOARD, COMPLETE



SECTION 7 EXPLODED VIEWS

NOTE:

Items with no part number and no description are not stocked because they are seldom required for routine service.
 The construction parts of an assembled

 The construction parts of an assembled part are indicated with a collation number in the remark column.

 Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items. The components identified by shading and mark A are critical for safety.


specified.

Replace only with part number

Les composants identifies par une trame et une marque & sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

7-1. CHASSIS

▲: + BVTP3 × 8 7-685-646-79 ♦: + BVTP3 × 12 7-685-648-79 ■: + BVTP4 × 16 7-685-663-79 Δ: + PS4 × 8 7-682-661-09



REF.NO. PART NO.	DESCRIPTION	REMARK	REF.NO	PART NO.	DESCRIPTION
2 4-391-825-01 3 4-847-802-11	SCREW (OS), CASE, CLAW A BOARD, COMPLETE (PVM-1351Q/ A BOARD, COMPLETE (PVM-1350) TRANSFORMER ASSY, FLYBACK BRACKET, MAIN BRACKET, G FUSE, GLASS TUBE (4.0A/125V)	′1354Q)	10 11 12 13 14 15 16 17	*4-044-053-01 1-537-735-11 1-537-735-21 4-043-688-01 4-043-688-11 *4-043-678-01 4-346-618-01 *A-1390-391-A *4-044-256-01	TERMINAL BOARD ASSY, I/O (A (PVM- TERMINAL BOARD ASSY, I/O (E PANEL, CONNECTOR (PVM-1351Q PANEL, CONNECTOR (PVM-1350)) TERMINAL, GROUND COVER, REAR RIVET, T TYPE S BOARD, COMPLETE

SECTION 7 EXPLODED VIEWS

NOTE:

 Items with no part number and no description are not stocked because they are seldom required for routine service.

- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


The components identified by shading and mark A are critical for safety.

specified.

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.


7-1. CHASSIS

▲:	+ BVTP3 × 8	7-685-646-79
•:	+ BVTP3 × 12	7-685-648-79
	+ BVTP4 × 16	7-685-663-79
Δ :	+ PS4 × 8	7-682-661-09
Π.	1 DVTT4 × 0 (C)	7 600 E61 0



REF. NO	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
6 7	4-391-825-01 4-847-802-11 *A-1297-195-A *A-1297-196-A 1-453-163-11 *4-043-690-01 *4-043-689-01 \$1-532-746-11	SCREW (OS), CASE, CLAW A BOARD, COMPLETE (PVM-1351Q/135- A BOARD, COMPLETE (PVM-1350) TRANSFORMER ASSY, FLYBACK BRACKET, MAIN	4 Q)	11 12 13 14 15 16	1-537-735-21 4-043-688-01 4-043-688-11 *4-043-678-01 4-043-687-01 4-386-618-01	SHEET, AC COVER TERMINAL BOARD ASSY, I/O (A) (PVM-135 TERMINAL BOARD ASSY, I/O (B) (PANEL, CONNECTOR (PVM-1351Q/13 PANEL, CONNECTOR (PVM-1350) TERMINAL, GROUND COVER, REAR RIVET, T TYPE S BOARD, COMPLETE SHEET METAL, G REINFORCEMENT	1Q/1354Q) PVM-1350) 54Q)

7-2. PICTURE TUBE



X-4031-711-1 CABINET ASSY, BOTTOM 4-042-608-01 NUT, PLATE A.8-734-822-05 PICTURE TUBE (M34KBE20X) (PVM-1354Q) A.8-736-255-05 PICTURE TUBE (A34JHS12X) (PVM-1350/1351Q)

3-703-961-01 SPACER, DY

SECTION 8 ELECTRICAL PARTS LIST

A (PVM-1351Q/1354Q)

NOTE:

The components identified by shading and mark \(\Delta\) are critical for safety. Replace only with part number specified.

Les composats identifi Les composants identifies par une trame et une marque \(\Delta\) sont critiques pour la securite. Ne les remplacer que par une

.

- Items marked " * " are not stocked. since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- · All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS

- All resistors are in ohms
 F: nonflammable

When indicating parts by reference number, please include ence number, please the board name.

CAPACITORS COILS · MF : µF, PF : µµF • MMH : mH, UH : μH

- ullet The components identified by $lackbox{1}{f Z}$ in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
- * : Selected to yield optimum performance.
- · There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please include the board name.

REF.NO.	PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION		REMARK
;	1-540-044-11 *4-030-359-01	A BOARD, COMPLETE (PVM-13 *************** SOCKET, IC HEAT SINK, H. PIN	510/135	54Q)	C171 C172 C173 C174 C200	1-163-243-11 1-163-243-11	CERAMIC CHIP 100P CERAMIC CHIP 47PF CERAMIC CHIP 47PF CERAMIC CHIP 47PF ELECT 4.7M	5% 5%	50V 50V 50V 50V 50V
	*4-043-154-01 *4-043-994-01 4-363-414-00 4-382-854-11	HOLDER, IC PLATE (CF), SHIELD SPACER, MICA SCREW (M3X10), P, SW (+)			C201 C202 C203 C204 C205	1-106-383-00 1-163-017-00 1-124-927-11 1-124-907-11 1-124-360-00	CERAMIC CHIP 0.00	IF 20%	100V 50V 50V 50V 16V
		D PASS FLTER>			C206 C207	1-126-375-11 1-124-478-11		fF 20%	25V 25V
BPF400	1-236-363-11	FILTER, BAND PASS			C208 C209 C300	1-124-907-11	ELECT 10MF	F 20% NF 20%	50V 50V 50V
C10F		ACITOR>	£ 9	50V	C304 C305	1-164-004-11 1-163-125-00	CERAMIC CHIP 0.18	4F 10% PF 5%	25V 50V
C105 C106 C114 C115 C116	1-163-251-11 1-163-251-11 1-163-031-11 1-163-031-11	CERAMIC CHIP 100PF CERAMIC CHIP 100PF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF	5%	50V 50V 50V 50V	C306 C309 C310	1-163-031-11 1-163-031-11 1-164-004-11	CERAMIC CHIP 220P CERAMIC CHIP 0.01 CERAMIC CHIP 0.01 CERAMIC CHIP 0.1N	1MF	50V 50V 25V
C117 C118 C119 C121	1-163-031-11 1-163-125-00 1-165-319-11 1-163-237-11 1-165-319-11		5% 5%		C311 C312 C313 C314 C315	1-163-809-11 1-124-925-11 1-163-145-00 1-163-249-11 1-124-907-11	CERAMIC CHIP 0.04 ELECT 2.21 CERAMIC CHIP 0.00 CERAMIC CHIP 82PI ELECT 10M	MF 20% 015MF 5% F 5% F 20%	25V 50V 50V 50V 50V
C123 C124 C132 C133 C134 C135	1-163-251-11 1-163-141-00 1-163-251-11 1-163-251-11 1-163-251-11	CERAMIC CHIP 100PF CERAMIC CHIP 0.001MF CERAMIC CHIP 100PF CERAMIC CHIP 100PF	5% 5% 5% 5%	50V 50V 50V 50V 50V	C316 C317 C318 C319 C320	1-124-477-11 1-163-097-00 1-124-907-11 1-163-222-11 1-163-031-11	CERAMIC CHIP 15PI ELECT 10M CERAMIC CHIP 5PF CERAMIC CHIP 0.0	F 5% F 20% 0.25PF	50V
C136 C141 C142 C143 C144	1-163-251-11 1-164-161-11 1-163-125-00 1-165-319-11 1-165-319-11	CERAMIC CHIP 100PF CERAMIC CHIP 0.0022MF CERAMIC CHIP 220PF	5% 10% 5%	50V 50V 50V 50V 50V	C322 C323 C324 C325 C326	1-163-119-00 1-163-097-00 1-163-235-11 1-124-907-11 1-164-004-11	CERAMIC CHIP 120 CERAMIC CHIP 15P CERAMIC CHIP 22P ELECT 10M CERAMIC CHIP 0.1	F 5% F 5% IF 20% MF 10%	50V 50V 50V 50V 25V
C145 C154 C155 C156 C156	1-165-319-11 1-163-037-11 1-163-023-00 1-163-019-00 1-163-019-00	CERAMIC CHIP 0.022MF CERAMIC CHIP 0.015MF CERAMIC CHIP 0.0068MF	10% 10% 10% 10%	50V 25V 50V 50V 50V	C327 C328 C329 C330 C331	1-164-004-11 1-163-031-11 1-163-251-11 1-163-243-11 1-163-097-00	CERAMIC CHIP 0.1 CERAMIC CHIP 0.0 CERAMIC CHIP 100 CERAMIC CHIP 47P CERAMIC CHIP 15P	PF 5% PF 5%	25V 50V 50V 50V 50V
C158 C159 C161 C162 C164	1-163-809-11 1-163-037-11	CERAMIC CHIP 0.047MF CERAMIC CHIP 0.022MF	10% 10% 20%	25V 25V 16V 50V 50V	C332 C333 C334 C335 C336	1-164-004-11 1-163-031-11 1-163-141-00 1-163-141-00 1-124-477-11	ELECT 47M	01MF 001MF 5% 001MF 5% MF 20%	25V 50V 50V 50V 25V
C165 C166 C167 C168	1-165-319-11 1-164-004-1 1-124-472-1 1-124-472-1	CERAMIC CHIP 0.001MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF LELECT 470MF CERAMIC CHIP 0.01MF	10% 20% 20%	50V 25V 10V 10V	C337 C338 C339 C340 C341	1-163-031-11 1-163-119-00 1-163-097-00 1-163-031-11 1-163-119-00	CERAMIC CHIP 120 CERAMIC CHIP 15F CERAMIC CHIP 0.0	OPF 5% PF 5% NIMF	50V 50V 50V 50V 50V
¢169	1-164-232-1	CERAMIC CHIP O.DIMF	10%	50 V	C342	1-163-018-00	CERAMIC CHIP O.	0056MF 10%	50V

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION		REMARK
C343	1-163-031-11	CERAMIC CHIP O	.01MF		50V	C409		CERAMIC CHIP 0.01MF		50V
C344 C345 C346 C347	1-163-141-00 1-163-141-00 1-124-903-11 1-163-243-11	CERAMIC CHIP O CERAMIC CHIP O CERAMIC CHIP O ELECT 1 CERAMIC CHIP 4	.001MF .001MF MF 7PF	5% 20% 5%	50V 50V 50V			ELECT 22MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.01MF ELECT 10MF	20% 10% 20% 10%	50V 25V 50V 50V
C348 C349	1-164-004-11 1-163-141-00	CERAMIC CHIP O CERAMIC CHIP O	.1MF .001MF	10% 5%	25V 50V	C416	1-164-232-11	CERAMIC CHIP 0.01MF		507
C350 C351 C352	1-163-141-00 1-124-477-11 1-163-031-11	CERAMIC CHIP O CERAMIC CHIP O CERAMIC CHIP O CECT CERAMIC CHIP O CERAMIC CHIP O CERAMIC CHIP I	.001MF 7MF .01MF	5% 20%	50V 25V 50V	C417 C418 C419 C420 C421	1-164-182-11 1-124-472-11 1-163-809-11	CERAMIC CHIP 0.01MF CERAMIC CHIP 0.0033MF ELECT 470MF CERAMIC CHIP 0.047MF CERAMIC CHIP 0.22MF	10%	50V 50V 10V 25V 25V
C353 C354 C355 C356	1-163-121-00 1-124-903-11 1-124-927-11	CERAMIC CHIP O	50PF MF 7MF	5% 20% 20%	50V 50V 50V	C421 C422 C423		ELECT 1MF CERAMIC CHIP 0.047MF CERAMIC CHIP 0.047MF	20% 10%	50V 25V
Č357	1-163-031-11	CERAMIC CHIP O	0.01MF	20%	50V	C424 C425	1~164-[141-11	I HRAMII I NIP II IIIMH		25V 50V
C358 C359 C360	1-163-031-11 1-124-477-11	CERAMIC CHIP OF).01MF 17MF) 01ME	20%	25V 25V	C426 C427		CERAMIC CHIP 47PF CERAMIC CHIP 0.01MF		50V 50V
C361 C362	1-163-031-11 1-163-031-11	CERAMIC CHIP O CERAMIC CHIP O ELECT CERAMIC CHIP O CERAMIC CHIP O CERAMIC CHIP O CERAMIC CHIP O	0.01MF 0.01MF	10%	50V 50V	C428 C429	1-124-119-00 1-163-031-11 1-124-119-00	ELECT 330MF CERAMIC CHIP 0.01MF ELECT 330MF	20% 20%	16V 50V 16V
C364	1-163-099-00 1-163-031-11	CERAMIC CHIP I CERAMIC CHIP C MYLAR C CERAMIC CHIP (18PF 0.01MF	5%	50V 50V	C430 C431 C432	1-165-319-11	CERAMIC CHIP O.1MF	10%	50V
C365 C366 C367	1-106-343-00 1-163-031-11	CERAMIC CHIP (CERAMIC CHIP (3.001MF 0.01MF	10%	100V 50V 50V	1 C433	1-163-235-11	CERAMIC CHIP 0.1MF CERAMIC CHIP 22PF CERAMIC CHIP 0.01MF CERAMIC CHIP 6PF CERAMIC CHIP 0.1MF	5%	50V 50V
C368	1 100 001 11	CERTIFIC CHIL	0.01111		50V	C434 C435 C436	1-163-089-00 1-164-004-11	CERAMIC CHIP 6PF CERAMIC CHIP 0.1MF	0.25PF 10%	50V 25V
C369 C370	1-164-298-11 1-124-477-11	ELECT CERAMIC CHIP (ELECT ELECT CERAMIC CHIP (0.15MF 47MF	10% 20%	25V 25V 25V	C437		CERAMIC CHIP 0.1MF CERAMIC CHIP 0.047MF		25V 25V
C371 C372					C438 C439 C440	1-163-809-11 1-163-809-11 1-163-031-11	CERAMIC CHIP 0.047MF	10%	25V 50V	
C373 C374 C375	1-163-141-00 1-124-903-11	CERAMIC CHIP (ELECT CERAMIC CHIP :	0.001MF 1MF	5% 20%	50V 50V	C441	1-126-962-11	ELECT 3.3MF		50V
C375 C376 C377	1-124-902-00	CERAMIC CHIP : ELECT CERAMIC CHIP :	U.47MF	5% 20% 10%	50V 50V 25V	C442 C443 C444	1-163-809-11 1-163-243-11 1-165-319-11	CERAMIC CHIP 0.047MF CERAMIC CHIP 47PF CERAMIC CHIP 0.1MF	10% 5%	25V 50V 50V
C378	1-163-809-11	CERAMIC CHIP	0.047MF		25V	C445 C446	1-163-809-11 1-163-089-00	CERAMIC CHIP 0.047MF CERAMIC CHIP 6PF	10% 0.25PF	25V 50V
C379 C380		CERAMIC CHIP			50V 10V 50V	C447 C448	1-163-263-11	CERAMIC CHIP 330PF	5% 5%	50V
C381 C382					50V	C449 C450	1-163-227-11	CERAMIC CHIP 330PF CERAMIC CHIP 47PF CERAMIC CHIP 10PF CERAMIC CHIP 0.047MF CERAMIC CHIP 0.1MF	0.5PF 10%	50V 25V
C383 C384	1-124-477-11 1-163-249-11	ELECT CERAMIC CHIP ELECT ELECT CERAMIC CHIP	47MF 82PF	20% 5%	25V 50V	C451				
C385 C386	1-124-477-11	ELECT ELECT	47MF 10MF	20% 20%	25V 50V 50V	C452 C453 C454	1-163-263-11 1-163-031-11	CERAMIC CHIP 330PF CERAMIC CHIP 0.01MF	5% 5%	50V 50V 50V
C387 C388	1-124-907-11		10MF	20%	50V	C455 C456	1-163-263-11 1-163-089-00	CERAMIC CHIP 47PF CERAMIC CHIP 330PF CERAMIC CHIP 6PF	5% 0.25PI	50V
C389 C390	1-124-477-11 1-163-243-11	ELECT CERAMIC CHIP	47MF 47PF	20% 5%	25V 50V	C457	1-163-031-11	CERAMIC CHIP O.OIMF	F. W	50V
C391 C392	1-124-477-11 1-164-298-11		47MF 0.15MF	20% 10%	25V 25V	C458 C459 C460	1-163-249-11 1-165-319-11 1-164-004-11	CERAMIC CHIP 0.1MF	5% 10%	50V 50V 25V
C393 C394	1-164-298-11 1-124-477-11		0.15MF 47MF	10% 20%	25V 25V	C461	1-163-119-00	CERAMIC CHIP 120PF	5%	50V
C394 C395 C396	1-163-235-11 1-164-299-11	CERAMIC CHIP	0.22MF	5% 10%	50V 25V	C462	1-163-031-11 1-163-031-11	CERAMIC CHIP 0.01MF	10%	50V 50V 25V
C397 C398	1-124-477-11		47MF	20% 20%	25V 25V	C464 C465 C466	1-164-299-11 1-163-097-00 1-163-119-00	CERAMIC CHIP 15PF	5% 5%	50V 50V
C399 C400	1-124-477-11 1-164-232-1	L ELECT L CERAMIC CHIP	47MF 0.01MF	20% 10%	25V 25V 50V	C467	1-163-119-00	CERAMIC CHIP 120PF	5%	50V
C401 C402	1-164-346-11 1-124-910-11		1MF 47MF	20%	16V 50V	C469 C470 C471	1-163-037-11 1-163-243-11 1-163-105-00	CERAMIC CHIP 47PF	10% 5% 5%	25V 50V 50V
C403 C406	1-124-916-1	1 ELECT	22MF	10% 20%	50V 50V	C472	1-163-031-11	CERAMIC CHIP 0.01MF	<i>-</i>	507
C407 C408	1-124-477-1	1 ELECT	47MF 0.01MF	20% 10%	25V 50V	C473	1-163-031-11 1-163-031-11	CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF		50V 50V

The components identified by shading and mark \triangle are critical for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque \triangle sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

60,000,000,000,000		The terms of the control of the cont		ent of graphs fleet		<u></u>				
REF.NO.	PART NO.			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
C476 C477 C478 C479 C482	1-163-031-11 1-164-299-11 1-124-907-11 1-163-121-00 1-124-472-11	CERAMIC CHIP 0.01MF CERAMIC CHIP 0.22MF ELECT 10MF CERAMIC CHIP 150PF ELECT 470MF	10% 20% 5% 20%	50V 25V 50V 50V 10V	C549 C550 C551 C552 C554	1-124-667-11 1-126-163-11 1-106-375-12 1-126-336-11 1-130-736-11 1-124-907-11		10MF 4.7MF 0.022MF 220MF 0.01MF	20% 20% 10% 20% 5%	50V 50V 100V 25V 50V
C483 C484 C485 C486 C487	1-163-249-11 1-163-113-00 1-163-113-00 1-163-249-11 1-163-235-11	CERAMIC CHIP 82PF CERAMIC CHIP 68PF CERAMIC CHIP 68PF CERAMIC CHIP 82PF CERAMIC CHIP 22PF	5% 5% 5% 5%	507		1-124-907-11 1-124-907-11 1-106-381-12 1-124-903-11 1-136-173-00 1-136-159-00			20% 20% 10% 20% 5%	50V 50V 100V 50V 50V
C488 C490 C491 C492 C493	1-163-097-00 1-164-336-11 1-164-336-11 1-164-336-11 1-104-760-11	CERAMIC CHIP 15PF CERAMIC CHIP 0.33MF CERAMIC CHIP 0.33MF CERAMIC CHIP 0.33MF CERAMIC CHIP 0.047MF	10%	25V 25V 25V 50V		1-136-159-00 1-163-249-11 1-124-907-11 1-124-903-11 1-106-367-00 1-136-499-11			5% 20% 20% 10%	50V 50V 50V 50V 100V
C494 C495 C496 C497 C498	1-124-925-11		20%	50V 50V 50V 50V 50V 50V	C568 C569 C570 C571	1-136-499-11 1-124-903-11 1-131-351-00 1-124-360-00 1-164-232-11 1-104-709-11	FLECT TANTALUM ELECT CERAMIC CHIP	1MF 4.7MF 1000MF 0.01MF 4.7MF	5% 20% 10% 20% 10% 0	50V 50V 25V 16V 50V 160V
C499 C500 C501 C502 C503		CERAMIC CHIP 0.01MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.0033MF CERAMIC CHIP 0.001MF CERAMIC CHIP 100PF		25V 50V 50V 50V	C572 C573 C574 C575 C576 C577	1-136-173-00 1-249-383-11 1-163-031-11 1-102-244-00	FILM CARBON CERAMIC CHIP CERAMIC	0.47MF 1.5 5% 0.01MF 220PF	5% 1/4W 10%	50V F 50V 500V
C504 C505 C506 C507 C508		FILM 0.068MF CERAMIC CHIP 560PF ELECT 0.47MF ELECT 100MF MYLAR 0.1MF	5% 5% 20% 20% 5%	50V 50V 50V 25V 50V		1-124-907-11 1-136-540-11 1-126-804-11 1-136-756-11 1-124-927-11 1-102-002-00		10MF 0.82MF 100MF 0.24MF 4.7MF	20% 5% 20% 5% 20%	50V 200V 50V 200V 50V
	1-124-935-11 1-108-700-11 1-124-902-00 1-126-096-11 <u>1</u> 1-129-718-00	MYLAR 0.047MF ELECT 0.47MF ELECT 10MF FILM 0.022MF		6504	C582 C583 C584 C585 C586 C587	1-136-569-11 1-123-267-00 1-124-666-11 1-124-557-11			5% 20% 20% 20%	500V 200V 160V 250V 25V
C515 C516 C517 C518 C519	1-107-995-51	CERAMIC CHIP 0.047MF CERAMIC 330PF CERAMIC CHIP 0.018MF ELECT 100MF CERAMIC CHIP 0.0047MF	10%	25V 500V 50V 160V 50V	C588 C589 C590	1-102-030-00 1-124-667-11 1-102-030-00 1-126-387-11 1-106-371-00 1-123-932-00			10% 20% 10% 20% 10%	500V 500V 500V 50V 200V
C520 C521 C522 C523 C525	1-163-257-11 1-162-114-00 1-126-375-11 1-126-801-11 & 1-136-545-11	CERAMIC CHIP 180PF CERAMIC 0.0047MF ELECT 100MF ELECT 1MF FILM 0.0078MF	5% 20% 20% 3%	50V 2KV 25V 50V 2KV	C592 C593 C594 C595	1-123-932-00 1-165-319-11 1-163-229-11 1-126-336-11 1-124-478-11	CERAMIC CHII CERAMIC CHII ELECT	P 0.1MF P 12PF 220MF	20% 5% 20% 20%	160V 50V 50V 25V 25V
C526 C529 C530 C531 C532	A 1-162-116-91 1-104-789-51 1-124-120-11 1-124-477-11 1-163-031-11	ELECT 0.47MF ELECT 220MF ELECT 47MF	10% 20% 20% 20% 20%	2KV 50V 25V 25V 50V	C597 C598 C599 C1300 C1301	1-164-346-11 1-164-346-11 1-126-157-11 1-124-477-11	CERAMIC CHIL CERAMIC CHIL ELECT	P 1MF	20% 20% 20%	16V 16V 16V 25V 25V
C533 C534 C537 C538 C539	1-102-212-00 1-123-948-00 1-124-913-11 1-106-367-00 1-130-480-00	ELECT 22MF ELECT 470MF MYLAR 0.01MF	10% 20% 20% 10% 5%	500V 250V 50V 100V 50V	C1302 C1304 C1305 C1306 C1307	1-163-133-00 1-124-477-11 1-124-477-11 1-163-031-11	CERAMIC CHI ELECT ELECT CERAMIC CHI	P 470PF 47MF 47MF P 0.01MF	5% 20% 20%	50v 25v 25v 50v 50v
C540 C541 C542 C543 C544	1-163-133-00 1-124-927-11 1-106-351-00 1-106-351-00 1-106-367-00	ELECT 4.7MF MYLAR 0.0022MF MYLAR 0.0022MF	5% 20% 10% 10% 10%	50V 50V 100V 100V 100V	C1308 C1309 C1310 C1311	1-124-907-11 1-163-257-11 1-163-031-11 1-124-477-11	CERAMIC CHI CERAMIC CHI ELECT	10MF P 180PF P 0.01MF 47MF	20% 5% 20%	50V 50V 50V 25V
C545 C546 C547 C548	1-102-212-00 1-163-119-00 1-163-251-11 1-102-212-00	CERAMIC CHIP 120PF CERAMIC CHIP 100PF	10% 5% 5% 10%	500V 50V 50V 500V	C1314	1-163-031-11 1-163-031-11 1-124-477-11 1-124-477-11	CERAMIC CHI ELECT	P 0.01MF P 0.01MF 47MF 47MF	20% 20%	50V 50V 25V 25V

Claifs 1-16-03-11 CREAMIC CRIP 0.01WF 20	REE NO DART NO	DESCRIPTION	D	CMADY 1	DEE NO	DADT NO	DESCRIPTION		DEMARK
1-124-477-11 ELECT APR 201 59V C1405 1-136-173-00 ERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-10 CERANT CUIP 0.019F 50V C1505 1-163-031-10 CERANT CUIP 0.019F 50V C150				i	REP.NU.	PARI NU.	DESCRIPTION		REMARK
1-124-477-11 ELECT APR 201 59V C1405 1-136-173-00 ERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-10 CERANT CUIP 0.019F 50V C1505 1-163-031-10 CERANT CUIP 0.019F 50V C150	C1316 1-163-031- C1317 1-124-477-	1 CERAMIC CHIP 0.01MF 1 ELECT 47MF	50 20% 25)V 5V					507
1-124-477-11 ELECT APR 201 59V C1405 1-136-173-00 ERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-11 CERANT CUIP 0.019F 50V C1405 1-163-293-10 CERANT CUIP 0.019F 50V C1505 1-163-031-10 CERANT CUIP 0.019F 50V C150	C1318 1-124-477- C1319 1-163-037-	1 ELECT 47MF 1 CERAMIC CHIP 0.022MF	20% 25 10% 25	5V 5V	C1393 C1400	1-163-251-11 1-163-031-11	CERAMIC CHIP 100PF CERAMIC CHIP 0.01MF	5%	50V
C1326 1-124-477-11 ELECT 47MF 200 50V C1500 1-124-473-11 ELECT 1000MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C150	C132U 1-124-477-	1 ELECT 47MF	20% 25	1	C1401 C1402	1-136-173-00 1-163-031-11 1-136-173-00	CERAMIC CHIP O.01MF		50V
C1326 1-124-477-11 ELECT 47MF 200 50V C1500 1-124-473-11 ELECT 1000MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C150	C1322 1-124-120- C1323 1-163-031-	1 ELECT 47MF 1 ELECT 220MF 1 CERAMIC CHIP 0 01MF	20% 16	5 V ¦	•				
C1326 1-124-477-11 ELECT 47MF 200 50V C1500 1-124-473-11 ELECT 1000MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 10V C1500 1-124-473-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C1500 1-124-104-104-11 ELECT 100MF 200 50V C1500 1-124-104-11 ELECT 100MF 200 50V C150	C1324 1-163-031- C1325 1-163-031-	1 CERAMIC CHIP 0.01MF 1 CERAMIC CHIP 0.01MF	50 50) V	C1405 C1406	1-163-235-11 1-163-090-00	CERAMIC CHIP 22PF CERAMIC CHIP 7PF	5% 0.25PF	50V
C139	C1326 1-124-477-	1 ELECT 47MF	20% 25	5 Y	C1407 C1408	1-163-085-00 1-163-113-00	CERAMIC CHIP 2PF CERAMIC CHIP 68PF	0.25PF 5%	50V
C1331 1-124-477-11 ELECT 47WF 20\$ 25V C1503 1-129-907-11 ELECT 10MF 20\$ 50V C1333 1-124-477-11 ELECT 47WF 20\$ 25V C1503 1-136-165-00 FILM 20\$ 30WF 20\$ 16V C1335 1-124-477-11 ELECT 47WF 20\$ 25V C1506 1-124-19-00 ELECT 330WF 20\$ 16V C1335 1-124-477-11 ELECT 47WF 20\$ 25V C1506 1-124-19-00 ELECT 330WF 20\$ 50V C1336 1-163-227-11 ELECT 47WF 20\$ 25V C1506 1-124-907-11 ELECT 47WF 20\$ 50V C1338 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1338 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1340 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1341 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1341 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1510 1-124-907-11 ELECT 4.7WF 20\$ 50V C1341 1-163-031-10 (ERRMIC CHIP 0.01WF 50 50V C1341 1-163-03	C1327 1-163-031- C1328 1-163-031-	1 CERAMIC CHIP 0.01MF 1 CERAMIC CHIP 0.01MF	50 50) V	ì				
C1331 1-124-477-11 ELECT 47WF 20\$ 25V C1503 1-129-907-11 ELECT 10MF 20\$ 50V C1333 1-124-477-11 ELECT 47WF 20\$ 25V C1503 1-136-165-00 FILM 20\$ 30WF 20\$ 16V C1335 1-124-477-11 ELECT 47WF 20\$ 25V C1506 1-124-19-00 ELECT 330WF 20\$ 16V C1335 1-124-477-11 ELECT 47WF 20\$ 25V C1506 1-124-19-00 ELECT 330WF 20\$ 50V C1336 1-163-227-11 ELECT 47WF 20\$ 25V C1506 1-124-907-11 ELECT 47WF 20\$ 50V C1338 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1338 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1340 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1341 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1341 1-163-031-11 (ERRMIC CHIP 0.01WF 50 50V C1510 1-124-907-11 ELECT 4.7WF 20\$ 50V C1341 1-163-031-10 (ERRMIC CHIP 0.01WF 50 50V C1341 1-163-03	C1329 1-124-907- C1330 1-163-031-	1 ELECT 10MF 1 CERAMIC CHIP 0.01MF	20% 50 50) (C1501 C1502	1-124-472-11 1-101-821-00	CERAMIC 0.0022MF	20%	500V
C1336 1-124-477-11 ELECT 47MF 20% 25V C1508 1-124-907-11 ELECT 10MF 20% 50V C1338 1-163-031-11 CERANIC CHIP 0.01MF 50V C1510 1-124-907-11 ELECT 47MF 20% 50V C1511 1-164-182-11 CERANIC CHIP 0.01MF 50V C1511 1-164-182-11 CERANIC CHIP 0.0033MF 10% 50V C1514 1-163-183-00 CERANIC CHIP 0.01MF 50V C1514 1-164-182-11 CERANIC CHIP 0.0033MF 10% 50V C1514 1-163-183-00 CERANIC CHIP 0.0035MF 5% 50V C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V C1344 1-163-113-00 CERANIC CHIP 19F 0.25PF 50V C1344 1-163-113-00 CERANIC CHIP 19F 0.25PF 50V C1344 1-163-083-00 CERANIC CHIP 19F 0.25PF 50V C1516 1-163-033-00 CERANIC CHIP 19F 0.25PF 50V C1516 1-163-03-03-00 CERANIC CHIP 19F 0.25PF 50V C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V C1346 1-124-907-11 ELECT 47MF 20% 50V C1516 1-163-03-03-00 CERANIC CHIP 20PF 5% 50V C1516 1-163-133-00 CERANIC CHIP 20PF 5% 50V C1516 1-163-03-11 ELECT 10MF 20% 50V C1516 1-163-133-00 CERANIC CHIP 20PF 5% 50V C1516 1-163-037-11 ELECT 10MF 20% 50V C1518 1-124-477-11 ELECT 47MF 20% 50V C1518 1-124-477-11 ELECT 10MF 20% 50V C1518 1-124-477-11 ELECT 47MF 20% 50V C1518 1-124-907-11 ELECT 10MF 20% 50V C1518 1-124-907-11 ELECT 10	C1331 1-124-477- C1332 1-124-477-	1 ELECT 47MF	20% 25 20% 25	5 V	C1504	1-124-907-11	ELECT 10MF	20%	50V
C1336 1-124-477-11 ELECT 47MF 20% 25V C1508 1-124-907-11 ELECT 10MF 20% 50V C1338 1-163-031-11 CERANIC CHIP 0.01MF 50V C1510 1-124-907-11 ELECT 47MF 20% 50V C1511 1-164-182-11 CERANIC CHIP 0.01MF 50V C1511 1-164-182-11 CERANIC CHIP 0.0033MF 10% 50V C1514 1-163-183-00 CERANIC CHIP 0.01MF 50V C1514 1-164-182-11 CERANIC CHIP 0.0033MF 10% 50V C1514 1-163-183-00 CERANIC CHIP 0.0035MF 5% 50V C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V C1344 1-163-113-00 CERANIC CHIP 19F 0.25PF 50V C1344 1-163-113-00 CERANIC CHIP 19F 0.25PF 50V C1344 1-163-083-00 CERANIC CHIP 19F 0.25PF 50V C1516 1-163-033-00 CERANIC CHIP 19F 0.25PF 50V C1516 1-163-03-03-00 CERANIC CHIP 19F 0.25PF 50V C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V C1346 1-124-907-11 ELECT 47MF 20% 50V C1516 1-163-03-03-00 CERANIC CHIP 20PF 5% 50V C1516 1-163-133-00 CERANIC CHIP 20PF 5% 50V C1516 1-163-03-11 ELECT 10MF 20% 50V C1516 1-163-133-00 CERANIC CHIP 20PF 5% 50V C1516 1-163-037-11 ELECT 10MF 20% 50V C1518 1-124-477-11 ELECT 47MF 20% 50V C1518 1-124-477-11 ELECT 10MF 20% 50V C1518 1-124-477-11 ELECT 47MF 20% 50V C1518 1-124-907-11 ELECT 10MF 20% 50V C1518 1-124-907-11 ELECT 10	C1333 1-124-477- C1334 1-163-227-	1 ELECT 47MF 1 CERAMIC CHIP 10PF	20% 25 0.5PF 50	SV OV	C1505 C1506	1-136-165-00 1-124-119-00	FILM 0.1MF ELECT 330MF	5% 20%	
C1340 1-163-031-11 CERAMIC CHIP 0.01HF 5% 50V C1510 1-124-927-11 ELECT 4.7MF 20% 50V C1341 1-163-031-10 CERAMIC CHIP 0.001HF 5% 50V C1511 1-164-182-11 GERAMIC CHIP 0.0033MF 5% 50V C1341 1-163-133-00 CERAMIC CHIP 0.001HF 5% 50V C1512 1-124-927-11 ELECT 4.7MF 20% 50V C1344 1-163-133-00 CERAMIC CHIP 10PF 0.25PF 50V C1346 1-124-907-11 ELECT 10MF 20% 50V C1348 1-163-132-00 CERAMIC CHIP 0.01MF 5% 50V C1351 1-124-907-11 ELECT 10MF 20% 10V C1351 1-123-00 CERAMIC CHIP 0.01MF 5% 50V C1351 1-124-907-11 ELECT 10MF 20% 10V C1351 1-12	C1335 1-124-477-	1 ELECT 47MF	20% 25	5V	: C1508	1-124-927-11	CERAMIC CHIP 0.001MF ELECT 4.7MF	5% 20%	50V
C1342 1-102-963-00 CERAMIC C 133PF 5% 50V C1341 1-130-477-00 MYLAR 0.003MF 5% 50V C1344 1-163-113-00 CERAMIC C 11P 1PF 0.25PF 50V C1344 1-163-103-03 CERAMIC C 11P 1PF 0.25PF 50V C1346 1-124-907-11 ELECT 10MF 20% 50V C1346 1-124-907-11 ELECT 10MF 20% 25V C1346 1-163-123-00 CERAMIC C 11P 0.01MF 20% 25V C1348 1-163-122-00 CERAMIC C 11P 0.01MF 20% 10V C1347 1-163-127-00 CERAMIC C 11P 0.01MF 20% 10V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 10V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 50V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 50V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 50V C1351 1-124-903-11 ELECT 1MF 20% 50V C1351 1-124-903-11 ELECT 1MF 20% 50V C1351 1-164-232-11 CERAMIC C 11P 0.01MF 50V C1351 1-163-033-11 C ERAMIC C 11P 0.01MF 50V C1352 1-163-033-00 CERAMIC C 11P 0.01MF 50V C1355 1-163-033-11 C CERAMIC C 11P 0.01MF 50V C1355 1-163-033-11 C CERAMIC C 11P 0.01MF 50V C1355 1-163-035-11 C CERAMIC C 11P 10.01MF 50V C1355 1-163-235-11 C CERAMIC C 11P 10.01MF 50V C1355 1-163-125-00 C CERAMIC C 11P 10.01MF 50V C1355 1-163-125-11 C CERAMIC C 11P 10.01MF 50V C1355 1-163-125-11 C C C C C C C C C C C C C C C C C C	C1336 1-124-477- C1338 1-163-031- C1330 1-163-031-	1 CERAMIC CHIP 0.01MF	20% 25 50	ογ)γ	1		ELECT IOMF	20%	
C1342 1-102-963-00 CERAMIC C 133PF 5% 50V C1341 1-130-477-00 MYLAR 0.003MF 5% 50V C1344 1-163-113-00 CERAMIC C 11P 1PF 0.25PF 50V C1344 1-163-103-03 CERAMIC C 11P 1PF 0.25PF 50V C1346 1-124-907-11 ELECT 10MF 20% 50V C1346 1-124-907-11 ELECT 10MF 20% 25V C1346 1-163-123-00 CERAMIC C 11P 0.01MF 20% 25V C1348 1-163-122-00 CERAMIC C 11P 0.01MF 20% 10V C1347 1-163-127-00 CERAMIC C 11P 0.01MF 20% 10V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 10V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 50V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 50V C1349 1-163-127-00 CERAMIC C 11P 0.01MF 20% 50V C1351 1-124-903-11 ELECT 1MF 20% 50V C1351 1-124-903-11 ELECT 1MF 20% 50V C1351 1-164-232-11 CERAMIC C 11P 0.01MF 50V C1351 1-163-033-11 C ERAMIC C 11P 0.01MF 50V C1352 1-163-033-00 CERAMIC C 11P 0.01MF 50V C1355 1-163-033-11 C CERAMIC C 11P 0.01MF 50V C1355 1-163-033-11 C CERAMIC C 11P 0.01MF 50V C1355 1-163-035-11 C CERAMIC C 11P 10.01MF 50V C1355 1-163-235-11 C CERAMIC C 11P 10.01MF 50V C1355 1-163-125-00 C CERAMIC C 11P 10.01MF 50V C1355 1-163-125-11 C CERAMIC C 11P 10.01MF 50V C1355 1-163-125-11 C C C C C C C C C C C C C C C C C C	C1340 1-163-031- C1341 1-163-275-	1 CERAMIC CHIP 0.01MF	50 50 57 50) V) V	C1511	1-124-927-11	CERAMIC CHIP 0.0033MF	20% 10% 20%	50V
C1343 1-163-03-03-00 CERAMIC CHIP POFF 14 20 25 50V C1346 1-124-907-11 ELECT 10MF 20 25 50V C1346 1-124-907-11 ELECT 10MF 20 20 20 10V C1347 1-163-031-11 CERAMIC CHIP 200F 52 50V C1350 1-163-233-11 CERAMIC CHIP 0.01MF 10 50V C1351 1-124-907-11 ELECT 1MF 20 25 50V C1350 1-163-233-11 CERAMIC CHIP 0.01MF 50V C1351 1-163-173-00 CERAMIC CHIP 0.01MF 50V C1351 1-163-123-00 CERAMIC CHIP 0.01MF 50V C1355 1-163-125-00 CERAMIC CHIP 20PF 52 50V C1350 1-163-233-11 CERAMIC CHIP 20PF 52 50V C1355 1-163-125-00 CERAMIC CHIP 20PF 52 50V C1356 1-163-125-00 CERAMIC CHIP 20PF 52 50V C1356 1-163-235-1 CERAMIC CHIP 20PF 52 50V C1360 1-164-163-133-00 CERAMIC CHIP 20PF 52 50V C1360 1-164-161-11 CERAMIC CHIP 30PP 52 50V C1360 1-164-161-11 CERAMIC CHIP 20PF 52 50V C1360 1-164-161-11 CERAMIC	C1342 1-102-963-	OO CERAMIC 33PF	5% 50) V	C1513	1-163-133-00	CERAMIC CHIP 470PF MYLAR 0.0033MF	5% 5%	50Y
C1347 1-163-031-11 CERAMIC CHIP 270FF 5% 50V C1348 1-163-127-00 CERAMIC CHIP 270FF 5% 50V C1349 1-163-127-00 CERAMIC CHIP 100FF 5% 50V C1350 1-164-232-11 CERAMIC CHIP 100FF 5% 50V C1351 1-163-123-01 ELECT 1MF 20% 50V C1351 1-124-903-11 ELECT 1MF 20% 50V C1351 1-163-230-11 CERAMIC CHIP 0.01MF 50V C1353 1-163-031-11 CERAMIC CHIP 0.01MF 50V C1353 1-163-031-11 CERAMIC CHIP 150FF 5% 50V C1355 1-163-125-00 CERAMIC CHIP 220FF 5% 50V C1356 1-163-235-11 CERAMIC CHIP 220FF 5% 50V C1356 1-163-235-11 CERAMIC CHIP 220FF 5% 50V C1356 1-163-2263-11 CERAMIC CHIP 220FF 5% 50V C1356 1-163-2263-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-225-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-249-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-235-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-227-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-227-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-237-11 CERAMIC CHIP 270FF 5% 50V C1360 1-163-237-11 CERAMIC CHIP 10FF 0.5PF 50V C1360 1-124-477-11 ELECT 47MF 20% 25V C1370 1-124-477	C1343 1-163-113- C1344 1-163-083-	OO CERAMIC CHIP 68PF	5% 50 0.25PF 50	OV OV					
C1347 1-163-031-11 CERAMIC CHIP 270FF 5% 50V C1348 1-163-127-00 CERAMIC CHIP 270FF 5% 50V C1349 1-163-127-00 CERAMIC CHIP 100FF 5% 50V C1350 1-164-232-11 CERAMIC CHIP 100FF 5% 50V C1351 1-163-123-01 ELECT 1MF 20% 50V C1351 1-124-903-11 ELECT 1MF 20% 50V C1351 1-163-230-11 CERAMIC CHIP 0.01MF 50V C1353 1-163-031-11 CERAMIC CHIP 0.01MF 50V C1353 1-163-031-11 CERAMIC CHIP 150FF 5% 50V C1355 1-163-125-00 CERAMIC CHIP 220FF 5% 50V C1356 1-163-235-11 CERAMIC CHIP 220FF 5% 50V C1356 1-163-235-11 CERAMIC CHIP 220FF 5% 50V C1356 1-163-2263-11 CERAMIC CHIP 220FF 5% 50V C1356 1-163-2263-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-225-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-249-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-235-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-227-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-227-11 CERAMIC CHIP 220FF 5% 50V C1360 1-163-237-11 CERAMIC CHIP 270FF 5% 50V C1360 1-163-237-11 CERAMIC CHIP 10FF 0.5PF 50V C1360 1-124-477-11 ELECT 47MF 20% 25V C1370 1-124-477	C1345 1-124-907- C1346 1-124-477-	II ELECT 10MF II ELECT 47MF	20% 50 20% 25	0V 5V	C1516 C1517	1-163-063-00 1-126-101-11	CERAMIC CHIP 0.022MF ELECT 100MF	10% 20%	107
C1350 1-164-232-11 CERAMIC CHIP 0.01MF 10% 50V CI350 1-163-023-01 CERAMIC CHIP 0.01MF 10% 50V CI351 1-124-903-11 ELECT 1MF 20% 50V CI353 1-163-031-11 CERAMIC CHIP 0.01MF 50V CI354 1-163-121-00 CERAMIC CHIP 2.01MF 50V CI355 1-163-213-10 CERAMIC CHIP 2.20PF 5% 50V CI356 1-163-235-11 CERAMIC CHIP 3.00PF 5% 50V CI356 1-163-235-11 CERAMIC CHIP 3.00PF 5% 50V CI356 1-163-235-11 CERAMIC CHIP 3.00PF 5% 50V CI356 1-163-235-11 CERAMIC CHIP 2.20PF 5% 50V CI356 1-163-237-11 CERAMIC CHIP 2.20PF 5% 50V CI356 1-163-10-00 CERAMIC CHIP 2.20PF 5% 50V CI356 1-163-10-10 CERAMIC CHIP 2.20PF 5% 50V C	C1347 1-163-031-	11 CERAMIC CHIP 0.01MF	50 57 50	0 V	C1518	1-163-037-11	CERAMIC CHIP 0.022MF	20% 10%	25V
C1352 1-163-023-00 CERAMIC CHIP 0.015MF 10% 50V CN102 1-1564-516-11 PLUG, CONNECTOR 11P C1353 1-163-031-11 CERAMIC CHIP 10.01MF 50V CN104 1-564-506-11 PLUG, CONNECTOR 3P CN201 1-1564-510-11 PLUG, CONNECTOR 3P CN201 1-1564-510-11 PLUG, CONNECTOR 3P CN201 1-1564-506-11 PLUG, CONNECTOR 3P CN201 1-1564-510-11 PLUG, CONNECTOR 3P CN201 1-1564-510-11 PLUG, CONNECTOR 1P CN202 1-1564-510-11 PLUG, CONNECTOR 1P CN302 1-1564-510-11 PLUG, CONNECTOR P CN305 1-1564-510-11 PLUG, CONN	C1349 1-163-117- C1350 1-164-232-	O CERAMIC CHIP 100PF 11 CERAMIC CHIP 0.01MF	5% 50 10% 50	ÖV OV	0.52			3%	301
C1353 1-163-031-11 CERAMIC CHIP 0.01MF 5% 50V CN104 *1-564-506-11 PLUG, CONNECTOR 3P CN1355 1-163-125-00 CERAMIC CHIP 22PF 5% 50V CN105 *1-565-505-31 CONNECTOR 3P CN1355 1-163-125-01 CERAMIC CHIP 22PF 5% 50V CN105 *1-564-506-11 PLUG, CONNECTOR 3P CN301 *1-564-506-11 PLUG, CONNECTOR 3P CN302 *1-564-506-11 PLUG, CONNECTOR 3P CN302 *1-564-506-11 PLUG, CONNECTOR 1P CN302 *1-564-516-11 PLUG, CONNECTOR 1P CN304 *1-564-509-11 PLUG, CONNECTOR 6P CN304 *1-564-509-11 PLUG, CONNECTOR 6P CN304 *1-564-509-11 PLUG, CONNECTOR 6P CN304 *1-564-509-11 PLUG, CONNECTOR 8P CN304 *1-564-515-11 PLUG, CONNECTOR 8P CN305 *1-565-504-11 PLUG, CONNECTOR 8P CN305 *1-565-504-11 PLUG, CONNECTOR 8P CN305 *1-565-504-11 PLUG, CONNECTOR 9P CN306 *1-564-506-11 PLUG, CONNECTOR 9P CN306 *1-564-506-11 PLUG, CONNECTOR 3P CN307 *1-535-419-00 TAB, FASTEN (PCB) CN307 *1-535-419-00 TAB,	C1351 1-124-903-	II ELECT IMF	20% 50		CN101			RD 11P	
C1357 1-124-119-00 ELECT 330MF 20% 16V CN301 *1-564-516-11 PLUG, CONNECTOR 7P C1358 1-124-477-11 ELECT 47MF 20% 25V CN304 *1-564-515-11 PLUG, CONNECTOR 7P C1360 1-163-263-11 CERAMIC CHIP 330PF 5% 50V CN304 *1-564-515-11 PLUG, CONNECTOR 6P C1360 1-163-249-11 CERAMIC CHIP 82PF 5% 50V CN304 *1-564-519-11 CONNECTOR, BOARD 13P C1362 1-163-235-11 CERAMIC CHIP 22PF 5% 50V CN304 *1-564-515-11 PLUG, CONNECTOR 8P CN305 *1-564-515-11 PLUG, CONNECTOR 8P CN306 *1-564-515-11 PLUG, CONNECTOR 8P CN306 *1-564-515-11 PLUG, CONNECTOR 8P CN306 *1-564-515-11 PLUG, CONNECTOR PIN (DY) 6P CN306 *1-564-515-11 PLUG, CONNECTOR PIN (DY) 6P CN306 *1-564-515-11 PLUG, CONNECTOR PIN (DY) 6P CN306 *1-564-506-11 PL	C1352 1-163-023- C1353 1-163-031-	OO CERAMIC CHIP 0.015MF 11 CERAMIC CHIP 0.01MF	10% 50	0٧	CN102	*1-564-514-11 *1-564-506-11	PLUG, CONNECTOR 11P PLUG, CONNECTOR 3P	N + 0 D	
C1357 1-124-119-00 ELECT 330MF 20% 16V CN301 *1-564-516-11 PLUG, CONNECTOR 7P C1358 1-124-477-11 ELECT 47MF 20% 25V CN304 *1-564-515-11 PLUG, CONNECTOR 7P C1360 1-163-263-11 CERAMIC CHIP 330PF 5% 50V CN304 *1-564-515-11 PLUG, CONNECTOR 6P C1360 1-163-249-11 CERAMIC CHIP 82PF 5% 50V CN304 *1-564-519-11 CONNECTOR, BOARD 13P C1362 1-163-235-11 CERAMIC CHIP 22PF 5% 50V CN304 *1-564-515-11 PLUG, CONNECTOR 8P CN305 *1-564-515-11 PLUG, CONNECTOR 8P CN306 *1-564-515-11 PLUG, CONNECTOR 8P CN306 *1-564-515-11 PLUG, CONNECTOR 8P CN306 *1-564-515-11 PLUG, CONNECTOR PIN (DY) 6P CN306 *1-564-515-11 PLUG, CONNECTOR PIN (DY) 6P CN306 *1-564-515-11 PLUG, CONNECTOR PIN (DY) 6P CN306 *1-564-506-11 PL	C1355 1-163-121- C1356 1-163-235-	OO CERAMIC CHIP 150PF OO CERAMIC CHIP 220PF	5% 50 5% 50	0٧	CN201	*1-564-506-11	PLUG, CONNECTOR 3P	RD 12P	
C1363 1-163-235-11 CERAMIC CHIP 22PF 5% 50V CN401 *1-564-515-11 PLUG. CONNECTOR 12P C1364 1-163-133-00 CERAMIC CHIP 470PF 5% 50V CN501 *1-580-798-11 CUNNECTOR PIN (DY) 6P C1365 1-163-227-11 CERAMIC CHIP 10PF 0.5PF 50V CN501 *1-580-798-11 CONNECTOR PIN (DY) 6P C1366 1-124-477-11 ELECT 47MF 20% 25V CN503 *1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P C1367 1-124-477-11 ELECT 47MF 20% 25V CN503 *1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P C1369 1-163-237-11 CERAMIC CHIP 27PF 5% 50V CN505 *1-564-506-11 PLUG, CONNECTOR 3P C1370 1-163-237-11 CERAMIC CHIP 27PF 5% 50V CN506 *1-564-506-11 PLUG, CONNECTOR 3P C1373 1-124-477-11 ELECT 47MF 20% 25V CN506 *1-564-506-11 PLUG, CONNECTOR 3P C1373 1-124-477-11 ELECT 47MF 20% 25V CN506 *1-535-419-00 TAB, FASTEN (PCB) CN507 *1-535-419-00 TAB, FASTEN (PCB) C					CN301 CN302	*1-564-514-11 *1-564-510-11	PLUG, CONNECTOR 11P PLUG, CONNECTOR 7P		
C1363 1-163-235-11 CERAMIC CHIP 22PF 5% 50V CN401 *1-564-515-11 PLUG. CONNECTOR 12P C1364 1-163-133-00 CERAMIC CHIP 470PF 5% 50V CN501 *1-580-798-11 CUNNECTOR PIN (DY) 6P C1365 1-163-227-11 CERAMIC CHIP 10PF 0.5PF 50V CN501 *1-580-798-11 CONNECTOR PIN (DY) 6P C1366 1-124-477-11 ELECT 47MF 20% 25V CN503 *1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P C1367 1-124-477-11 ELECT 47MF 20% 25V CN503 *1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P C1369 1-163-237-11 CERAMIC CHIP 27PF 5% 50V CN505 *1-564-506-11 PLUG, CONNECTOR 3P C1370 1-163-237-11 CERAMIC CHIP 27PF 5% 50V CN506 *1-564-506-11 PLUG, CONNECTOR 3P C1373 1-124-477-11 ELECT 47MF 20% 25V CN506 *1-564-506-11 PLUG, CONNECTOR 3P C1373 1-124-477-11 ELECT 47MF 20% 25V CN506 *1-535-419-00 TAB, FASTEN (PCB) CN507 *1-535-419-00 TAB, FASTEN (PCB) C	C1358 1-124-477- C1359 1-163-263-	11 ELECT 47MF 11 CERAMIC CHIP 33OPF	20% 25 5% 50	5 V O V	CN303	*1-564-515-11 *1-564-509-11	PLUG, CONNECTOR 12P PLUG CONNECTOR 6P		
C1363 1-163-235-11 CERAMIC CHIP 22PF 5% 50V CN401 *1-564-515-11 PLUG. CONNECTOR 12P C1364 1-163-133-00 CERAMIC CHIP 470PF 5% 50V CN501 *1-580-798-11 CUNNECTOR PIN (DY) 6P C1365 1-163-227-11 CERAMIC CHIP 10PF 0.5PF 50V CN501 *1-580-798-11 CONNECTOR PIN (DY) 6P C1366 1-124-477-11 ELECT 47MF 20% 25V CN503 *1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P C1367 1-124-477-11 ELECT 47MF 20% 25V CN503 *1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P C1369 1-163-237-11 CERAMIC CHIP 27PF 5% 50V CN505 *1-564-506-11 PLUG, CONNECTOR 3P C1370 1-163-237-11 CERAMIC CHIP 27PF 5% 50V CN506 *1-564-506-11 PLUG, CONNECTOR 3P C1373 1-124-477-11 ELECT 47MF 20% 25V CN506 *1-564-506-11 PLUG, CONNECTOR 3P C1373 1-124-477-11 ELECT 47MF 20% 25V CN506 *1-535-419-00 TAB, FASTEN (PCB) CN507 *1-535-419-00 TAB, FASTEN (PCB) C	C1360 1-164-161- C1362 1-163-249-	11 CERAMIC CHIP 0.0022MF 11 CERAMIC CHIP 82PF	10% 50 5% 50	0 A 0 A	1			RD 13P	
C1365 1-163-227-11 CERAMIC CHIP 10PF	C1363 1-163-235-	11 CERAMIC CHIP 22PF	5% 50		CN402	*1-564-515-11	PLUG, CONNECTOR 12P		
C1367 1-124-477-11 ELECT 47MF 20% 25V C1369 1-163-237-11 CERAMIC CHIP 27PF 5% 50V C1370 1-163-237-11 CERAMIC CHIP 27PF 5% 50V C1372 1-124-477-11 ELECT 47MF 20% 25V C1373 1-124-477-11 ELECT 47MF 20% 25V C1374 1-124-477-11 ELECT 47MF 20% 25V C1375 1-124-477-11 ELECT 47MF 20% 25V C1376 1-163-097-00 CERAMIC CHIP 15PF 5% 50V C1378 1-163-097-00 CERAMIC CHIP 15PF 5% 50V C1380 1-163-101-00 CERAMIC CHIP 22PF 5% 50V C1381 1-163-101-00 CERAMIC CHIP 22PF 5% 50V C1382 1-124-443-00 ELECT 100MF 20% 10V CP300 1-236-366-11 MODULE, TRAP C1382 1-124-443-00 ELECT 100MF 20% 10V CP301 1-236-365-11 MODULE CP303 1-466-162-61 FILTER BLOCK, COM (CFB-4)	C1365 1-163-227-	11 CERAMIC CHIP 10PF	0.5PF 51	01	CN502	*1-573-964-11	PIN, CONNECTOR (PC BOAR	D) 6P	
C1370 1-163-237-11 CERAMIC CHIP 27PF 5% 50V CN506 *1-564-506-11 PLUG, CONNECTOR 3P C1372 1-124-477-11 ELECT 47MF 20% 25V C1373 1-124-477-11 ELECT 47MF 20% 25V C1374 1-124-477-11 ELECT 47MF 20% 25V C1375 1-124-927-11 ELECT 47MF 20% 25V C1378 1-163-097-00 CERAMIC CHIP 15PF 5% 50V CP300 1-236-366-11 MODULE, TRAP C1380 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP301 1-236-365-11 MODULE, TRAP C1381 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP302 1-808-654-21 MODULE CP303 1-466-162-61 FILTER BLOCK, COM (CFB-4)	C1367 1-124-477-	11 ELECT 47MF	20% 2	ŠΫ				<i>o</i> , o.	
C1373 1-124-477-11 ELECT 47MF 20% 25V 25V C1374 1-124-477-11 ELECT 47MF 20% 25V C1375 1-124-927-11 ELECT 4.7MF 20% 50V C1378 1-163-097-00 CERAMIC CHIP 15PF 5% 50V CP300 1-236-366-11 MODULE, TRAP C1380 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP301 1-236-365-11 MODULE, TRAP C1381 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP301 1-236-365-11 MODULE, TRAP C1381 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP302 1-808-654-21 MODULE C1382 1-124-443-00 ELECT 100MF 20% 10V CP303 1-466-162-61 FILTER BLOCK, COM (CFB-4)	C1370 1-163-237-	11 CERAMIC CHIP 27PF	5% . 5	0 V	CN506	*1-564-506-11	PLUG, CONNECTOR 3P		
C1375 1-124-927-11 ELECT 4.7MF 20% 50V C1378 1-163-097-00 CERAMIC CHIP 15PF 5% 50V CP300 1-236-366-11 MODULE, TRAP C1380 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP301 1-236-365-11 MODULE, TRAP C1381 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP302 1-808-654-21 MODULE C1382 1-124-443-00 ELECT 100MF 20% 10V CP303 1-466-162-61 FILTER BLOCK, COM (CFB-4)	C1373 1-124-477-	11 ELECT 47MF	20% 2	5V	LNSU7	*1-535-419-00	TAB, FASTEN (PCB)		
C1378 1-163-097-00 CERAMIC CHIP 15PF 5% 50V CP300 1-236-366-11 MODULE, TRAP C1380 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP301 1-236-365-11 MODULE, TRAP C1381 1-163-101-00 CERAMIC CHIP 22PF 5% 50V CP302 1-808-654-21 MODULE CP302 1-124-443-00 ELECT 100MF 20% 10V CP303 1-466-162-61 FILTER BLOCK, COM (CFB-4)	C1375 1-124-927-		20% 5		1	<001	MPOSITION CIRCUIT BLOCK>		
C1382 1-124-443-00 ELECT 100MF 20% 10V CP303 1-466-162-61 FILTER BLOCK, COM (CFB-4)	C1378 1-163-097- C1380 1-163-101-	OO CERAMIC CHIP 15PF OO CERAMIC CHIP 22PF	5% 5 5% 5	0V 0V	CP301	1-236-365-11	MODULE, TRAP		
C1383 1-124-477-11 FIECT 47MF 207 25V	C1381 1-163-101- C1382 1-124-443-		5% 5 20% 1				MODULE	4)	
C1384 1-163-038-00 CERAMIC CHIP 0.1MF 25V <diode></diode>	C1383 1-124-477- C1384 1-163-038	11 ELECT 47MF 00 CERAMIC CHIP 0.1MF	20% 2	.5V .5V		<0.11	IDF>		
C1385 1-163-031-11 CERAMIC CHIP 0.01MF 50V D101 8-719-800-76 D10DE 1SS226	C1385 1-163-031	11 CERAMIC CHIP 0.01MF	5	OV	D101				

					L			
	PART NO.	DESCRIPTION	REMARK		PART NO.	DESCRIPTION		REMARK
D102 D103 D104 D105 D107	8+719-800-76	D10DE 1SS226 D10DE 1SV230TPH3 D10DE 1SS226 D10DE 1SS226 D10DE 1SS226		D405 D406 D407 D408 D410	8-719-801-78 8-719-404-46 8-719-404-46 8-719-404-46 8-719-404-46	DIODE MAILO DIODE MAILO DIODE MAILO		
D109 D110 D112 D113 D114	8-719-801-78 8-719-404-46 8-719-404-46 8-719-158-07 8-719-404-46	DIODE 1SS184 DIODE MA110 DIODE MA110 DIODE RD4.7SB DIODE MA110		D411 D414 D415 D416 D417	8-719-404-46 8-719-801-78 8-719-801-78 8-719-801-78	DIODE MA110		
D200 D300 D301 D302 D303	8-719-025-07 8-719-404-46 8-719-158-07 8-719-977-05	DIODE DT713C DIODE 1SV232-TPH3 DIODE MA110 DIODE RD4.7SB DIODE DT26.2		D418 D421 D422 D423	8-719-801-78 8-719-404-46 8-719-404-46 8-719-800-76	DIODE JSS184 DIODE MAIIO DIODE MAIIO DIODE 1SS226		
D304 D305 D306 D307 D309	8-719-800-76 8-719-104-34 8-719-404-46 8-719-404-46	DIODE 1SS184 DIODE 1SS226 DIODE 1S2836 DIODE MA110 DIODE MA110		D424 D425 D426 D427 D500 D501	8-719-158-07 8-719-404-46 8-719-404-46	DIODE RD4.7SB DIODE MAI10		·
D310 D311 D313 D314 D315	8-719-801-78 8-719-404-46 8-719-404-46	DIODE MA110		D502 D503 D504 D505 D506	8-719-979-80 8-719-404-46 8-719-901-83	DIODE UF5406	EL-6433 S	
D317 D318 D319 D320 D322	8-719-800-76 8-719-404-46 8-719-404-46	DIODE 158226 DIODE MAIIO DIODE MAIIO		D507 D508 D509 D510 D512	8-719-800-76 8-719-800-76 8-719-404-46 8-719-302-43 8-719-979-80	DIODE 1SS226 DIODE 1SS226 DIODE MAI10 DIODE EL1Z		
D323 D324 D325 D326 D327	8-719-801-78 8-719-045-70	DIODE MA110 DIODE 1SV230TPH3 DIODE 1SS184 DIODE 1SV230TPH3 DIODE 1S2836		D513 D514 D515 D516	8-719-404-46	DIODE MAIIO DIODE ERC38-06 DIODE ERC38-06 DIODE MAIIO		
D332 D333 D335 D336 D337	8-719-404-46 8-719-404-46	DIODE MA110 DIODE MA110 DIODE MA110 DIODE MA110 DIODE MA110		D517 D518 D519 D520 D521	8-719-404-46 8-719-404-46	DIODE MA110		
D338 D339 D341 D344 D345	8-719-404-46 8-719-158-07 8-719-801-78	DIODE MA110 DIODE MA110 DIODE RD4.7SB DIODE 1SS184 DIODE 1S2836		D522 D523 D524 D525 D526	8-719-404-46 8-719-200-02 8-719-200-02 8-719-404-46	DIODE MAILO DIODE 10E-2 DIODE 10E-2 DIODE MAILO		
D346 D347 D348 D349 D350	8-719-104-34 8-719-104-34 8-719-800-76 8-719-800-76 8-719-800-76	DIODE 152836 DIODE 155226 DIODE 155226		D527 D528 D529 D530 D531	8-719-200-02 8-719-300-76 8-719-200-02 8-719-300-76 8-719-977-32	DIODE RH-1A DIODE 10E-2 DIODE RH-1A DIODE DTZ11B		
D351 D352 D353 D354 D355	8-719-800-76 8-719-800-76 8-719-800-76 8-719-800-76 8-719-800-76	DIODE 1SS226 DIODE 1SS226 DIODE 1SS226		D532 D533 D534 D535 D536	8-719-800-76 8-719-302-43 8-719-404-46 8-719-404-46 8-719-800-76	DIODE EL1Z DIODE MAI10 DIODE MAI10 DIODE 1SS226		
D360 D361 D362 D363 D364	8-719-104-34 8-719-104-34 8-719-158-40 8-719-158-40 8-719-104-34	DIODE 1S2836 DIODE RD1OSB1 DIODE RD1OSB1		D537 D538 D539 D540 D541	8-719-800-76 8-719-800-76 8-719-404-46 8-719-404-46 8-719-801-78	DIODE 1SS184		
D365 D381 D401 D404	8-719-404-46 8-719-404-46 8-719-404-46 8-719-800-76	DIODE MA110 DIODE MA110		D542		DIODE 188133 LAY LINE> DELAY LINE, Y		

Les composants identifies par une trame et une marque Δ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark △ are critical for safety.
Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
DL301 DL401	1-415-632-11 1-409-547-11	DELAY LINE, Y DELAY LINE		10506	8-759-009-51	IC MC14538BF	
	<\$11.3	TFR>		1C507 1C508	8-759-100-60 8-752-053-21 8-759-998-98	IC CXA1211M	
FL300 FL401	1-236-547-11	TRAP, LC		10510	8-759-998-98 8-759-009-51	IC MC14538BF	
FL401	1-230-304-11	FILIER, BAND PASS			<c011< td=""><td>L></td><td></td></c011<>	L>	
I C 1 0 1	<[C>	IC 11DD70013VCH~V03		L101 L102 L104	1-408-609-41 1-408-417-00 1-410-478-11	INDUCTOR INDUCTOR	33UH 47UH
I C 102 I C 103 I C 104 I C 105	8-759-168-37 8-759-008-48 8-759-262-59 8-759-196-70	DESCRIPTION DELAY LINE, Y DELAY LINE TER> TRAP, LC FILTER, BAND PASS IC UPD78013YCW-Y03 IC ST24C01B1 IC MC74HC86F IC UPD6451AGT-632-E2 IC M62358FP-E1 IC MC14094BF IC AN5265 IC CXA1211M IC LM358D IC CXA1211M IC LM358D IC CXA1214P IC XRU4053BF-E2 IC M51279FP IC NJM2245M IC NJM2245M IC XRU4053BF-E2 IC MM1149XF IC MM149XF IC M		L105 L300	1-410-482-31 1-410-478-11	INDUCTOR INDUCTOR INDUCTOR	47UH 100UH 47UH
I C 106	8-759-196-70	IC M62358FP-E1		L301 L302 L303	1-408-411-00 1-412-008-31 1-408-416-00	INDUCTOR INDUCTOR CHIP INDUCTOR	150H 150H 390H
I C107 I C108 I C109	8-759-196-70 8-759-042-02 8-759-196-70	1C M62358FP-E1 1C S-80743AL-A7-S 1C M62358FP-E1		L304 L305	1-412-008-31 1-410-196-11	INDUCTOR CHIP	15UH 2.2UH
I C110	8-759-196-70	IC MC14094BF		L306 L307 L308		INDUCTOR INDUCTOR INDUCTOR	39NH 15UH 4.7UH
I C200 I C301 I C302	8-759-420-04 8-752-053-21 8-759-998-98	IC AN5265 IC CXA1211M IC LM358D		L309 L311	1-410-470-11 1-410-470-11	INDUCTOR INDUCTOR	100H
I C303	8-752-056-67	IC CXA1214P		L312 L314	1-412-011-31	INDUCTOR CHIP	27UH 27UH
I C305 I C306	8-759-631-08 8-759-711-32	IC M51279FP IC NJM2245M		L316 L317 L319	1-412-011-31 1-410-090-41 1-408-421-00	INDUCTOR CHIP INDUCTOR INDUCTOR	27UH 18MMH 100UH
1 C309 1 C310	8-759-711-32 8-759-509-19	1C NJM2245M 1C XRU4053BF-E2		L320 L401	1-410-478-11 1-410-478-11	INDUCTOR INDUCTOR	47UH 47UH
I C311 I C312 I C313	8-759-509-05 8-759-711-32 8-759-501-21	IC XRU4066BF IC NJM2245M IC MM1149YF		L402 L403 L404	1-410-216-31 1-410-216-31	INDUCTOR CHIP INDUCTOR CHIP INDUCTOR CHIP	100UH 100UH 100UH
I C314 I C315	8-759-501-21 8-759-509-19	IC MM1149XF IC XRU4053BF-E2		L405	1-408-419-00	INDUCTOR	68UH
I C316 I C317	8-759-048-09 8-759-009-51	IC MM1148XF IC MC14538BF		L406 L407 L408	1-408-419-00 1-408-413-00 1-408-413-00	INDUCTOR INDUCTOR INDUCTOR	68UH 22UH 22UH
I C318 I C320	8-759-509-57 8-759-501-21 8-759-501-21	IC XRU4584BF IC MM1149XF		L409 L500	1-410-214-31	INDUCTOR CHIP COIL (WITH COR	68UII
I C322	8-759-501-21	IC MM1149XF		L501 L502	1-407-365-00 1-407-365-00	COLL, CHOKE	
I C323 I C324 I C325	8-759-501-21 8-759-501-21 8-759-501-21	IC MM1149XF IC MM1149XF IC MM1149XF		L503 L504	1-410-093-11 1-410-666-31	INDUCTOR INDUCTOR	33MMH 18UH
I C326	8-759-998-96 8-759-100-96	IC LM324D		L505 L507 L508	1-410-671-31 1-410-686-11 1-412-530-31	INDUCTOR INDUCTOR INDUCTOR	47UH 1MMH 27UH
I C401 I C402	8-759-196-69 8-752-053-21	IC BA7655AF-E2 IC CXAL211M		L509 L511	1-459-075-00		27UH CONVERSION CHOKE E
1 0404	6-192-092-02	IC XRU4066BF IC CXA1478S		L512 A	1-459-155-00 1-412-447-11	COIL (WITH COR	E) 45UH 3.9MMH
I C405 I C406 I C407	8-759-509-19 8-759-998-98 8-759-509-05	IC XRU4053BF-E2 IC LM358D IC XRU4066BF		L514 L515	1-459-104-00 1-459-059-00	COIL, DUST COR	E E
I C408	8-759-509-91 8-759-998-96	IC XRA10393F		;	1-412-547-21	COIL, HORIZONT INDUCTOR	AL LINEARITY 680UH
I C411	8-759-932-64 8-759-008-92	IC BU4052BF IC MC14024BF			< NF 0	N LAMP>	
I C412 I C413		1C XRU4053BF-E2 1C XRU4053BF-E2		NL.500	1-519-526-11		
I C502 I C503	8-759-009-51	IC MC14538BF				NSISTOR:	
l C504 l C505		IC XXA1211M IC XRA17812T		Q101 Q102	8-729-901-01 8-729-216-22	TRANSISTOR DTC TRANSISTOR 25A	144EK 1162-G

REF.NO. F	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
Q103 8 Q104 8 Q105 8 Q107 8 Q108 8	3-729-216-22 3-729-907-26 3-729-901-06 3-729-901-06 3-729-120-28	TRANSISTOR 2SA1162-G TRANSISTOR DTA144EK TRANSISTOR DTA144EK TRANSISTOR DTA144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G		Q354 Q355 Q356 Q357	8-729-120-28 8-729-120-28 8-729-901-01 8-729-120-28 8-729-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6	
Q109 8 Q110 8 Q111 8 Q112 8 Q113 8	3-729-120-28 8-729-120-28 8-729-901-06 8-729-120-28 8-729-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTA144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		Q359 Q360 Q361 Q362 Q363	8-729-216-22 8-729-907-26 8-729-901-06 8-729-120-28 8-729-120-28	TRANSISTOR 2SA1162-G TRANSISTOR 1MX1 TRANSISTOR DTA144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6	
Q114 Q200 Q201 Q300 Q301	8-729-119-78 8-729-140-96 8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR 2SC2785-HFE TRANSISTOR 2SD774-34 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		Q364 Q365 Q366 Q367 Q368	8-729-901-01 8-729-901-01 8-729-216-22 8-729-216-22 8-729-216-22	TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G	
Q302 Q303 Q304 Q305 Q306	8-729-216-22 8-729-120-28 8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		Q369 Q372 Q376 Q377 Q378	8-729-901-01 8-729-901-01 8-729-901-01 8-729-901-06 8-729-901-06	TRANSISTOR DTA144EK TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR DTA144EK	
Q307 Q308 Q309 Q310 Q311	8-729-120-28 8-729-120-28 8-729-216-22 8-729-216-22 8-729-216-22	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G		Q401 Q402 Q403 Q404 Q405	8-729-120-28 8-729-120-28 8-729-901-01 8-729-216-22 8-729-216-22	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC144EK TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G	
Q312 Q313 Q314 Q315 Q316	8-729-120-28 8-729-216-22 8-729-901-06 8-729-216-22 8-729-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR DTA144EK TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6		Q406 Q407 Q408 Q409 Q410	8-729-120-28 8-729-120-28 8-729-216-22 8-729-216-22 8-729-907-26	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR IMX1	
Q319 Q320 Q321 Q322	8-729-216-22 8-729-120-28 8-729-119-78 8-729-120-28 8-729-120-28	TRANSISTOR 2SC11623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		Q411 Q412 Q413 Q414 Q415	8-729-120-28 8-729-216-22 8-729-141-53 8-729-216-22 8-729-216-22	TRANSISTOR 2SC1623-L5C6 TRANSISTOR 2SA1162-G TRANSISTOR 2SK94-X2X3X4 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G	
Q324 Q325 Q326 Q327	8-729-901-01 8-729-901-01 8-729-120-28 8-729-120-28 8-729-216-22	TRANSISTOR DTC144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G		Q417 Q418 Q419 Q420	8-729-216-22 8-729-120-28 8-729-216-22 8-729-216-22 8-729-216-22	TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G	
Q328 Q329 Q330 Q331 Q332	8-729-141-53 8-729-141-53 8-729-216-22 8-729-216-22 8-729-901-01	TRANSISTOR 25K94-X2X3X4 TRANSISTOR 25K94-X2X3X4 TRANSISTOR 25A1162-G TRANSISTOR DTC144EK		Q422 Q423 Q424 Q425	8-729-120-28 8-729-120-28 8-729-120-28 8-729-901-01 8-729-901-01	TRANSISTUR DTC144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC144EK TRANSISTOR DTC144EK	
Q 337	8-729-120-28	TRANSISTOR 2SC1623-L5L6		Q430 Q431	8-729-120-28 8-729-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6	
Q338 Q339 Q341 Q342 Q343	8-729-216-22 8-729-920-39 8-729-920-39 8-729-920-39	TRANSISTOR IMTIUS TRANSISTOR IMTIUS TRANSISTOR IMTIUS		Q432 Q433 Q434 Q435 Q436	8-729-120-28 8-729-901-01 8-729-120-28 8-729-901-01 8-729-901-01	TRANSISTOR DTC144EK TRANSISTOR 25C1623-L5L6 TRANSISTOR DTC144EK TRANSISTOR DTC144EK	
Q345 Q346 Q347 Q348 Q349	8-729-120-28 8-729-120-28 8-729-901-01 8-729-216-22 8-729-216-22	TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC144EK TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G		Q437 Q438 Q439 Q440 Q441	8-729-901-01 8-729-120-28 8-729-216-22 8-729-120-28 8-729-141-53	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SK94-X2X3X4	
Q350 Q351 Q352 Q353		TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		Q442 Q443 Q444	8-729-120-28 8-729-216-22 8-729-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G	

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
Q445 Q500 Q501 Q502 Q503	8-729-901-01 8-729-216-22 8-729-800-35 8-729-119-80 8-729-313-42	TRANSISTOR DTC1 TRANSISTOR 2SA1 TRANSISTOR 2SD1 TRANSISTOR 2SC2 TRANSISTOR 2SD1	44EK 162-G 397-CA 688-LK 134-C			R134 R135 R136 R137	1-216-065-00 1-216-085-00 1-216-295-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 33K 0 4.7K		1/10W 1/10W 1/10W 1/10W
Q505 Q506 Q507 Q508 Q509	8-729-120-28 8-729-120-28 8-729-120-28 8-729-216-22 8-729-901-06	TRANSISTOR 2SCI TRANSISTOR 2SCI TRANSISTOR 2SCI TRANSISTOR 2SAI TRANSISTOR DTAI	623-L5L6 623-L5L6 623-L5L6 162-G 44EK			R138 R139 R140 R141 R142	1-216-295-00 1-216-295-00 1-216-033-00 1-216-085-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE		5%	1/10W 1/10W 1/10W 1/10W 1/10W
Q510 Q511 Q512 Q513 Q514 Q515	8-729-120-28 8-729-195-82 8-729-122-03 8-729-901-00	TRANSISTOR DICT TRANSISTOR 2SCI TRANSISTOR 2SCI TRANSISTOR DTCI	623-L5L6 958-L 220A-P 24EK			R144 R145 R147 R148	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W 1/10W
Q515 Q517 Q518 Q519 Q520	8-729-169-02 8-729-901-06 8-729-901-01 8-729-901-01 8-729-905-67	TRANSISTOR 2SC2 TRANSISTOR DTAI TRANSISTOR DTC: TRANSISTOR DTC: TRANSISTOR 2SD:	2690A-Q 144EK 144EK 144EK 1944-K			R149 R150 R151 R152 R153	1-216-065-00 1-216-295-00 1-216-061-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W 1/10W
Q520 Q522 Q523 Q524 Q525 Q526	8-729-120-28 8-729-120-28 8-729-119-78 8-729-119-76 8-729-216-22	TRANSISTOR 2SCI TRANSISTOR 2SCI TRANSISTOR 2SCI TRANSISTOR 2SAI TRANSISTOR 2SAI	1623-L5L6 1623-L5L6 2785-HFE 1175-HFE			R154 R155 R156 R157 R158	1-216-065-00 1-249-434-11 1-216-295-00 1-216-065-00 1-216-295-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 27K 0 4.7K 0	5% 5%	1/10W 1/4W 1/10W 1/10W 1/10W
Q526 Q527	8-729-120-28 <res< td=""><td>TRANSISTOR 2SC</td><td>1623-L5L6</td><td></td><td></td><td>R159 R160 R162 R163 R164</td><td>1-216-063-00 1-216-061-00 1-216-065-00 1-216-065-00 1-216-067-00</td><td>METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</td><td>3.9K 3.3K 4.7K 4.7K 5.6K</td><td>5% 5% 5% 5%</td><td>1/10W 1/10W 1/10W 1/10W 1/10W</td></res<>	TRANSISTOR 2SC	1623-L5L6			R159 R160 R162 R163 R164	1-216-063-00 1-216-061-00 1-216-065-00 1-216-065-00 1-216-067-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.9K 3.3K 4.7K 4.7K 5.6K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
JR122 JR123 JR302 R101 R102	1-216-295-00 1-216-295-00 1-216-295-00 1-216-025-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 100 5% 100 5%	1/10W 1/10W 1/10W 1/10W 1/10W) 	R165 R167 R168 R169	1-216-295-00 1-216-061-00 1-216-085-00 1-216-107-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 3.3K 33K 270K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
R103 R104 R105 R106 R107	1-216-025-00 1-216-073-00 1-216-059-00 1-216-065-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 5% 10K 5% 2.7K 5% 4.7K 5% 4.7K 5%	1/10W 1/10W 1/10W 1/10W 1/10W)))	R171 R172 R173 R174	1-216-031-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W
R108 R109 R110 R111 R112	1-216-065-00 1-216-065-00 1-216-073-00 1-216-295-00 1-216-295-00	DESCRIPTION TRANSISTOR DTC1 TRANSISTOR 2SA1 TRANSISTOR 2SC1 TRANSISTOR 2SC2 TRANSISTOR 2SC1 TRANSISTOR 2SC1 TRANSISTOR 2SC1 TRANSISTOR 2SC1 TRANSISTOR 2SC1 TRANSISTOR 2SC1 TRANSISTOR DTC1 TRANSISTOR 2SC1 TRANSISTOR 2SC2 TRANSISTOR DTC1 TRANSISTOR 2SC2 TRANSISTOR 2SC1 TRANSISTOR 2SC2 T	4.7K 5% 4.7K 5% 10K 5% 0 5% 0 5%	1/10V 1/10V 1/10V 1/10V 1/10V	6 6 6	R177 R180 R181 R183	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W 1/10W 1/10W
R113 R114 R115 R116 R117	1-216-085-00 1-216-295-00 1-216-295-00 1-218-761-11 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	33K 5% 0 5% 0 5% 240K 0.4 47K 5%	1/100 1/100 1/100 1/100 1/100 1/100	ტ ტ ტ ტ	R185 R186 R187 R188 R188	1-216-073-00 1-216-295-00 1-216-061-00 1-216-295-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W 1/10W 1/10W
R118 R119 R120 R121 R122	1-216-295-00 1-216-689-11 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 39K 5% 0 5% 0 5% 0 5%	1/10/ 1/10/ 1/10/ 1/10/ 1/10/	r) r) r)	R190 R192 R193 R194 R195	1-216-049-00 1-216-073-00 1-216-295-00 1-216-295-00 1-216-071-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1 K 10 K 0 0 8.2 K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
R123 R124 R125 R126 R127	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10/ 1/10/ 1/10/ 1/10/ 1/10/) 년 년	R197 R198 R199 R200 R201	1-216-061-00 1-216-295-00 1-216-295-00 1-216-684-11 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	3.3K 0 0 24K 1K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
R128 R129 R130 R131 R132	1-216-295-00 1-216-295-00 1-216-099-00 1-216-295-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 120K 5% 0 5% 4.7K 5%	1/10/ 1/10/ 1/10/ 1/10/ 1/10/	ki W	R202 R203 R204 R205 R206	1-212-857-00 1-260-095-11 1-260-072-11 1-216-647-11 1-216-073-00	FUSIBLE CARBON CARBON METAL CHIP	10 470 4.7 680 10K	5% 5% 5%	1/4W F 1/2W 1/2W 1/10W 1/10W
R133	1-216-091-00	METAL GLAZE	56K 5%	1/10	W	1.200	1 210 013 00	HEINE VENZE	100	1/6	1/ 10#

REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R207 R208 R209 R210 R211	1-216-065-00 1-216-065-00 1-216-073-00 1-216-061-00 1-249-393-11	CAKBUN	4.7K 4.7K 10K 3.3K		1/10W 1/10W 1/10W 1/10W 1/4W	F	R364	1-216-113-00 1-216-113-00 1-216-065-00 1-216-051-00 1-216-049-00 1-216-069-00	METAL GLAZE	470K 470K 4.7K 1.2K 1K 6.8K	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R237 R301 R302 R303 R304	1-216-089-91 1-216-025-00 1-216-025-00 1-216-025-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 100 100 100 100	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R371 R372 R373 R374	1-216-053-00 1-216-645-11 1-216-647-11	METAL GLAZE METAL CHIP METAL CHIP	1.5K 560	5% 0.50% 0.50%	1/10W 1/10W 1/10W 1/10W	
R305 R306 R307 R308 R311	1-216-295-00 1-216-295-00 1-216-115-00 1-216-065-00 1-216-055-00		0 0 560K 4.7K 1.8K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R376	1-216-053-00	METAL GLAZE	1.5K 390K 390K 6.8K 4.7K 39K 270K		1/10W 1/10W 1/10W 1/10W 1/10W	
R312 R313 R314 R315 R316	1-216-073-00 1-216-649-11 1-216-099-00 1-216-099-00 1-216-049-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	120K 120K 1K	5% 0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R382		METAL GLAZE	3.3K 10K 4.7K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R317 R318 R319 R320 R321	1-216-057-00 1-216-049-00 1-216-069-00 1-216-057-00 1-216-051-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 1K 6.8K 2.2K 1.2K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R389 R391 R393	1-216-645-11 1-216-113-00 1-216-073-00	METAL CHIP METAL GLAZE METAL GLAZE	560 470K 10K	0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R322 R323 R324 R325 R326	1-216-035-00 1-216-109-00 1-216-101-00 1-216-037-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	270 330K 150K 330 220	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R396	1-216-083-00 1-216-647-11 1-216-113-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	27K 680 470K 470K 220K 390K 1.5K	5% 0.50%	1/10W 1/10W 1/10W	
R328 R329 R330 R331 R332	1-216-121-00 1-216-055-00 1-216-089-91 1-216-093-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1M 1.8K 47K 68K 100K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R397 R398 R399 R401 R402 R403 R404 R406 R407	1-216-111-00 1-216-053-00 1-216-053-00 1-216-069-00 1-216-029-00	METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W 1/10W	
R333 R334 R335 R336 R337	1-216-097-00 1-216-093-00	METAL GLAZE	100K 68K 27K 4.7K 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R406 R407 R408 R410 R411 R412 R413	1-216-069-00	METAL GLAZE METAL GLAZE METAL CHIP		5% 5% 0.50% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W	
R338 R339 R340 R341 R342	1-216-091-00 1-216-071-00 1-216-089-91 1-216-673-11 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	56K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R412 R413 R416 R417 R418		METAL GLAZE METAL GLAZE METAL CHIP METAL CHIP METAL CHIP METAL CHIP METAL GLAZE				
R343 R344 R345 R346 R347	1-216-095-00 1-216-099-00 1-216-063-00 1-216-057-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	82K 120K 3.9K 2.2K 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R420 R422 R423	1-216-065-00 1-216-689-11 1-216-073-00 1-216-073-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 39K 10K 10K 220	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R348 R349 R350 R351 R352	1-216-031-00 1-216-694-11 1-216-085-00 1-216-061-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	180 62K 33K 3.3K	5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W		R424 R425 R426 R427 R428	1-216-049-00 1-216-039-00 1-216-033-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 390 220 100K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R353 R355 R356 R357	1-216-675-11 1-216-049-00 1-216-059-00 1-216-689-11 1-216-121-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 1K 2.7K 39K 1M	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R429 R430 R431 R432 R434 R435	1-216-073-00 1-216-119-00 1-216-097-00 1-216-089-91 1-216-109-00	METAL GLAZE METAL GLAZE METAL GLAZE	10K 820K 100K 47K 330K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R359 R360 R361	1-216-053-00 1-216-065-00 1-216-039-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.5K 4.7K 390 100	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R435 R436 R437	1-216-105-00 1-216-105-00 1-216-113-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE	220K 470K 100K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R362	1-216-067-00	METAL GLAZE	5.6K	5%	1/10W		R439	1-216-033-00	METAL GLAZE	220	5% 5%	1/10W	

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R440 R441 R442 R443 R444	1-216-049-00 1-216-645-11 1-216-647-11 1-216-049-00 1-216-105-00	METAL GLAZE METAL CHIP METAL CHIP METAL GLAZE METAL GLAZE	680 1K 220K	0.50% 1/10 0.50% 1/10 5% 1/10 5% 1/10		R507 R508 R509 R510 R511 R512	1-216-083-00 1-216-105-00 1-216-089-91 1-216-097-00 1-216-099-00	METAL GLAZE	27K 5 220K 5 47K 5 100K 5 120K 5 1.8K 5		1/10W 1/10W 1/10W 1/10W 1/10W	
R445 R447 R448 R449 R450	1-216-095-00 1-216-069-00 1-216-049-00 1-216-073-00 1-216-121-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	82K 6.8K 1K 10K 1M	5% 1/10 5% 1/10 5% 1/10 5% 1/10 5% 1/10		R512 R513 R514 R515 R516 R516	1-216-099-00 1-216-055-00 1-216-295-00 1-216-295-00 1-216-697-11 1-216-697-11	METAL GLAZE	0 5 0 5 10K 0	%	1/10W 1/10W 1/10W 1/10W	
R451 R452 R453 R455 R456	1-216-053-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE		0.50% 1/10 5% 1/10 5% 1/10 5% 1/10	Μ Μ Μ	R517 R518 R519 R520 R521 R522	1-260-123-11 1-216-017-00 1-249-423-11 1-216-065-00	CARBON METAL GLAZE CARBON METAL GLAZE	10K 1	%	1/2W 1/2W 1/10W 1/4W F 1/10W	î
R457 R458 R459 R460 R462	1-216-113-00 1-216-649-11 1-216-073-00 1-216-651-11	METAL GLAZE METAL CHIP METAL GLAZE METAL CHIP	820 10K 1K	5% 1/10 5% 1/10 0.50% 1/10 5% 1/10 0.50% 1/10	₩ ₩ ₩	R522 R523 R524 R525 R526 R527	1-260-111-11 1-215-892-11 1-216-093-00 1-216-069-00 1-216-089-91	METAL OXIDE METAL GLAZE METAL GLAZE METAL GLAZE	1K 5 68K 5 6.8K 5	% %	1/2W 2W { 1/10W 1/10W 1/10W	ì
R463 R464 R465 R466 R467	1-216-065-00 1-216-065-00 1-216-025-00 1-216-077-00 1-216-121-00 1-216-105-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 4.7K 100 15K 1M	5% 1/10 5% 1/10 5% 1/10)M)M M	R528 R529 R530 R531 R532	1-216-089-91 1-216-089-91 1-216-089-91 1-216-367-11 1-216-077-00 1-215-919-71	METAL OXIDE METAL GLAZE	47K 5 47K 5 0.68 5	5% 5%	1/10W 1/10W 1/10W 2W 1 1/10W 3W 1	
R469 R470 R471 R472	1-216-063-00 1-216-069-00 1-216-109-00 1-216-077-00 1-216-121-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220K 3.9K 6.8K 330K 15K) M) M) M) M	R533 R534 R535 R536 R537	1-247-723-11 1-216-085-00 1-249-448-11 1-216-101-00 1-216-089-91	CARBON METAL GLAZE CARBON METAL GLAZE	6.8K 33K 1.2 150K 47K		1/4W 1/10W 1/4W 1/10W 1/10W	F
R474 R475 R476 R477	1-216-649-11 1-216-025-00 1-216-061-00 1-216-061-00	METAL CHIP METAL GLAZE	820 100 3.3K 3.3K	0.50% 1/1 5% 1/1 5% 1/1 5% 1/1) M) M) M) M	R539 R540 R541 R542 R543	1-216-065-00 1-216-113-00 1-249-383-11 1-216-057-00 1-212-883-00	METAL GLAZE	4.7K 5	5% 5% 5%	1/10W 1/10W 1/10W 1/4W 1/10W	
R479 R480 R481 R482	1-216-085-00 1-216-077-00 1-216-033-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33K 15K 220 2.2K		OW OW OW	R544 R545 R546 R548 R549	1-216-095-00 1-216-073-00 1-249-425-11 1-216-057-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE	82K 10K 4.7K 2.2K	5% 5% 5%	1/10W 1/10W 1/4W 1/10W	
R483 R484 R485 R486 R487	1-216-033-00 1-216-681-11	METAL GLAZE METAL CHIP METAL GLAZE METAL CHIP METAL CHIP	100 1K 220 18K 1.2K	5% 1/1 0.50% 1/1 5% 1/1 0.50% 1/1 0.50% 1/1		R550 R551 R552 R553	1-216-677-11 1-216-053-00 1-216-077-00 1-216-033-00 1-216-083-00	METAL GLAZE METAL GLAZE METAL GLAZE	1.5K 15K 220 27K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R488 R489 R490 R491 R492	1-216-073-00 1-216-077-00 1-216-057-00 1-216-061-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE	10K 15K 2.2K 3.3K 33K	5% 1/1 5% 1/1 5% 1/1 5% 1/1 5% 1/1	OW OW	R554 R555 R556 R558 R559	1-216-095-00 1-216-692-11 1-216-464-11 1-247-711-11 1-216-109-00	METAL CHIP METAL OXIDE CARBON	82K 51K	5%	1/10W 1/10W 2W 1/4W 1/10W	F F
R493 R494 R495 R496 R497	1-216-295-00 1-216-085-00 1-216-651-11 1-216-073-00 1-216-653-11	METAL GLAZE METAL CHIP METAL GLAZE	0 33K 1K 10K 1.2K	5% 1/1 5% 1/1 0.50% 1/1 5% 1/1 0.50% 1/1	OM OM OM	R560 R561 R563 R564 R565	1-216-091-00 1-216-049-00 1-216-017-00 1-216-107-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 47 - 270K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R498 R499 R500 R501 R502	1-216-061-00 1-216-033-00 1-216-689-11 1-216-077-00 1-216-677-11	METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 220 39K 15K 12K	5% 1/1 5% 1/1 5% 1/1 5% 1/1 0.50% 1/1	OW OW	R566 R567 R568 R569	1-216-685-11 1-216-081-00 1-216-073-00 1-260-114-11	METAL CHIP METAL GLAZE METAL GLAZE CARBON	27K 22K 10K	0.50% 5% 5%	1/10W 1/10W 1/10W 1/2W	
R503 R504 R505 R506	1-216-111-00 1-216-067-00	METAL GLAZE METAL GLAZE	12K 390K 5.6K 10K	0.50% 1/1 5% 1/1 5% 1/1 5% 1/1	OM OM	R571 R572 R573 R574	1-216-065-00 1-216-059-00 1-216-071-00 1-216-689-11	METAL GLAZE METAL GLAZE	8.2K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	

REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	<u> </u>	DESCR	IPTION				REMARK
R576 R578 R580 R582 R583	1-216-101-00 1-216-693-11 1-216-105-00 1-216-085-00 1-216-039-00 1-216-033-00 1-216-686-11 1-216-675-11 1-216-077-00 1-216-081-00 1-216-688-11 1-247-688-11 1-247-688-11 1-216-687-11 1-216-687-11 1-216-689-11 1-216-689-11 1-216-689-11 1-216-085-00 1-216-685-01 1-216-095-00 1-216-099-11 1-216-099-11 1-216-099-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	150K 56K 220K 33K 390	5% 0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1146 R1147 R1148 R1150 R1151	1-216-057 1-216-057 1-216-065 1-216-037 1-216-081	7-00 7-00 5-00 7-00	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE GLAZE	2.2K 2.2K 4.7K 330 22K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R584 R585 R586 R587 R588	1-216-071-00 1-216-033-00 1-216-686-11 1-216-675-11 1-216-077-00	METAL GLAZE METAL GLAZE METAL CHIP METAL CHIP METAL GLAZE	8.2K 220 30K 10K 15K	5% 5% 0.50% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1155 R1161 R1162 R1163 R1164	1-216-133 1-218-776 1-218-768 1-216-033 1-216-049	3-00 5-11 3-11 3-00 9-00	METAL METAL METAL METAL METAL	GLAZE CHIP CHIP GLAZE GLAZE	3.3M 1M 470K 220 1K 1K	0.50% 0.50% 5%	1/10W 1/10W 1/10W	
R589 R590 R591 R592 R593	1-216-067-00 1-216-081-00 1-216-683-11 1-247-688-11 1-216-647-11	METAL GLAZE METAL GLAZE METAL CHIP CARBON METAL CHIP	22K 22K 10 680	5% 5% 0.50% 5% 0.50%	1/10W 1/10W 1/10W 1/4W 1/10W	F	R1165 R1166 R1167 R1168 R1169	1-216-049 1-216-295 1-216-097 1-216-097 1-216-088	5-00 7-00 7-00 7-00 7-00	METAL METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	0 100K 100K 100K 100K 47K		1/10W 1/10W 1/10W 1/10W 1/10W	
R595 R596 R597 R598 R599	1-216-689-11 1-214-754-00 1-249-417-11 1-216-085-00 1-216-645-11	METAL GLAZE METAL CARBON METAL GLAZE METAL CHIP	39K 11K 1K 33K 560	5% 1% 5% 5% 0.50%	1/10W 1/4W 1/4W 1/10W	F	R1171 R1172 R1173 R1176 R1177	1-216-085 1-216-085 1-216-295 1-216-295 1-216-071	5-00 5-00 5-00 5-00	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	33K 33K 0 0 8.2K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1101 R1102 R1103 R1104	1-216-295-00 1-216-295-00 1-216-077-00 1-216-699-11 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	0 0 15K 100K	5% 5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W		R1178 R1179 R1180 R1181 R1182	1-216-29 1-216-04 1-216-08 1-216-29 1-216-13	5-00 1-00 9-91 5-00 1-11	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	0 470 47K 0 2.7M		1/10W 1/10W 1/10W 1/10W 1/10W	
R 1 106 R 1 107 R 1 108 R 1 109	1-216-097-00 1-216-059-00 1-216-681-11 1-216-295-00 1-216-295-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	100K 2.7K 18K 0	5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W		R1183 R1184 R1185 R1186 R1187	1-216-07 1-216-13 1-216-07 1-216-13 1-216-07	1-00 1-11 1-00 1-11 1-00	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	8.2K 2.7M 8.2K 2.7M 8.2K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1114 R1115	1-216-049-00 1-216-049-00	METAL GLAZE METAL GLAZE	1 K	5% 5% 5% 5% 5% 5%	1/10W		R1188 R1189 R1190 R1191 R1192	1-216-13 1-216-07 1-216-13 1-216-07 1-216-13	1-11 1-00 1-11 1-00 1-11	METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	2.7M 8.2K 2.7M 8.2K 2.7M	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1117 R1118 R1119		METAL GLAZE METAL GLAZE METAL CHIP	6.8K 470K 62K	5% 5% 0.50%	1/10W 1/10W 1/10W		R1193 R1194 R1195 R1196 R1197	1-216-03 1-216-07 1-216-07 1-216-13 1-216-03 1-216-02 1-216-08 1-216-08 1-216-08	5-00 5-00 5-00 5-00 5-00	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	100 33K 100 33K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R 1126 R 1127	1-216-041-00 1-216-295-00	METAL GLAZE	0	5% 5% 5% 5% 5% 5% 5%	1/10W		R1198 R1301 R1302 R1303 R1304	1-216-08 1-216-02 1-216-02 1-216-03 1-216-68	5-00 9-00 9-00 9-00 9-11	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	33K 150 150 390 39K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R 1128 R 1129 R 1130 R 1131	1-216-071-00 1-216-049-00 1-216-049-00 1-216-071-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 8.2K 1K 1K 8.2K	5% 5%	1/10W 1/10W 1/10W 1/10W]]]	R1305 R1306 R1307 R1308 R1309	1-216-03 1-216-64 1-216-09 1-216-64 1-216-02	5-11 1-00 5-11	METAL METAL METAL	GLAZE	220 560 56K 560 100	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R 1133 R 1134 R 1135 R 1136	1-216-073-00 1-216-295-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	6.8K 10K 0 100K 10K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W] - 	R1310 R1311 R1312 R1313 R1314		19-91 17-00 17-00	METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	100 47K 120 100K 22K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R 1138 R 1139 R 1140 R 1141	1-216-653-11 1-216-083-00 1-216-653-11	METAL GLAZE METAL CHIP METAL GLAZE METAL CHIP	22K 1.8K 1.2K 27K	0.50% 5% 0.50%	1/10W 1/10W 1/10W 1/10W	} } }	R1315 R1316 R1317 R1318 R1319	1-216-02 1-216-06 1-216-04 1-216-06	25-00 55-00 11-00 51-00	METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	100 4.7K 470 3.3K 33K	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R 1143 R 1144 R 1145	1-216-073-00	METAL GLAZE	1.2K 10K 5.6K	5%	1/10W 1/10W 1/10W	ý	R1320 R1321				GLAZE CHIP	4.7K 820		1/10W 1/10W	

_																
		PART NO.	DESCRIPTION				REMARK	REF.NO.	PAR	T NO.	DESC	RIPTION				REMARK
	R1322 R1323 R1324 R1325 R1326	1-216-057-00 1-216-097-00 1-216-061-00 1-216-652-11 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	2.2K 100K 3.3K 1.1K 10K	5% 5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1386 R1387 R1388 R1389	1-2 1-2 1-2 1-2	16-077-00 16-653-11 16-689-11 16-657-11	METAL METAL METAL METAL	GLAZE CHIP CHIP CHIP	15K 1.2K 39K 1.8K	0.50%	1/10W 1/10W	
	R1328 R1329 R1330	1-216-073-00 1-216-125-00 1-216-103-91 1-216-081-00 1-216-679-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	10K 1.5M 180K 22K 15K	5% 5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		R1391 R1392 R1393 R1394	1-2 1-2 1-2 1-2 1-2	16-077-00 16-653-11 16-689-11 16-657-11 16-647-11 16-025-00 16-041-00 16-041-00 16-071-00 16-071-00 16-065-00	METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	680 100 470 3.9K 470 8.2K 8.2K	0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R1332 R1333 R1334 R1335 R1336	1-216-671-11 1-216-049-00 1-216-063-00 1-249-401-11 1-216-095-00	METAL CHIP METAL GLAZE METAL GLAZE CARBON METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	6.8K 1K 3.9K 47 82K	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/4W 1/10W	F	R1396 R1397 R1399 R1401 R1402	1-2 1-2 1-2 1-2	16-071-00 16-065-00 16-073-00 16-085-00 16-295-00	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE	8.2K 4.7K 10K 33K	5%	1/10W	
	R1340 R1341	1-216-033-00 1-216-033-00	METAL GLAZE METAL GLAZE	220 220 220	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1403 R1404 R1405 R1406 R1407	1-2 1-2 1-2 1-2 1-2	16-651-11 16-681-11 16-071-00 16-653-11 16-061-00 16-113-00	METAL METAL METAL METAL METAL	CHIP CHIP GLAZE CHIP GLAZE	0 1K 18K 8.2K 1.2K 3.3K 470K			
	R1344 R1345 R1346	1-216-083-00 1-216-037-00 1-216-093-00 1-216-109-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE	68K 330K 100K	5% 5% 5%	1/10W 1/10W		R1409 R1410	1-2 1-2	16-113-00 16-295-00 16-053-00 16-073-00 16-107-00 16-081-00	METAL METAL	GLAZE GLAZE	0 1.5K 10K 270K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
	R1349 R1350 R1351	1-216-073-00 1-216-071-00 1-216-035-00 1-216-073-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 8.2K 270 10K 220	5% 5% 5%	1/10W 1/10W 1/10W		R1414 R1415 R1416 R1417	1-2 1-2 1-2 1-2	16-057-00 16-093-00 16-113-00 16-033-00	METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE	22K 2.2K 68K 470K 220 220	24	1/10W 1/10W 1/10W 1/10W 1/10W	
	R1353 R1354 R1355 R1356	1-216-065-00 1-216-065-00 1-216-089-91 1-216-033-00 1-216-105-00		4.7K 4.7K 47K 220 220K		1/10W 1/10W 1/10W 1/10W				116-033-00 116-025-00 116-089-91 116-649-11 116-085-00 116-057-00			100 47k	5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W 1/10W	
	R 1358 R 1359 R 1360 R 1361	1-216-065-00 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE	150K 8.2K 120K 4.7K 470K	5% 5%	1/10W 1/10W		R1424 R1425	1-2 1-2	216-081-00 216-013-00	METAL METAL	. GLAZE . GLAZE	22K 33	5% 5%	1/10W 1/10W	
	R 1365	1-216-676-11 1-216-113-00 1-216-073-00 1-216-131-11 1-216-081-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	11K 470K 10K 2.7M 22K	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1428 R1429 R1430 R1431 R1432	1-2 1-2 1-2 1-2	216-113-00 216-681-11 216-061-00 216-668-11 216-073-00 216-129-00 216-089-91 216-085-00	METAL METAL METAL METAL METAL	. GLAZE . CHIP . GLAZE . GLAZE . GLAZE	3.3K 5.1K 10K 2.2M	5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W	
	R 1367 R 1368 R 1369 R 1370 R 1371	1-216-057-00 1-216-059-00 1-216-051-00 1-216-105-00 1-216-113-00	METAL GLAZE	2.2K 2.7K 1.2K 220K 470K		1/10W 1/10W 1/10W 1/10W 1/10W		R1433 R1434 R1435 R1436 R1437	i-2 1-2	216-085-00 216-645-11 216-055-00 216-073-00 216-069-00	METAL	GLAZE	1.8K 10K	5% 0.50% 5% 5% 5%	1/10W 1/10W	
	R 1372 R 1373 R 1374 R 1375 R 1376	1-249-437-11 1-216-063-00 1-216-101-00 1-216-645-11 1-216-647-11		47K 3.9K 150K 560 680	5% 0.50%	1/4W 1/10W 1/10W 1/10W 1/10W		R1438 R1439 R1440 R1441	1-2 1-2 1-2 1-2	216-073-00 216-059-00 216-041-00 216-033-00	METAI METAI METAI METAI	GLAZE GLAZE GLAZE GLAZE GLAZE	6.8K 10K 2.7K 470 220	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R 1377 R 1378 R 1379 R 1380 R 1381	1-216-055-00 1-216-065-00 1-216-037-00 1-216-645-11 1-216-647-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL CHIP	1.8K 4.7K 330 560 680	5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		R1442 R1443 R1444 R1445 R1446	1-2 1-2 1-2 1-3	216-073-00 216-013-00 216-057-00 216-071-00 216-071-00	METAI METAI METAI METAI	GLAZE L GLAZE L GLAZE L GLAZE L GLAZE	10K 33 2.2K 8.2K 8.2K	5555 555555555555555555555555555555555	1/10W 1/10W 1/10W 1/10W 1/10W	
	R 1382 R 1383 R 1384 R 1385	1-216-091-00	METAL CHIP METAL GLAZE	10K 18K 56K 10K	5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W		R1447 R1448 R1449 R1450	1-2 1-2	216-081-00 216-085-00 216-057-00 216-129-00	META!	L GLAZE L GLAZE L GLAZE L GLAZE	22K 33K 2.2K 2.2M	5%	1/10W 1/10W 1/10W 1/10W	

The components identified by shading and mark A are critical for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

A (PVM-1351Q/1354Q)

REF.NO. PART NO.	DESCRIPTION				REMARK	REF. NO.	PART NO.	DESCRIPTION		***		REMARK
R1452 1-216-085-00 M R1453 1-216-013-00 M R1454 1-216-065-00 M R1455 1-216-113-00 M		68K 33K 33 4.7K 470K		1/10W 1/10W 1/10W 1/10W 1/10W			1-216-355-11 1-216-007-00 1-216-029-00 1-249-400-11 1-216-350-11 1-216-427-00		3.3 18 150 39 1.2 120		1W 1/10W 1/10W 1/4W 1W	F
	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2M 47K 33K 3.3M 100K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1525	1-216-083-00	METAL GLAZE	27K	5% 5%	1W 1/10W	F F F
R1462 1-216-645-11 N R1463 1-216-645-11 N R1464 1-216-057-00 N R1465 1-216-097-00 N	METAL CHIP METAL CHIP METAL CHIP METAL GLAZE METAL GLAZE	560 560 560 2.2K 100K	0.50% 0.50% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1529 R1530 R1531 R1532 R1533	1-202-829-11 1-216-115-00 1-247-697-11 1-216-059-00 1-249-414-11	CARBON METAL OXIDE SOLID METAL GLAZE CARBON METAL GLAZE CARBON METAL CHIP CARBON METAL CHIP	8.2K 560K 56 2.7K 560	20% 5% 5% 5%	1/2W 1/10W 1/4W 1/10W 1/4W	F
R1466 1-216-055-00 N R1467 1-216-073-00 N R1468 1-249-438-11 (R1469 1-216-057-00 N R1470 1-216-057-00 N	METAL GLAZE METAL GLAZE CARBON METAL GLAZE METAL GLAZE	1.8K 10K 56K 2.2K 2.2K	5% 5% 5% 5%	1/10W 1/10W 1/4W 1/10W 1/10W		R1534 ► R1535 A ► R1536 A	1-216-659-11 A A 1-249-389-11	METAL CHIP	2.2K	0.750% 5%	1/10W	F.
R1471 1-216-049-00 R1472 1-216-085-00 R1473 1-216-081-00 R1474 1-216-687-11 R1475 1-216-677-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	33K 22K 33K	5% 5% 5% 0.50%	1/10W 1/10W 1/10W		R1539 R1540 R1541	1-216-689-11 1-216-105-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE	39K 220K 22K	5% 5% 5%	1/10W 1/10W 1/10W	
R1476 1-216-063-00 R1477 1-216-057-00 R1478 1-216-061-00 R1479 1-216-295-00		12K 3.9K 2.2K 3.3K 0 47K		1/10W 1/10W 1/10W 1/10W 1/10W		R1542 R1543 R1544 R1545 R1547	1-216-111-00 1-216-027-00 1-216-117-00 1-216-101-00 1-216-393-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL OXIDE	390K 120 680K 150K 2.2	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 3W	
R1480 1-216-089-91 R1481 1-216-015-00 R1482 1-216-089-91 R1483 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	560K 47K 47K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R1548	1-216-057-00 1-260-094-11 1-216-105-00 1-249-393-11 1-216-091-00	METAL CLAZE	2.2K 390 220K 10 56K	5% 5% 5%	1/10W 1/2W 1/10W 1/4W 1/10W	F
R1486 1-216-121-00 R1487 1-216-113-00 R1488 1-216-083-00	METAL GLAZE	22K 470K 1M 470K 27K 6.8K 270	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1553 R1554 R1555 R1556 R1556	1-216-091-00 1-216-059-00 1-216-295-00 1-216-071-00 1-218-760-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	56K 2.7K 0 8.2K 220K	5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1490 1-216-035-00 R1491 1-216-035-00 R1492 1-216-035-00 R1493 1-216-083-00	METAL GLAZE METAL GLAZE		5% 5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1558 R1559 R1560 R1561	1-249-393-11 1-249-393-11 1-216-049-00 1-216-681-11 1-214-964-00	CARBON CARBON METAL GLAZE METAL CHIP METAL	10 10 1K 18K	5% 5% 5% 0.50%	1/4W 1/4W 1/10W 1/10W	F
R1494 1-216-081-00 R1495 1-216-089-91 R1497 1-216-113-00 R1498 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE	470K 2.2K	5% 5%	1/10W 1/10W 1/10W 1/10W		R1563 R1564 R1567 R1568	1-214-964-00 1-216-681-11 1-216-089-91 1-216-081-00	METAL METAL CHIP METAL GLAZE METAL GLAZE	1 M 1 8 K 4 7 K 2 2 K	1% 0.50% 5% 5%	1/4W 1/10W 1/10W 1/10W	 - -
R1500 1-216-647-11 R1501 1-216-071-00 R1502 1-260-105-11 R1503 1-216-063-00	METAL GLAZE METAL CHIP METAL GLAZE CARBON METAL GLAZE	2.2K 680 8.2K 3.3K 3.9K	5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/2W 1/10W		R1569 R1570 R1571 R1572 R1573	1-216-073-00 1-216-073-00 1-216-103-91 1-216-101-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 10K 180K 150K 10K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W) . -
R 1505 1-247-688-11 R 1506 1-216-037-00 R 1507 1-216-065-00	METAL CHIP CARBON METAL GLAZE METAL GLAZE	30K 10 330 4.7K	0.50% 5% 5% 5%	1/10W 1/4W 1/10W		R1574 R1575 R1576 R1577	1-216-041-00 1-216-025-00 1-216-025-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 100 100 100	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	} } !
R1509 1-249-439-11 R1510 1-216-077-00 R1511 1-216-360-11	METAL GLAZE CARBON METAL GLAZE METAL OXIDE METAL CHIP	39K 68K 15K 8.2 680	5% 5% 5% 5% 0.50%	1/10W 1/4W 1/10W 1W 1/10W	F	R1578 R1579 R2300 R2301	1-216-065-00 1-216-689-11 1-216-065-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 39K 4.7K 4.7K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W)
R1514 1-247-711-11 R1515 1-216-350-11 R1516 1-247-883-00	CARBON CARBON METAL OXIDE CARBON METAL OXIDE	1K 680 1.2 150K 470	5% 5% 5% 5% 5%	1/2W 1/4W 1W 1/4W 1W	£ £	R2302 R2303 R2304 R2305 R2306	1-216-671-11 1-216-093-00 1-216-105-00 1-216-085-00 1-216-089-91	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	6.8K 68K 220K 33K 47K	0.50% 5% 5% 5%	1/10V 1/10V 1/10V 1/10V 1/10V) } V

The components identified by in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.

Should replacement be required, replace only with the value originally used.

REF.NO. PART NO.	DESCRIPTION		_		REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R2307 1-216-033-00 R2308 1-216-103-91 R2309 1-216-049-00 R2310 1-216-095-00 R2311 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220 180K 1K 82K 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2372 R2374 R2375 R2376	1-216-113-00 1-216-097-00 1-216-089-91 1-216-089-91	METAL GLAZE	470K 100K 47K 47K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R2315 1-216-679-11 R2316 1-216-081-00	METAL GLAZE METAL GLAZE METAL CHIP METAL CHIP METAL GLAZE	1.5K 1K 560 15K 22K	5% 5% 0.50% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2378 R2378 R2379 R2380 R2381 R2382	1-216-033-00 1-216-089-91 1-216-089-91 1-216-089-91 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220 47K 220 47K 47K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2317 1-216-049-00 R2318 1-216-069-00 R2319 1-216-093-00 R2320 1-216-677-11 R2321 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	1K 6.8K 68K 12K 2.2K	5% 5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2383 R2384 R2385 R2386 R2387	1-216-033-00 1-216-033-00 1-216-073-00 1-216-073-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	39K 10K 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R2322 1-216-065-00 R2323 1-216-683-11 R2324 1-216-073-00 R2325 1-216-063-00 R2326 1-216-041-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 22K 10K 3.9K 470	5% 0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2388 R2389 R2390 R2391 R2392	1-216-073-00 1-216-033-00 1-216-647-11 1-216-647-11 1-216-073-00	METAL GLAZE METAL GLAZE METAL CHIP METAL CHIP METAL GLAZE	10K 220 680 680 10K	5% 5% 0.50% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2327 1-216-059-00 R2328 1-216-049-00 R2329 1-216-059-00 R2330 1-216-049-00 R2331 1-216-059-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.7K 1K 2.7K 1K 2.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2393 R2394 R2396 R2397 R2398	1-216-073-00 1-216-081-00 1-216-041-00 1-216-113-00 1-216-109-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 22K 470 470K 330K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2332 1-216-049-00 R2333 1-216-089-91 R2334 1-216-041-00 R2335 1-216-061-00 R2336 1-216-065-00 R2337 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 47K 470 3.3K 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2399 R2501 R2502 R2551 R2552	1-216-073-00 1-216-083-00 1-216-077-00 1-216-091-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 27K 15K 56K 33K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2338 1-216-073-00 R2339 1-216-037-00 R2340 1-216-073-00 R2341 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 330 10K 330	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2555 R2556 R2557 R2558	1-216-055-00 1-216-051-00 1-216-067-00 1-216-057-00	METAL GLAZE	27K 1.8K 1.2K 5.6K 2.2K	5% 5%	1/10W 1/10W	
R2343 1-216-081-00 R2344 1-216-121-00 R2345 1-216-681-11 R2346 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	8.2K 22K 1M 18K 3.3K	5% 5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2560 R2561 R2562 R2563	1-216-039-00 1-216-069-00 1-216-001-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	390 6.8K 10 10 2.2K 10K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2347 1-216-061-00 R2348 1-216-061-00 R2349 1-216-679-11 R2350 1-216-061-00 R2351 1-216-061-00	METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 3.3K 15K 3.3K 3.3K	5% 5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W		R3301 R3302 R3303 R3304 R3305	1-216-073-00 1-216-065-00 1-216-065-00 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 4.7K 4.7K 4.7K 3.3K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2353 1-216-041-00 R2354 1-216-025-00 R2356 1-216-089-91 R2357 1-216-095-00 R2358 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 47K 82K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R3308 R3309 R3310 R3311	1-216-097-00 1-216-073-00 1-216-049-00 1-216-091-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 10K 1K 56K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2359 1-216-097-00 R2360 1-216-689-11 R2361 1-216-099-00 R2362 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 100K 39K 120K 22K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3312 R3317 R3320 R3333 R3334 R3335	1-216-105-00 1-216-103-91 1-216-085-00 1-216-113-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220K 180K 33K 470K 10K	5% 5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2363 1-216-065-00 R2364 1-216-025-00 R2365 1-216-687-11 R2366 1-216-067-00 R2367 1-216-093-00 R2368 1-216-065-00	METAL GLAZE METAL CHIP METAL GLAZE	4.7K 100 33K 5.6K 68K	5% 5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3337 R3338 R3339 R3340	1-216-113-00 1-216-099-00 1-218-759-11 1-216-093-00 1-216-099-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	470K 120K 200K 68K 120K	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2369 1-216-083-00 R2370 1-216-081-00 R2371 1-216-049-00	METAL GLAZE METAL GLAZE	4.7K 27K 22K 1K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R3341 R3344 R3345	1-216-083-00 1-216-081-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE	27K 22K 220	5% 5% 5%	1/10W 1/10W 1/10W	

A (PVM-1351Q/1354Q) A (PVM-1350)

REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRI	PTION			REMARK
R3347 R3348 R3349	1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 100 100	5%	1/10W 1/10W 1/10W 1/10W 1/10W		X101 X300 X301	1-579-175-11 1-577-259-11 1-527-722-00	VIBRATO OSCILLA	TOR, CRY	AL STAL	:*****	******
R3351	1-216-119-00	METAL GLAZE METAL GLAZE	820K	5%	1/10W 1/10W			*A-1297-196-		. COMPLE		350)	
R3355 R3356 R3357 R3358	1-216-089-91 1-216-051-00 1-216-051-00 1-216-051-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.2K 1.2K 1.2K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		į	1-540-044-1 *4-030-359-0 *4-043-154-0	SOCKET	IC NK, H. P			
R3359 R3360 R3361 R3362	1-216-081-00 1-216-073-00 1-216-089-91 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 10K 47K 1K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W			*4-043-994-0 4-363-414-0 4-382-854-1	1 PLATE 0 SPACER.	CF), SHI Mica			
R3363	1-216-049-00	METAL GLAZE	1 K 1 O K		1/10W 1/10W		1 1 1	< R	AND PASS I	III TER>			
	1-216-073-00 1-216-081-00 1-216-081-00 1-216-107-00	METAL GLAZE METAL GLAZE METAL GLAZE	22K 22K 270K	5% 5% 5% 5%	1/10W 1/10W 1/10W		BPF400	1-236-363-1			ASS		
R3378 R3381	1-216-115-00 1-216-041-00	METAL GLAZE METAL GLAZE	560K 470	5%	1/10W 1/10W		1		APACITORS				
R3382 R3383 R3384 R3385	1-216-647-11 1-216-069-00 1-216-063-00 1-216-057-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	680 6.8K 3.9K 2.2K	0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		C105 C106 C114 C115 C116	1-163-251-1 1-163-251-1 1-163-031-1 1-163-031-1 1-163-031-1	1 CERAMI 1 CERAMI 1 CERAMI	C CHIP 10	00PF .01MF .01MF	5% 5%	50V 50V 50V 50V 50V
R3386 R3390	1-216-057-00 1-216-057-00	METAL GLAZE METAL GLAZE	2.2K 2.2K	5% 5% 5%	1/10W 1/10W		C117	1-163-031-1 1-163-125-0	1 CERAMI	C CHIP O	.01MF	5%	50V 50V
	1-216-041-00	METAL GLAZE CARBON METAL GLAZE	47K 1K 470	5%	1/10W 1/4W 1/10W		C118 C119 C121 C123	1-165-319-1 1-163-237-1 1-165-319-1	LI CERAMI LI CERAMI	C CHIP O C CHIP 2' C CHIP O	.1MF 7PF	5%	50V 50V 50V
R3397 R3398 R4401 R4402 R4404	1-216-085-00 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 150K 33K 470K 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C124 C132 C133 C134 C135	1-163-251-1 1-163-141-0 1-163-251-1 1-163-251-1	DO CERAMI 11 CERAMI 11 CERAMI	C CHIP 1 C CHIP 0 C CHIP 1 C CHIP 1 C CHIP 1	.001MF 00PF 00PF	5% 5% 5% 5% 5%	50 V 50 V 50 V 50 V 50 V
R4405 R4407 R4408 R4409 R4410	1-216-061-00 1-216-059-00 1-216-059-00	METAL GLAZE METAL GLAZE METAL GLAZE	5.6K 3.3K 2.7K 2.7K 2.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C136 C141 C142 C143 C144	1-163-251- 1-164-161- 1-163-125- 1-165-319- 1-165-319-	11 CERAMI 00 CERAMI 11 CERAMI	C CHIP 1 C CHIP 0 C CHIP 2 C CHIP 0 C CHIP 0).0022MF 220PF).1MF	5% 10% 5%	50 V 50 V 50 V 50 V 50 V
R4411 R4412 R4413 R4414 R4415	1-216-113-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE	470K 470K 0 0 0	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W) - -	C145 C154 C155 C156 C157	1-165-319- 1-163-037- 1-163-023- 1-163-019- 1-163-019-	11 CERAM 11 CERAM 00 CERAM 00 CERAM	C CHIP C C CHIP C C CHIP C	0.1MF 0.022MF 0.015MF 0.0068MF	10% 10% 10% 10%	50V 25V 50V 50V 50V
R4416	1-216-295-00	METAL GLAZE	0	5%	1/10	t	C158 C159	1-163-809- 1-163-037-		IC CHIP (10% 10%	25V 25V
RV50	<۷/ 1 1-223-102-00	RIABLE RESISTO RES, ADJ. W		D 120			C161 C162 C164	1-124-477- 1-163-141- 1-165-319-	11 ELECT 00 CERAM		47MF 0.001MF	20% 5%	16V 50V 50V
	<t1< td=""><td>RANSFOMER></td><td></td><td></td><td></td><td></td><td>C165 C166</td><td>1-165-319- 1-164-004-</td><td>11 CERAM</td><td>IC CHIP (</td><td>0.1MF</td><td>10%</td><td>50V 25V</td></t1<>	RANSFOMER>					C165 C166	1-165-319- 1-164-004-	11 CERAM	IC CHIP (0.1MF	10%	50V 25V
T300 T500	1-406-781-1	COIL TRANSFORMER					C167 C168 C169	1-124-472- 1-124-472- 1-164-232-	11 ELECT		470MF 470MF 0.01MF	20% 20% 10%	1 OV 1 OV 5 OV
1501	_		,				C171 C172	1-163-251- 1-163-243-	-11 CERAM	IC CHIP	47PF	5% 5% 5%	50V 50V 50V
TH50	T> 0 1-807-970-1	HERMISTOR> 1 THERMISTOR					C173 C200 C201	1-163-243- 1-124-927- 1-106-383-	-11 ELECT		4.7MF 0.047MF	20% 10%	50V 100V
		RYSTAL>					C202 C203 C204	1-163-017- 1-124-927- 1-124-907-	-11 ELECT		0.0047MF 4.7MF 10MF	10% 20% 20%	50V 50V 50V

The components identified by shading and mark $\, \Delta \,$ are critical for safety. Replace only with part number specified.

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

REF.NO.	PART NO.				REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
C205 C206 C207 C208	1-124-360-00 1-126-375-11 1-124-478-11 1-124-907-11 1-124-927-11	ELECT ELECT ELECT ELECT	1000MF 100MF 100MF 10MF	20% 20% 20% 20%	16V 25V 25V 50V	C399 C400 C401 C402	1-124-477-11 1-164-232-11 1-164-346-11	CEDANIC CUID	0.011/15	20% 10%	25V 50V 16V
C209 C304 C305	1-124-927-11 1-164-004-11 1-163-125-00	CERAMIC CHIP	4.7MF 0.1MF	20% 10%		C402 C403 C406	1-164-232-11 1-164-346-11 1-124-910-11 1-164-232-11 1-124-916-11			20% 10% 20%	50V 50V 50V
C306 C311 C312	1-164-004-11 1-163-125-00 1-163-031-11 1-163-809-11 1-124-925-11	CERAMIC CHIP CERAMIC CHIP ELECT	0.01MF 0.047MF 2.2MF	10% 20%	50V 25V 50V	C407 C408 C409 C410	1-124-477-11 1-164-232-11 1-163-031-11 1-124-916-11	ELECT CERAMIC CHIP CERAMIC CHIP	47MF 0.01MF 0.01MF	20% 10%	25V 50V 50V 50V
C313 C314 C315 C316 C318	1-124-923-11 1-163-145-00 1-163-249-11 1-124-907-11 1-124-477-11 1-124-907-11	CERAMIC CHIP CERAMIC CHIP ELECT ELECT ELECT	0.0015MF 82PF 10MF 47MF 10MF	5% 5% 20% 20% 20%	50V 50V 50V 25V 50V	C411 C414 C415 C416	1-164-004-11 1-163-031-11 1-124-907-11 1-164-232-11	ELECT CERAMIC CHIP	O.UIMF 10MF O.OIMF	20% 10% 20% 10%	50V 50V 50V 50V
C326 C343	1-164-004-11 1-163-031-11	CERAMIC CHIP	0.1MF 0.01MF	10%	25V 50V	C417	1-164-232-11 1-164-182-11	CERAMIC CHIP	0.01MF 0.0033MF	10% 10%	50V 50V
C349 C350 C352	1-164-004-11 1-163-031-11 1-163-141-00 1-163-141-00 1-163-031-11	CERAMIC CHIP CERAMIC CHIP	0.001MF 0.001MF 0.01MF	5% 5%	50V 50V 50V	C419 C420 C421 C422	1~164-222-11 1-124-903-11	ELECT CERAMIC CHIP CERAMIC CHIP ELECT	0.22MF 1MF	20% 10% 20%	10V 25V 25V 50V
C353 C354 C355 C356 C358	1-165-319-11 1-163-121-00 1-124-903-11 1-124-927-11 1-163-031-11	CERAMIC CHIP CERAMIC CHIP ELECT ELECT CERAMIC CHIP	0.1MF 150PF 1MF 4.7MF 0.01MF	5% 20% 20%	50V 50V 50V 50V 50V	C423 C424 C425 C426	1-163-809-11	CERAMIC CHIE CERAMIC CHIE CERAMIC CHIE CERAMIC CHIE	0.047MF		25V 25V 50V 50V
C359 C360 C361	1-124-477-11 1-164-232-11 1-163-031-11 1-163-031-11 1-163-099-00	ELECT CERAMIC CHIP CERAMIC CHIP	47MF 0.01MF 0.01MF	20% 10%	25V 50V 50V	C427 C428 C429 C430		CERAMIC CHIE CERAMIC CHIE ELECT			50V 16V 50V
C362 C363						C431 C432	1-124-119-00 1-165-319-11 1-164-004-11	CERAMIC CHIE ELECT CERAMIC CHIE CERAMIC CHIE CERAMIC CHIE	330MF 0.1MF 0.1MF	20% 10%	16V 50V 25V
C365 C366 C367 C368	1-106-343-00 1-163-031-11 1-163-031-11 1-124-907-11	CERAMIC CHIP MYLAR CERAMIC CHIP CERAMIC CHIP ELECT	0.001MF 0.001MF 0.01MF 0.01MF 10MF	10% 20%	50V 100V 50V 50V 50V	C433 C434 C435 C436		CERAMIC CHII CERAMIC CHII CERAMIC CHII CERAMIC CHII			50V 50V 50V 25V
C369 C370 C371 C372	1-164-298-11 1-124-477-11 1-124-477-11 1-163-031-11	CERAMIC CHIF ELECT ELECT CERAMIC CHIF CERAMIC CHIF	0.15MF 47MF 47MF 0.01MF	10% 20% 20%	25V 25V 25V 50V	C437 C438 C439 C440	1-163-809-11 1-163-809-11 1-163-031-11	CERAMIC CHIL	0.047MF	10%	25V 25V 50V
C373 C374 C375	1-163-141-00 1-124-903-11	ELECT	1MF	5% 20%	50V 50V 50V	C441 C442 C443	1-126-962-11 1-163-809-11 1-163-243-11	CERAMIC CHI	3.3MF 0.047MF 47PF	20% 10% 5%	50V 25V 50V
C376 C377 C378	1-124-902-00 1-163-809-11 1-163-809-11	ELECT CERAMIC CHII ELECT CERAMIC CHII CERAMIC CHII	0.47MF P 0.047MF P 0.047MF	20% 10% 10%	50V 25V 25V	C444 C445 C446 C447	1-165-319-11 1-163-809-11 1-163-089-00 1-163-263-11	CERAMIC CHI CERAMIC CHI CERAMIC CHI CERAMIC CHI	P 0.1MF P 0.047MF P 6PF P 330PF	10% 0.25PF 5%	50V 25V 50V 50V
C379 C380 C381 C382 C383	1-163-031-11 1-124-472-11 1-163-031-11 1-163-243-11 1-124-477-11	CERAMIC CHIL CERAMIC CHIL	470MF P 0.01MF	20% 5% 20%	50V 10V 50V 50V 25V	C448 C449 C450 C451	1-163-243-11 1-163-227-11 1-163-809-11 1-164-004-11	CERAMIC CHI	P 10PF P 0.047MF	5% 0.5PF 10% 10%	50V 50V 25V 25V
C384 C385 C386	1-163-249-11 1-124-477-11	CERAMIC CHI	P 82PF 47MF	5% 20%	50V 25V	C452 C453	1-163-263-11 1-163-031-11	CERAMIC CHI CERAMIC CHI	P 330PF P 0.01MF	5%	50V 50V
C387 C388	1-124-907-11 1-163-141-00 1-124-907-11	CERAMIC CHI ELECT	10MF	20% 5% 20%	50V 50V 50V	C454 C455 C456 C457	1-163-243-11 1-163-263-11 1-163-089-00 1-163-031-11	CERAMIC CHI CERAMIC CHI CERAMIC CHI	P 330PF P 6PF P 0.01MF	5% 5% 0.25PF	50V 50V 50V 50V
C390 C391 C392 C393	1-163-243-11 1-124-477-11 1-164-298-11 1-164-298-11	ELECT CERAMIC CHI CERAMIC CHI	47MF P 0.15MF P 0.15MF	5% 20% 10% 10%	50V 25V 25V 25V	C458 C459 C460	1-163-249-11 1-165-319-11 1-164-004-11	CERAMIC CHI CERAMIC CHI CERAMIC CHI	P 82PF P 0.1MF P 0.1MF	5% 10%	50V 50V 25V
C394 C395 C396	1-124-477-11 1-163-235-11 1-164-299-11	CERAMIC CHI		20% 5% 10%	25V 50V 25V	C461 C462 C463	1-163-119-00 1-163-031-11 1-163-031-11	CERAMIC CHI	P 0.01MF	5%	50V 50V 50V
C397 C398	1-124-477-11 1-124-477-11	ELECT	47MF 47MF	20% 20% 20%	25V 25V 25V	C464 C465	1-164-299-11 1-163-097-00			10% 5%	25V 50V

The components identified by shading and mark \triangle are critical for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

REF.NO.	PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
C466	1-163-119-00			50V	C541	1-124-927-11	ELECT	4.7MF	20%	50V
C467 C469 C470 C471	1-163-119-00 1-163-037-11 1-163-243-11 1-163-105-00	CERAMIC CHIP 120PF CERAMIC CHIP 120PF CERAMIC CHIP 0.022MF CERAMIC CHIP 47PF CERAMIC CHIP 33PF	5% 10% 5% 5%	50V 25V 50V 50V	C542 C543 C544 C545 C547	1-106-351-00 1-106-351-00 1-106-367-00 1-102-212-00 1-102-251-11	MYLAR MYLAR MYLAR CERAMIC	0.0022MF 0.0022MF 0.01MF 820PF	10% 10% 10% 10%	100V 100V 100V 500V
C472 C473 C475 C476 C477	1-163-031-11 1-163-031-11 1-163-031-11	CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.22MF	10%	50V 50V 50V 50V 25V	C548 C549 C550	1-102-212-00 1-124-667-11 1-126-163-11	CERAMIC ELECT ELECT	820PF 10MF 4.7MF	5% 10% 20% 20%	50V 500V 50V 50V
C478 C479 C482 C483 C484	1-124-472-11 1-163-249-11	ELECT 10MF CERAMIC CHIP 150PF ELECT 470MF CERAMIC CHIP 82PF CERAMIC CHIP 68PF	20% 5% 20% 5%	50V 50V 10V 50V 50V	C551 C552 C556 C557 C558 C559	1-106-375-12 1-126-336-11 1-124-907-11 1-106-381-12 1-124-903-11 1-136-173-00 1-136-159-00	ELECT	0.022MF 220MF 10MF 0.039MF 1MF 0.47MF 0.033MF	10% 20% 20% 10% 20%	100V 25V 50V 100V 50V
C485 C486 C487 C488	1-163-113-00 1-163-249-11 1-163-235-11	CERAMIC CHIP 68PF CERAMIC CHIP 82PF CERAMIC CHIP 22PF CERAMIC CHIP 15PF CERAMIC CHIP 0.33MF		50V 50V 50V 50V	C559 C561 C562 C564				5% 5% 5% 20%	50V 50V 50V 50V
C490 C491 C492	1-164-336-11 1-164-336-11 1-164-336-11		10%	25V 25V 25V	C565 C566 C568	1-163-249-11 1-124-907-11 1-124-903-11 1-106-367-00 1-124-903-11			20% 10% 20%	50V 100V 50V
C493 C494 C495	1-104-760-11 1-124-907-11	ELECT 10MF	10% 10% 20%	50V 50V 50V 50V	C569 C570 C571 C572 C573	1~124-360-00	CERAMIC CHIP	1000MF	10% 20% 10% 0 5%	25V 16V 50V 160V 50V
C498 C499 C500 C501	1-124-925-11 1-163-031-11 1-164-004-11 1-164-182-11	CERAMIC CHIP 0.01MF	20% 10% 10%	50V 50V 25V 50V	C574 C575 C576 C577 C578	1-249-383-11	CARBON CERAMIC CHIP	1.5 5%	1/4W 10% 20%	
C502 C503 C504 C505 C506	1-163-251-11 1-136-175-00 1-163-135-00	CERAMIC CHIP 0.001MF CERAMIC CHIP 100PF FILM 0.068MF CERAMIC CHIP 560PF ELECT 0.47MF	5% 5% 5% 20%	50V 50V 50V 50V 50V	C578 C579 C580 C581	1-136-540-11 1-126-804-11 1-136-756-11 1-124-927-11 1-102-002-00 1-136-569-11			5% 20% 5% 20%	200V 50V 200V 50V
C507 C508 C509	1-126-375-11 1-130-495-00 1-124-935-11	ELECT 100MF MYLAR 0.1MF ELECT 470MF	20% 5% 20%	25V 50V 100V	C582 C583				10% 5% 20%	500V 200V 160V
C511 C512 C513 C514	1-108-700-11 1-124-902-00 1-126-096-11 1-129-718-00	MYLAR 0.047MF ELECT 0.47MF ELECT 10MF FILM 0.022MF	10% 20% 20%	200V 50V 25V 630V	C585 C586 C587 C588		ELECT ELECT ELECT CERAMIC ELECT		20% 20% 10% 20%	250V 25V 500V 50V
C515 C516 C517	1-163-809-11 1-102-030-00 1-163-024-00	CERAMIC CHIP 0.047MF CERAMIC 330PF CERAMIC CHIP 0.018MF	10%	25V 500V 50V	C589 C590 C591 C592	1-102-030-00 1-126-387-11 1-106-371-00 1-123-932-00	CERAMIC ELECT MYLAR ELECT	330PF 2.2MF 0.015MF 4.7MF	10% 20% 10% 20%	500V 50V 200V 160V
C518 C519 C520 C521 C522	1-107-995-51 1-163-017-00 1-163-257-11 1-162-114-00 1-126-375-11	ELECT 100MF CERAMIC CHIP 0.0047MF CERAMIC CHIP 180PF CERAMIC 0.0047MF ELECT 100MF	0 10% 5% 20%	160V 50V 50V 2KV 25V	C593 C594 C595 C596 C597	1-165-319-11	CERAMIC CHII ELECT ELECT	P 12PF 220MF 100MF	5% 20% 20%	50V 50V 25V 25V 16V
C526 C529	1-126-801-11 A 1-136-545-11 A 1-162-116-91 1-104-789-51	ELECT 1MF F1LM 0.0078MF CERAMIC 680PF ELECT 0.47MF	20% 3% 10% 20%	50V 2KV 2KV 50V	C598 C599 C1300	1-164-346-11 1-126-157-11 1-124-477-11	CERAMIC CHII ELECT ELECT	P 1MF 10MF 47MF	20% 20%	16V 16V 25V
C530 C531 C532 C533	1-124-120-11 1-124-477-11 1-163-031-11 1-102-212-00	ELECT 220MF ELECT 47MF CERAMIC CHIP 0.01MF CERAMIC 820PF	20% 20% 10%	25V 25V 50V 500V	C1302 C1303 C1305	1-164-004-11 1-124-477-11	CERAMIC CHIL	P 0.1MF 47MF	5% 10% 20%	50V 25V 25V 50V
C534 C535	1-123-948-00 1-163-125-00 1-124-913-11	ELECT 22MF CERAMIC CHIP 220PF ELECT 470MF	20% 5% 20%	250V 50V 50V	C1308 C1311 C1313 C1314	1-124-907-11 1-124-477-11 1-163-031-11	ELECT ELECT CERAMIC CHI	10MF 47MF	20% 20% 20%	50V 50V 25V 50V 25V
C537 C538 C539 C540	1-106-367-00 1-130-480-00 1-163-133-00	MYLAR 0.01MF FILM 0.0056MF	10% 5% 5%	100v 50v 50v	C1316 C1317	1-163-031-11	CERAMIC CHI		20%	50V 25V

REF.NO. PART NO. DESCRIPTION REMARK SEP.NO. PART NO. DESCRIPTION DESCRIPTI			-									
C1322 1-163-031-11 CERANIC CHIP 0.01MF C1324 1-163-031-11 CERANIC CHIP 0.01MF C1325 1-163-031-11 CERANIC CHIP 0.01MF C1326 1-163-031-11 CERANIC CHIP 0.01MF C1327 1-163-031-11 CERANIC CHIP 0.01MF C1328 1-163-031-11 CERANIC CHIP 0.01MF C1329 1-124-097-11 ELECT 47MF C1320 1-124-						REMARK	REF.NO.	PART NO.	DESCRIPTION	l -		REMARK
C1322 1-163-031-11 CERANIC CHIP 0.01MF C1324 1-163-031-11 CERANIC CHIP 0.01MF C1325 1-163-031-11 CERANIC CHIP 0.01MF C1326 1-163-031-11 CERANIC CHIP 0.01MF C1327 1-163-031-11 CERANIC CHIP 0.01MF C1328 1-163-031-11 CERANIC CHIP 0.01MF C1329 1-124-097-11 ELECT 47MF C1320 1-124-	C1318	1-124-477-11	ELECT CHIP	47MF	20%	25V	C1517	1-126-101-11	ELECT	100MF	20%	107
C1326 -163-031-11 CERAMIC CRIP P. 0.119F 201				A 1 (1)	20%	250	C1518 C1519	1-124-477-11 1-163-037-11	ELECT CERAMIC CHIE	47MF 0.022MF	20% 10%	
C1329	C1323 C1324	1-163-031-11	CERAMIC CHIP	0.01MF				< CON	NECTOR>			
C1392 -124-907-11 ELECT OMNE CORP CONSECTOR 7P PLUG, CONNECTOR 7P PLUG C	C1326 C1327	1-124-477-11 1-163-031-11	ELECT CERAMIC CHIP	47MF 0.01MF 0.01MF		25V 50V	CN102 CN201	*1-564-514-11 *1-564-506-11	PLUG, CONNEC PLUG, CONNEC	CTOR 11P CTOR 3P	RD 11P	
Class -124-477-1 ELECT 47MF 20% 25V CM011 -156-45-11-7 FUIG. CONNECTOR 2P CM022-477-11 ELECT 47MF 20% 25V CM012 -156-45-11-7 FUIG. CONNECTOR 2P CM022-477-11 ELECT 47MF 20% 25V CM012 -156-45-11-7 FUIG. CONNECTOR 2P CM022-477-11 ELECT 47MF 20% 25V CM012 -156-45-10-11 FUIG. CONNECTOR 3P CM022-477-11 ELECT 47MF 20% 25V CM022-477	C1329 C1330	1-124-907-11	CERAMIC CHIP	U UIME			CN302	*1-564-510-11	PLUG, CONNEC	TOR 7P		
C1334 1-163-031-11 CERAMIC CHIP 0.01HF 50V CN502 #1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P C1336 1-163-031-11 CERAMIC CHIP 0.01HF 50V CN504 #1-564-508-11 PINC, CONNECTOR (PC BOARD) 6P C1336 1-163-031-11 CERAMIC CHIP 0.01HF 50V CN504 #1-564-508-11 PINC, CONNECTOR (PC BOARD) 6P C1340 1-163-031-11 CERAMIC CHIP 0.01HF 50V CN504 #1-564-508-11 PINC, CONNECTOR (PC BOARD) 6P C1340 1-163-031-11 CERAMIC CHIP 0.01HF 50V CN504 #1-564-508-11 PINC, CONNECTOR PC BOARD) 6P C1340 1-163-030-10 CERAMIC CHIP PN 0.2545 50V C1341 1-163-038-00 CERAMIC CHIP PN 0.2545 50V C1343 1-163-038-10 CERAMIC CHIP PN 0.2545 50V C1343 1-163-038-11 CERAMIC CHIP PN 0.2545 50V C1343 1-163-031-11 CERAMIC CHIP PN 0.01HF 50V C1343 1-163-031-11 CERAMIC CHIP 2.054 50V C1355 1-163-125-00 CERAMIC CHIP 2.054 50V C1356 1-163-125-10 CERAMIC CHIP 2.054 50V C1356 1-164-161-1 CERAMIC CHIP 2.054 50V C1356 1-164-161-1 CERAMIC CHIP 2.074 5	C1331 C1332 C1333	1-124-477-11 1-124-477-11 1-124-477-11	ELECT ELECT ELECT	47MF 47MF 47MF		25V 25V	CN401 CN402	*1-564-511-51 *1-564-515-11	PLUG, CONNEC	CTOR 8P CTOR 12P	RD 13P	
C1340 1-163-031-11 CERANIC CHIP 0.01MF 50 C1341 1-163-039-00 CERANIC CHIP 10MF 20X 50V C1345 1-124-907-11 ELECT 30MF 50 C1355 1-163-135-00 CERANIC CHIP 10MF 20X 50V C1355 1-163-135-00 CERANIC CHIP 10MF 20X 50V C1356 1-163-125-00 CERANIC CHIP 20MF 50 C1356 1-163-125-10 CERANIC CHIP 20MF 50 C1356 1-163-125-10 CERANIC CHIP 20MF 50 C1356 1-163-125-10 CERANIC CHIP 20MF 50 C1356 1-163-255-11 CERANIC CHIP 20MF 50 C1356 1-163-255-10 CERANIC CHIP 20MF	C1334 C1335	1-163-227-11 1-124-477-11	CERAMIC CHIP	10PF 47MF	0.5PF 20%	258	CN502	*1-573-964-11	PIN, CONNECT	TOR (PC BOAR	D) 6P	
C1340 1-163-031-11 CERAMIC CHIP 0.01MF C1353 1-163-031-11 CERAMIC CHIP 150PF C1355 1-163-125-00 CERAMIC CHIP 150PF C1355 1-163-255-10 CERAMIC CHIP 22PF C1357 1-124-117-00 ELECT C1358 1-163-255-10 CERAMIC CHIP 22PF C1358 1-163-255-10 CERAMIC CHIP 23PF C1359 1-163-253-11 CERAMIC CHIP 20PF C1350 1-163-253-11 CERAMIC CHIP 0.0022MF C1350 1-163-253-11 CERAMIC CHIP 0.0022MF C1350 1-163-253-11 CERAMIC CHIP 0.0022MF C1350 1-163-263-11 CERAMIC CHIP 0.0022MF C1350 1-163-273-11 ELECT C1350 1-124-477-11 CERAMIC CHIP 0.0022MF C1350 1-124-477-11 CERAMIC CHIP 0.0022MF C1350 1-124-477-11 CERAMIC CHIP 0.002MF C1350 1-124-479-11 CERAMIC CHIP 0.002MF C1350 1-124-479-11 CERAMIC CHI	C1336 C1338 C1339	1-124-477-11 1-163-031-11 1-163-031-11				25V 50V 50V	CN504	*1-564-508-11 *1-564-506-11	PLUG, CONNEC	CTOR 5P CTOR 3P	D) 6P	
C1354 1-163-121-00	C1340 C1342	1-163-031-11	CERAMIC CHIP	0.01MF 33PF	5%	50V 50V	CN507	*1-535-419-00	TAB, FASTEN	(PCB)		
C1354 1-163-121-00	C 1344 C 1345	1-163-083-00 1-124-907-11	CERAMIC CHIP ELECT CERAMIC CHIP			50V 50V 50V	CD2O2				4)	
C1359 1-163-263-11 CERAMIC CHIP 330PF 5% 50V C1360 1-164-161-11 CERAMIC CHIP 0.0022MF 10% 50V C1360 1-164-161-11 CERAMIC CHIP 0.05PF 50V C1365 1-163-227-11 CERAMIC CHIP 10PF 0.5PF 50V C1365 1-163-227-11 CERAMIC CHIP 10PF 0.5PF 50V C1366 1-124-477-11 ELECT 47MF 20% 25V D1107 8-719-800-76 D10DE ISS226 D107 8-719-404-46 D10DE MAI10 D107 D107 D107 D107 D107 D107 D107 D1	C1354	1-163-121-00	CERAMIC CHIP	150PF	5% 5%	50V 50V	1 (17303	1-400-102-01	FILIER BLUC	K, COM (CPB-	4)	
C1359 1-163-263-11 CERAMIC CHIP 330PF 5% 50V C1360 1-164-161-11 CERAMIC CHIP 0.0022MF 10% 50V C1360 1-164-161-11 CERAMIC CHIP 0.05PF 50V C1365 1-163-227-11 CERAMIC CHIP 10PF 0.5PF 50V C1365 1-163-227-11 CERAMIC CHIP 10PF 0.5PF 50V C1366 1-124-477-11 ELECT 47MF 20% 25V D1107 8-719-800-76 D10DE ISS226 D107 8-719-404-46 D10DE MAI10 D107 D107 D107 D107 D107 D107 D107 D1	C 1356	1-163-235-11	CERAMIC CHIP	22PF 330MF	5% 20%	50V						
C1359 1-163-263-11 CERAMIC CHIP 300PF 5% 50V D103 8-719-045-70 D10DE ISS226 C1363 1-163-235-11 CERAMIC CHIP 20PF 5% 50V D105 8-719-800-76 D10DE ISS226 C1363 1-163-225-11 CERAMIC CHIP 10PF 20% 25V D107 8-719-800-76 D10DE ISS226 C1365 1-124-477-11 ELECT 47MF 20% 25V D110 8-719-801-78 D10DE ISS226 C1372 1-124-477-11 ELECT 47MF 20% 25V D110 8-719-801-78 D10DE ISS226 D107 8-719-801-74 D10DE ISS226 D107 8-719-801-74 D10DE ISS226 D107 8-719-801-74 D	C 1358	1-124-477-11	ELECT			25V	D101	8-719-800-76	DIODE 18822	6		
C1366 1-124-477-11 ELECT 47MF 20X 25V 0100 8-719-801-78 0100E 15S184 C1372 1-124-477-11 ELECT 47MF 20X 25V 0110 8-719-801-78 0100E 15S184 C1373 1-124-477-11 ELECT 47MF 20X 25V 0110 8-719-801-78 0100E MA110 C1373 1-124-477-11 ELECT 47MF 20X 25V 0112 8-719-404-46 0100E MA110 C1374 1-124-477-11 ELECT 47MF 20X 25V 0113 8-719-180-70 0100E RD4.7SB C1375 1-124-927-11 ELECT 47MF 20X 50V 025V 025V 025V 025V 025V 025V 025V	C 1360 C 1363 C 1365	1-164-161-11 1-163-235-11 1-163-227-11	CERAMIC CHIF CERAMIC CHIF CERAMIC CHIF	330PF 0.0022MF 22PF 10PF	5% 10% 5% 0.5PF	50V 50V	D104	8-719-045-70 8-719-800-76	DIODE 1SV23 DIODE 1SS22	ОТРНЗ 6		
C1400 1-163-031-11 CERAMIC CHIP 0.01MF 5% 50V D301 8-719-404-46 D10DE MA110 C1401 1-136-173-00 FILM 0.47MF 5% 50V D302 8-719-158-07 D10DE ISS226 C1403 1-163-031-11 CERAMIC CHIP 0.01MF 5% 50V D305 8-719-800-76 D10DE ISS226 C1403 1-164-299-11 CERAMIC CHIP 0.22MF 10% 25V D307 8-719-404-46 D10DE MA110 C1407 1-163-035-01 CERAMIC CHIP 22PF 5% 50V D311 8-719-404-46 D10DE MA110 C1407 1-163-089-00 CERAMIC CHIP 22PF 5% 50V D312 8-719-404-46 D10DE MA110 C1407 1-163-089-00 CERAMIC CHIP 2PF 0.25PF 50V D313 8-719-404-46 D10DE MA110 C1407 1-163-085-00 CERAMIC CHIP 2PF 0.25PF 50V D313 8-719-404-46 D10DE MA110 C1500 1-124-473-11 ELECT 1000MF 20% 10V D313 8-719-404-46 D10DE MA110 C1501 1-124-473-11 ELECT 470MF 20% 10V D320 8-719-404-46 D10DE MA110 C1503 1-164-004-11 CERAMIC CHIP 0.1MF 10% 25V D320 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1508 1-124-19-00 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1508 1-124-19-01 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE IS2836 C1510 1-124-927-11 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE IS2836 C1511 1-164-182-11 CERAMIC CHIP 0.003MF 5% 50V D346 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477	C1366	1-124-477-11	ELECT	47MF		257		8-719-801-78				
C1400 1-163-031-11 CERAMIC CHIP 0.01MF 5% 50V D301 8-719-404-46 D10DE MA110 C1401 1-136-173-00 FILM 0.47MF 5% 50V D302 8-719-158-07 D10DE ISS226 C1403 1-163-031-11 CERAMIC CHIP 0.01MF 5% 50V D305 8-719-800-76 D10DE ISS226 C1403 1-164-299-11 CERAMIC CHIP 0.22MF 10% 25V D307 8-719-404-46 D10DE MA110 C1407 1-163-035-01 CERAMIC CHIP 22PF 5% 50V D311 8-719-404-46 D10DE MA110 C1407 1-163-089-00 CERAMIC CHIP 22PF 5% 50V D312 8-719-404-46 D10DE MA110 C1407 1-163-089-00 CERAMIC CHIP 2PF 0.25PF 50V D313 8-719-404-46 D10DE MA110 C1407 1-163-085-00 CERAMIC CHIP 2PF 0.25PF 50V D313 8-719-404-46 D10DE MA110 C1500 1-124-473-11 ELECT 1000MF 20% 10V D313 8-719-404-46 D10DE MA110 C1501 1-124-473-11 ELECT 470MF 20% 10V D320 8-719-404-46 D10DE MA110 C1503 1-164-004-11 CERAMIC CHIP 0.1MF 10% 25V D320 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1508 1-124-19-00 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1508 1-124-19-01 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE IS2836 C1510 1-124-927-11 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE IS2836 C1511 1-164-182-11 CERAMIC CHIP 0.003MF 5% 50V D346 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477	C1372	1-124-477-11	ELECT ELECT	47MF 47MF	20% 20%	25V	D112	8-719-404-46	DIODE MA110			
C1400 1-163-031-11 CERAMIC CHIP 0.01MF 5% 50V D301 8-719-404-46 D10DE MA110 C1401 1-136-173-00 FILM 0.47MF 5% 50V D302 8-719-158-07 D10DE ISS226 C1403 1-163-031-11 CERAMIC CHIP 0.01MF 5% 50V D305 8-719-800-76 D10DE ISS226 C1403 1-164-299-11 CERAMIC CHIP 0.22MF 10% 25V D307 8-719-404-46 D10DE MA110 C1407 1-163-035-01 CERAMIC CHIP 22PF 5% 50V D311 8-719-404-46 D10DE MA110 C1407 1-163-089-00 CERAMIC CHIP 22PF 5% 50V D312 8-719-404-46 D10DE MA110 C1407 1-163-089-00 CERAMIC CHIP 2PF 0.25PF 50V D313 8-719-404-46 D10DE MA110 C1407 1-163-085-00 CERAMIC CHIP 2PF 0.25PF 50V D313 8-719-404-46 D10DE MA110 C1500 1-124-473-11 ELECT 1000MF 20% 10V D313 8-719-404-46 D10DE MA110 C1501 1-124-473-11 ELECT 470MF 20% 10V D320 8-719-404-46 D10DE MA110 C1503 1-164-004-11 CERAMIC CHIP 0.1MF 10% 25V D320 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1508 1-124-19-00 ELECT 330MF 20% 16V D322 8-719-404-46 D10DE MA110 C1508 1-124-19-01 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE IS2836 C1510 1-124-927-11 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE IS2836 C1511 1-164-182-11 CERAMIC CHIP 0.003MF 5% 50V D346 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D340 8-719-104-34 D10DE IS2836 C1514 1-130-477	C1374	1-124-477-11	ELECT ELECT	47MF 47MF	20% 20%	251						
C1405 1-163-235-11 CERAMIC CHIP 22PF 5% 50V C1406 1-163-090-00 CERAMIC CHIP 7PF 0.25PF 50V C1407 1-163-085-00 CERAMIC CHIP 2PF 0.25PF 50V C1500 1-124-473-11 ELECT 1000MF 20% 10V C1501 1-124-473-11 ELECT 1000MF 20% 10V C1502 1-101-821-00 CERAMIC 0.0022MF 500V C1503 1-164-004-11 CERAMIC CHIP 0.1MF 10% 25V C1504 1-124-907-11 ELECT 330MF 20% 16V C1506 1-124-119-00 ELECT 330MF 20% 16V C1508 1-124-927-11 ELECT 4.7MF 20% 50V C1510 1-124-927-11 ELECT 4.7MF 20% 50V C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 20% 50V C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 5% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1516 1-124-907-11 ELECT 4.7MF 20% 50			ELECI				D300	8-719-977-46 8-719-025-07	DIODE DTZ13 DIODE 1SV23	2-TPH3		
C1405 1-163-235-11 CERAMIC CHIP 22PF 5% 50V C1406 1-163-090-00 CERAMIC CHIP 7PF 0.25PF 50V C1407 1-163-085-00 CERAMIC CHIP 2PF 0.25PF 50V C1500 1-124-473-11 ELECT 1000MF 20% 10V C1501 1-124-473-11 ELECT 1000MF 20% 10V C1502 1-101-821-00 CERAMIC 0.0022MF 500V C1503 1-164-004-11 CERAMIC CHIP 0.1MF 10% 25V C1504 1-124-907-11 ELECT 330MF 20% 16V C1506 1-124-119-00 ELECT 330MF 20% 16V C1508 1-124-927-11 ELECT 4.7MF 20% 50V C1510 1-124-927-11 ELECT 4.7MF 20% 50V C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 20% 50V C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 5% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1516 1-124-907-11 ELECT 4.7MF 20% 50	C1401	1-136-173-00	FILM	0.47MF	5%	50V	D302	8-719-158-07	DIODE RD4.7	SB		
C1405 1-163-235-11 CERAMIC CHIP 22PF 5% 50V C1406 1-163-090-00 CERAMIC CHIP 7PF 0.25PF 50V C1407 1-163-085-00 CERAMIC CHIP 2PF 0.25PF 50V C1500 1-124-473-11 ELECT 1000MF 20% 10V C1501 1-124-473-11 ELECT 1000MF 20% 10V C1502 1-101-821-00 CERAMIC 0.0022MF 500V C1503 1-164-004-11 CERAMIC CHIP 0.1MF 10% 25V C1504 1-124-907-11 ELECT 330MF 20% 16V C1506 1-124-119-00 ELECT 330MF 20% 16V C1508 1-124-927-11 ELECT 4.7MF 20% 50V C1510 1-124-927-11 ELECT 4.7MF 20% 50V C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 20% 50V C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 5% 50V C1515 1-124-907-11 ELECT 4.7MF 20% 50V C1516 1-124-907-11 ELECT 4.7MF 20% 50	C1403	1-136-173-00	FILM	0.47MF	5% 10%	50V	i					
C1406 1-163-090-00 CERAMIC CHIP 2PF							D309	8-719-404-46	DIODE MA110			
C1408	C1406	1-163-090-00	CERAMIC CHI	7PF	0.25PF	507	D312	8-719-404-46	DIODE MAILO	!		
C1501 1-124-472-11 ELECT 470MF 20% 10V D320 8-719-404-46 D10DE MA110 C1502 1-101-821-00 CERAMIC CHIP 0.1MF 10% 25V D323 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 10MF 20% 50V C1506 1-124-119-00 ELECT 330MF 20% 16V D327 8-719-104-34 D10DE IS2836 C1507 1-163-141-00 CERAMIC CHIP 0.001MF 5% 50V D338 8-719-404-46 D10DE MA110 C1508 1-124-927-11 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE 1S2836 C1510 1-124-927-11 ELECT 4.7MF 20% 50V D346 8-719-104-34 D10DE 1S2836 C1511 1-164-182-11 CERAMIC CHIP 0.003MF 10% 50V D346 8-719-104-34 D10DE 1S2836 C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V D361 8-719-104-34 D10DE 1S2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D361 8-719-104-34 D10DE 1S2836 C1515 1-124-907-11 ELECT 4.7MF 20% 50V D361 8-719-104-34 D10DE 1S2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D361 8-719-104-34 D10DE 1S2836 C1515 1-124-907-11 ELECT 10MF 20% 50V D361 8-719-104-34 D10DE 1S2836 C1515 1-124-907-11 ELECT 10MF 20% 50V D361 8-719-104-34 D10DE 1S2836 C1515 1-124-907-11 ELECT 10MF 20% 50V D361 8-719-104-34 D10DE 1S2836 C1515 1-124-907-11 ELECT 10MF 20% 50V D361 8-719-104-34 D10DE MA110	C1408	1-163-113-00	CERAMIC CHI	P 68PF	5%	507	D315	8-719-404-46	DIODE MAILO) 		
C1503 1-164-004-11 CERAMIC CHIP 0.1MF 10% 25V D323 8-719-404-46 D10DE MA110 C1504 1-124-907-11 ELECT 10MF 20% 50V D327 8-719-104-34 D10DE 152836 D332 8-719-404-46 D10DE MA110 C1507 1-163-141-00 CERAMIC CHIP 0.001MF 5% 50V D345 8-719-404-46 D10DE MA110 C1508 1-124-927-11 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE 152836 C1510 1-124-927-11 ELECT 4.7MF 20% 50V D346 8-719-104-34 D10DE 152836 C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 10% 50V C1512 1-124-927-11 ELECT 4.7MF 20% 50V D347 8-719-104-34 D10DE 152836 C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V D347 8-719-104-34 D10DE 152836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D361 8-719-104-34 D10DE 152836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D381 8-719-104-34 D10DE MA110 C1515 1-124-907-11 ELECT 10MF 20% 50V D361 8-719-104-34 D10DE MA110 C1515 1-124-907-11 ELECT 10MF 20% 50V D381 8-719-404-46 D10DE MA110					20%		D320	8-719-404-46	DIODE MA110	1		
C1506 1-124-119-00 ELECT 330MF 20% 16V D327 8-719-104-34 D10DE 1S2836 C1507 1-163-141-00 CERAMIC CHIP 0.001MF 5% 50V D338 8-719-404-46 D10DE MA110 C1508 1-124-927-11 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE 1S2836 C1510 1-124-927-11 ELECT 4.7MF 20% 50V D346 8-719-104-34 D10DE 1S2836 C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 10% 50V D346 8-719-104-34 D10DE 1S2836 C1512 1-124-927-11 ELECT 4.7MF 20% 50V D347 8-719-104-34 D10DE 1S2836 C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V D361 8-719-104-34 D10DE 1S2836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D361 8-719-104-34 D10DE 1S2836 C1515 1-124-907-11 ELECT 10MF 5% 50V D381 8-719-404-46 D10DE MA110	C1503	1-164-004-11	CERAMIC CHI	P 0.1MF	10%	25V	D322					
C1507 1-163-141-00 CERAMIC CHIP 0.001MF 5% 50V D345 8-719-104-34 D10DE M3110 C1508 1-124-927-11 ELECT 4.7MF 20% 50V D345 8-719-104-34 D10DE 152836 C1510 1-124-927-11 ELECT 4.7MF 20% 50V D346 8-719-104-34 D10DE 152836 C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 10% 50V C1512 1-124-927-11 ELECT 4.7MF 20% 50V D347 8-719-104-34 D10DE 152836 C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V D361 8-719-104-34 D10DE 152836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D361 8-719-104-34 D10DE 152836 C1515 1-124-907-11 ELECT 10MF 20% 50V D381 8-719-404-46 D10DE M3110							D327	8-719-104-34 8-719-404-46				
C1510 1-124-927-11 ELECT 4.7MF 20% 50V D346 8-719-104-34 D10DE 1\$\frac{1}{2}2836\$ C1511 1-164-182-11 CERAMIC CHIP 0.0033MF 10% 50V D347 8-719-104-34 D10DE 1\$\frac{1}{2}2836\$ C1512 1-124-927-11 ELECT 4.7MF 20% 50V D347 8-719-104-34 D10DE 1\$\frac{1}{2}2836\$ C1513 1-163-133-00 CERAMIC CHIP 470PF 5% 50V D361 8-719-104-34 D10DE 1\$\frac{1}{2}2836\$ C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D381 8-719-104-34 D10DE M3110 C1515 1-124-907-11 ELECT 10MF 20% 50V D401 8-719-404-46 D10DE M3110		1-163-141-00			5% 20%	50V 50V	; D338	8-719-404-46	DIODE MAILO	1		
C1512 1-124-927-11 ELECT 4.7MF 20% 50V D347 8-719-104-34 D10DE 152836 D360 8-719-104-34 D10DE 152836 D360 8-719-104-34 D10DE 152836 D361 8-719-104-34 D10DE 152836 D10DE 152836 D361 8-719-104-34 D10DE 152836 D10DE 152836 D361 8-719-404-46 D10DE MAILO D10DE MA	C1510	1-124-927-11 1-164-182-11	ELECT CERAMIC CHI	4.7MF	20%	50V	D346	8-719-104-34				
C1513 1-163-133-00 CERANIC CHIP 470PF 5% 50V D361 8-719-104-34 D10DE 152836 C1514 1-130-477-00 MYLAR 0.0033MF 5% 50V D381 8-719-404-46 D10DE MA110 C1515 1-124-907-11 ELECT 10MF 20% 50V D401 8-719-404-46 D10DE MA110	C1512	1-124-927-11	ELECT	4.7MF	20%	50V	D360	8-719-104-34	DIODE 15283	36		
	C1514 C1515	1-130-477-00 1-124-907-11	MYLAR Elect	0.0033MF 10MF	5% 20%	50V 50V	D381	8-719-404-46	DIODE 18283 DIODE MAILO	36)		

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
D404 D405 D406 D407 D408	8-719-800-76 8-719-801-78 8-719-404-46 8-719-404-46 8-719-404-46	DIODE 1SS226 DIODE 1SS184 DIODE MA110 DIODE MA110 DIODE MA110		IC101 IC102 IC103 IC104 IC105	8-759-196-71 8-759-168-37 8-759-008-48 8-759-262-59 8-759-196-70	IC UPD78013YCW-Y0 IC ST24C01B1 IC MC74HC86F IC UPD6451AGT-63: IC M62358FP-E1	2-E2
D410 D411 D414 D415 D416	8-719-404-46 8-719-404-46 8-719-801-78 8-719-801-78 8-719-801-78	DIODE MA110 DIODE MA110 DIODE 1SS184 DIODE 1SS184 DIODE 1SS184		IC106 IC107 IC108 IC109	8-759-196-70	1C M62358FP-E1 1C M62358FP-E1 1C S-80743AL-A7-1 1C M62358FP-E1	
D417 D418 D421 D422 D423	8-719-801-78 8-719-801-78 8-719-404-46 8-719-404-46 8-719-800-76	DIODE 1SS184 DIODE 1SS184 DIODE MA110 DIODE MA110 DIODE 1SS226		IC111 IC200 IC302 IC304 IC305	8-759-009-22 8-759-420-04 8-759-998-98 8-759-509-19 8-759-631-08	IC AN5265 IC LM358D IC XRU4053BF-E2	
D424 D425 D427 D500 D501	8-719-404-46 8-719-800-76 8-719-404-46 8-719-404-46 8-719-977-03	DIODE MAIIO DIODE 155226 DIODE MAIIO DIODE MAIIO DIODE DTZ5.6B		IC309 IC310 IC311	8-759-711-32 8-759-711-32 8-759-509-19 8-759-509-05 8-759-711-32	IC NJM2245M IC XRU4053BF-E2 IC XRU4066BF	
D502 D503 D504 D505 D506	8-719-979-80 8-719-404-46 8-719-901-83 8-719-028-72 8-719-945-80	DIODE UF5406 DIODE MA110 DIODE 1SS83 DIODE RGP02-17EL-6433 DIODE ERCO6-15S		1C314 1C318 1C320 1C321	8-759-048-09 8-759-501-21 8-759-509-57 8-759-501-21 8-759-501-21	IC MM1149XF IC XRU4584BF IC MM1149XF IC MM1149XF	
D507 D508 D510 D512 D513	8-719-302-43	DIODE UF5406		1C322 1C323 1C324 1C325 1C326	8-759-501-21 8-759-501-21	IČ MM1149XF IC MM1149XF	
D514 D515 D516 D517 D518	8-719-971-20 8-719-404-46 8-719-404-46	DIODE ERC38-06 DIODE ERC38-06 DIODE MA110 DIODE MA110 DIODE MA110		1C401 1C402 1C403	8-759-100-96 8-759-196-69 8-752-053-21 8-759-509-05 8-752-052-62	IC BA7655AF-E2 IC CXA1211M IC XRU4066BF	
D519 D520 D522 D523 D524	8-719-404-46 8-719-801-78 8-719-977-05 8-719-404-46 8-719-200-02	DIODE 1SS184 DIODE DTZ6.2 DIODE MA110		1C405 1C406 1C407 1C408 1C409	8-759-998-98	IC XRU4066BF IC XRA10393F	
D525 D526 D527 D528 D529	8-719-200-02 8-719-404-46 8-719-200-03 8-719-300-76 8-719-200-02	5 DIODE MA110 2 DIODE 10E-2 5 DIODE RH-1A		1C410 1C411 1C412 1C413 1C500	8-759-008-92 8-759-509-19	IC MC14024BF IC XRU4053BF-E2 IC XRU4053BF-E2	
D530 D531 D532 D533 D534	8-719-300-76 8-719-977-33 8-719-800-70 8-719-302-42 8-719-404-40	2 DIODE DT711B 6 DIODE 1SS226 3 DIODE EL17		1 C 5 O 2 1 C 5 O 3 1 C 5 O 4 1 C 5 O 5 1 C 5 O 7	8-759-009-51 8-752-053-21 8-759-520-07	IC MC14538BF IC CXA1211M IC XRA17812T	
D535 D536 D538 D539	8-719-404-44 8-719-800-74 8-719-800-74 8-719-404-4	6 DIODE 1SS226 6 DIODE 1SS226		10508 10509	8 8-752-053-21 9 8-759-998-98		
D540					<00	HL>	
DL30 DL30 DL40	0 1-415-633-1 1 1-415-632-1			L101 L102 L104 L300 L305	1-408-609-41 1-408-417-00 1-410-478-11 1-410-478-11 1-410-196-11	INDUCTOR INDUCTOR INDUCTOR	33UH 47UH 47UH 47UH 2.2UH
VL4V		C>		L308 L309 L311 L312	1-410-466-41 1-410-470-11 1-410-470-11 1-412-011-3	I INDUCTOR I INDUCTOR	4.7VH 10VH 10VH 27VH

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

REF.NO. PART	NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION		REMARK
L314 1-41 L316 1-41 L320 1-41 L401 1-41 L402 1-41	2-011-31 2-011-31 0-478-11 0-478-11 0-216-31	INDUCTOR CHIP 27UH INDUCTOR CHIP 27UH INDUCTOR 47UH INDUCTOR 47UH INDUCTOR CHIP 100UH INDUCTOR CHIP 100UH INDUCTOR CHIP 100UH INDUCTOR 68UH INDUCTOR 68UH INDUCTOR 22UH INDUCTOR 22UH INDUCTOR 22UH INDUCTOR 24TUH INDUCTOR 33MMH INDUCTOR 18UH INDUCTOR 18UH INDUCTOR 18UH INDUCTOR 27UH INDUCTOR 27UH INDUCTOR 33MMH INDUCTOR 1MMH INDUCTOR 37MH INDUCTOR 17MH INDUCTOR 37MH INDUCTOR 37MH INDUCTOR 37MH INDUCTOR 68UH INDUCTOR 68UH INDUCTOR 18UH INDUCTOR 37MH INDUCTOR 17MH INDUCTOR 68UH INDUCTOR 68UH INDUCTOR 68UH INDUCTOR 68UH		Q322 Q325 Q326 Q327	8-729-120-28 8-729-120-28 8-729-120-28 8-729-216-22	TRANSISTOR 2SO TRANSISTOR 2SO TRANSISTOR 2SO TRANSISTOR 2SO	C1623-L5L6 C1623-L5L6 C1623-L5L6 A1162-G	
L403 1-41 L404 1-41 L405 1-40 L406 1-40 L407 1-40	0-216-31 0-216-31 8-419-00 8-419-00 8-413-00	INDUCTOR CHIP 100UH INDUCTOR CHIP 100UH INDUCTOR 68UH INDUCTOR 68UH INDUCTOR 22UH		Q330 Q331 Q333 Q341	8-729-216-22 8-729-216-22 8-729-120-28 8-729-920-39	TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 1MT	K94-X2X3X4 A1162-G A1162-G C1623-L5L6 T1US	
L408 1-40 L409 1-41 L500 1-45 L501 1-40 L502 1-40	8-413-00 0-214-31 9-155-00 7-365-00 7-365-00	INDUCTOR 22UH INDUCTOR CHIP 68UH COIL (WITH CORE) 45UH COIL, CHOKE COIL, CHOKE		Q345 Q350 Q351	8-729-920-39 8-729-920-39 8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR IMT TRANSISTOR 2SO TRANSISTOR 2SO TRANSISTOR 2SO	TIUS TIUS C1623-L5L6 A1162-G C1623-L5L6	
L503 1-410 L504 1-410 L505 1-410 L507 1-410 L508 1-410	0-093-11 0-666-31 0-671-31 0-686-11 2-530-31	INDUCTOR 33MMH INDUCTOR 18UH INDUCTOR 47UH INDUCTOR 1MMH INDUCTOR 27UH		Q353 Q354 Q360 Q361	8-729-120-28 8-729-120-28 8-729-907-26 8-729-901-06 8-729-120-28	TRANSISTOR 2SO TRANSISTOR 2SO TRANSISTOR IM TRANSISTOR DTA	21623-L5L6 21623-L5L6 21623-L5L6 4144EK	
L509 1-45 L511 1-45 L512 1-45 L513 1-41 L514 1-45	9-075-00 9-106-00 9-155-00 2-447-11 9-104-00	COIL, DYNAMIC CONVERSION CHOKE COIL, DUST CORE COIL (WITH CORE) 45UH INDUCTOR 3.9MMH COIL, DUST CORE		Q364 Q365 Q372 Q401	8-729-901-01 8-729-901-01 8-729-901-01 8-729-120-28 8-729-120-28	TRANSISTOR DTC TRANSISTOR DTC TRANSISTOR DTC TRANSISTOR DTC TRANSISTOR 250	2144EK 2144EK 2144EK 2144EK 21623-1516	
L515 1-459 L516 A 1-459 L517 1-413	9-059-00 9-760-13 2-547-21	COIL, DUST CORE COIL, HORIZONTAL LINEARITY INDUCTOR 680UH		Q403 Q404 Q405	8-729-216-22 8-729-216-22 8-729-216-22	TRANSISTOR 2SA TRANSISTOR 2SA TRANSISTOR 2SA	1162-G 1162-G	
NL500 1-51	<neo 9-526-11</neo 	N LAMP> LAMP, NEON		Q407 Q408	8-729-120-28 8-729-120-28 8-729-216-22	TRANSISTOR 2SC TRANSISTOR 2SC TRANSISTOR 2SA	.1623-L51.6 C1623-L5L6 M1162-G	
Q101 8-72' Q107 8-72'	<tra 9-901-01</tra 	NSISTOR> TRANSISTOR DTC144EK		Q409 Q410 Q411 Q412 Q413	8-729-216-22 8-729-907-26 8-729-120-28 8-729-216-22 8-729-141-53	TRANSISTOR 2SA TRANSISTOR 1MX TRANSISTOR 2SC TRANSISTOR 2SA TRANSISTOR 2SK	A1162-G {1 [1623-1.51.6 A1162-G {94-X2X3X4	
Q108 8-72 Q109 8-72 Q110 8-72 Q111 8-72	9-120-28 9-120-28 9-120-28 9-120-28	LAMP, NEON TRANSISTOR DTC144EK TRANSISTOR DTA144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTA144EK TRANSISTOR DTA144EK TRANSISTOR 2SC1623-L5L6		Q414 Q415 Q416 Q417	8-729-216-22 8-729-216-22 8-729-216-22 8-729-216-22 8-729-120-28	TRANSISTOR 2SA TRANSISTOR 2SA TRANSISTOR 2SA TRANSISTOR 2SA TRANSISTOR 2SA	A1162-G A1162-G A1162-G A1162-G	
Q112 8-72 Q113 8-72 Q114 8-72 Q200 8-72	9-120-28 9-120-28 9-119-78 9-140-96	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC2785-HFE TRANSISTOR 2SD774-34		Q419 Q420 Q421 Q422	8-729-216-22 8-729-216-22 8-729-901-01 8-729-120-28	TRANSISTOR 2SA TRANSISTOR 2SA TRANSISTOR DTO TRANSISTOR 2SO	N1162-G N1162-G N144EK C1623-L5L6	
0303 8-72 0304 8-72	9-120-28 9-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		Q424 Q425 Q426	8-729-901-01 8-729-901-01 8-729-901-01	TRANSISTOR 2SC TRANSISTOR DTC TRANSISTOR DTC TRANSISTOR DTC TRANSISTOR 2SA	1144EK 1144EK 1144FK	
9308 8-729 9309 8-729	9-120-28 9-120-28 9-120-28 9-216-22 9-216-22	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G		Q429 Q430 Q431 Q432	8-729-120-28 8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR 2SA TRANSISTOR 2SC TRANSISTOR 2SC TRANSISTOR 2SC	11162-G 11623-1.51.6 11623-1.51.6 11623-1.51.6	
9313 8-729 9315 8-729 9316 8-729	9-120-28 9-216-22 9-216-22 9-120-28 9-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		Q434 Q435 Q436	8-729-901-01 8-729-120-28 8-729-901-01 8-729-901-01 8-729-901-01	TRANSISTOR DTC TRANSISTOR 2SC TRANSISTOR DTC TRANSISTOR DTC	144EK 1623-1.51.6 144EK 144EK	
Q318 8-729 Q319 8-729 Q320 8-729	9-216-22 9-120-28 9-119-78	TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC2785-HFE TRANSISTOR 2SC1623-L5L6		Q438 Q439 Q440	8-729-120-28 8-729-216-22 8-729-120-28	TRANSISTOR DTC TRANSISTOR 2SC TRANSISTOR 2SC TRANSISTOR 2SC TRANSISTOR 2SK	1623-L5L6 1162-G	

Ri	EF.NO.	PART NO.	DESCRIPTION			REMAI	RK ¦R	EF.NO.	PART NO.	DESCRIPTION				REMARK
(Q442 Q443 Q444 Q445 Q500	8-729-120-28 8-729-216-22 8-729-216-22 8-729-901-01 8-729-216-22 8-729-800-35 8-729-119-80 8-729-313-42 8-729-120-28 8-729-120-28 8-729-120-28 8-729-120-28 8-729-120-28 8-729-120-28 8-729-120-28 8-729-195-82 8-729-10-68 8-729-901-06 8-729-901-07 8-729-905-67 8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR 2SO TRANSISTOR 2SO TRANSISTOR 2SO TRANSISTOR DTO TRANSISTOR 2SO	21623-L 11162-G 21623-L 2144EK 11162-G	5L6 5L6			R139 R140 R141 R142 R143	1-216-295-00 1-216-033-00 1-216-085-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 220 33K 0	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
1	0501 0502 0503 0504 0505	8-729-800-35 8-729-119-80 8-729-313-42 8-729-120-28 8-729-120-28	TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI	01397-0 02688-L 01134-0 01623-L 01623-L	A K 5L6 5L6			R144 R147 R149 R150 R151	1-216-295-00 1-216-295-00 1-216-065-00 1-216-295-00 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 4.7K 0 3.3K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	9506 9507 9508 9511 9512	8-729-120-28 8-729-120-28 8-729-216-22 8-729-120-28 8-729-195-82	TRANSISTOR 2SC TRANSISTOR 2SC TRANSISTOR 2SC TRANSISTOR 2SC	21623-L 21623-L A1162-G 21623-L 22958-L	5L6 5L6 5L6			R153 R154 R155 R157 R159	1-216-295-00 1-216-065-00 1-249-434-11 1-216-065-00 1-216-063-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE METAL GLAZE	0 4.7K 27K 4.7K 3.9K	5% 5% 5% 5%	1/10W 1/10W 1/4W 1/10W 1/10W	
!	Q513 Q515 Q517 Q519 Q520	8-729-122-03 8-729-169-02 8-729-901-06 8-729-901-01 8-729-905-67	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR DT TRANSISTOR DT TRANSISTOR 2S	A1220A- C2690A- A144EK C144EK D1944-K	P Q			R160 R162 R163 R164 R165	1-216-061-00 1-216-065-00 1-216-065-00 1-216-067-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 4.7K 4.7K 5.6K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	Q525 Q526	8-729-119-76 8-729-216-22	TRANSISTOR 2S TRANSISTOR 2S	A1175-1 A1162-0	FË			R173 R175	1-216-061-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 0 0 0 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	Q527	0 127 120 20	TRANSISTOR 2S	C1623-I	.5L6		1	R180 R181 R183	1-216-295-00 1-216-065-00 1-216-295-00 1-216-073-00 1-216-061-00				1/10W 1/10W 1/10W	
	JR122	1-216-295-00	METAL GLAZE	0	5%	1/10W		R185 R187	1-216-073-00 1-216-061-00	METAL GLAZE METAL GLAZE	10K 3.3K	5% 5%	1/10W 1/10W	
	JR123 JR302 JR306 R101 R102	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 100	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R188 R189 R190 R192 R193	1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1 K 10 K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R 103 R 104 R 105 R 106	1-216-025-00 1-216-025-00 1-216-073-00 1-216-059-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 10K 2.7K 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R195 R197 R198 R199		METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP				
	R 108 R 109 R 110 R 111 R 112	1-216-065-00 1-216-065-00 1-216-073-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 4.7K 10K 0	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W 1/10W		R200 R201 R202 R203	1-216-684-11 1-216-049-00 1-212-857-00 1-260-095-11 1-260-072-11 1-216-647-11					F
	R113 R114 R115	1-216-085-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE	33K 0 0	5% 5% 5%	1/10W 1/10W 1/10W		R205 R206	1-216-647-11		4.7 680 10K		1/10W 1/10W	
	R116 R117	1-218-761-11 1-216-089-91	METAL CHIP METAL GLAZE	240K 47K	0.50% 5%	1/10W 1/10W	1	R207 R208 R209	1-216-065-00 1-216-065-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 4.7K 10K 3.3K	5% 5% 5% 5%	1/10W 1/10W 1/10W	
	R118 R119 R120 R121 R123	1-216-295-00 1-216-689-11 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE	0 39K 0 0 0	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	 	R210 R211 R237 R302 R304	1-216-061-00 1-249-393-11 1-216-089-91 1-216-025-00 1-216-025-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE METAL GLAZE	10 47K 100 100	5% 5% 5% 5%	1/10W 1/4W 1/10W 1/10W 1/10W	F
	R125 R128 R129 R130 R131	1-216-295-00 1-216-295-00 1-216-295-00 1-216-101-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 150K 0	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R307 R308 R312 R313	1-216-115-00 1-216-065-00 1-216-073-00 1-216-649-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	560K 4.7K 10K 820	5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W	
	R132 R134 R136 R137 R138	1-216-065-00 1-216-065-00 1-216-295-00 1-216-065-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 4.7K 0 4.7K 0	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R314 R315 R316 R317 R318	1-216-099-00 1-216-099-00 1-216-049-00 1-216-057-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE	120K 120K 1K 2.2K 1K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	

REF.NO. PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R320 1-216-057-00 R321 1-216-051-00 R322 1-216-035-00 R323 1-216-109-00 R324 1-216-101-00		2.2K 1.2K 270 330K 150K)₩ 164	R444 R444 R445 R447 R448	1-216-049-00 1-216-105-00 1-216-095-00 1-216-069-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 5 220K 5 82K 5 6.8K 5 1K 5 10K 5		
R325 1-216-037-00 R326 1-216-033-00 R328 1-216-121-00 R329 1-216-055-00 R330 1-216-089-91	METAL GLAZE		26 1/1)\\)\\)\\	R449	1-216-049-00 1-216-073-00 1-216-121-00 1-216-037-00 1-216-651-11 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	1M 5 330 5 1K 0	% 1/10W % 1/10W .50% 1/10W	
R331 1-216-093-00 R334 1-216-093-00 R335 1-216-083-00 R336 1-216-065-00 R342 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE	27K 4.7K 4.7K	5% 1/1 5% 1/1 5% 1/1 5% 1/1 5% 1/1)W)W	R455 R456 R457 R458 R459 R460	1-216-097-00 1-216-085-00 1-216-053-00 1-216-025-00 1-216-113-00 1-216-649-11 1-216-073-00	METAL GLAZE	100K 5 33K 5 1.5K 5 100 5 470K 5 820 0		
R345 1-216-063-00 R346 1-216-057-00 R350 1-216-085-00 R366 1-216-065-00 R376 1-216-111-00		3.9K 2.2K 33K 4.7K 390K)M)M)M	R462 R463 R464 R465	1-216-651-11 1-216-065-00 1-216-065-00 1-216-025-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	10K 5 1K 0 4.7K 5 4.7K 5 100 5	% 1/10W .50% 1/10W % 1/10W % 1/10W	
R382 1-216-107-00 R387 1-216-029-00 R388 1-216-033-00 R393 1-216-073-00 R394 1-216-083-00		390K 270K 150 220 10K		OM OM OM	R466 R467 R468 R469 R470	1-216-077-00 1-216-121-00 1-216-105-00 1-216-063-00 1-216-069-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 5 1M 5 220K 5 3.9K 5 6.8K 5 330K 5		
R397 1-216-113-00 R398 1-216-105-00 R399 1-216-111-00 R401 1-216-053-00		27K 470K 220K 390K 1.5K		JM JM JM JM JM	R472 R473 R474 R475	1-216-109-00 1-216-077-00 1-216-121-00 1-216-649-11 1-216-025-00 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	15K 5	% 1/10W % 1/10W .50% 1/10W	
R403 1-216-069-00 R406 1-216-083-00 R407 1-216-085-00 R408 1-216-689-11 R410 1-216-069-00	METAL GLAZE	6.8K	5% 1/1 5% 1/1 5% 1/1 5% 1/1 0.50% 1/1	าพ	R477 R478 R479 R480	1-216-061-00 1-216-073-00 1-216-085-00 1-216-077-00 1-216-033-00	METAL GLAZE METAL GLAZE	3.3K 5 10K 5 33K 5 15K 5 220 5	% 1/10W % 1/10W	
R411 1-216-033-00 R412 1-216-089-91 R413 1-216-668-11 R416 1-216-113-00 R417 1-216-665-11	METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	220 47K 5.1K 470K	5% 1/1 5% 1/1 0.50% 1/1 5% 1/1	OW OW	R482 R483 R484 R485 R486	1-216-057-00 1-216-025-00 1-216-651-11 1-216-033-00 1-216-681-11		2.2K 5 100 5 1K 0 220 5	% 1/10W % 1/10W % 1/10W % 1/10W % 1/10W % 1/10W	
R418 1-216-667-11 R419 1-216-065-00 R420 1-216-689-11 R422 1-216-073-00 R423 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K	0.50% 1/1 0.50% 1/1 5% 1/1 5% 1/1 5% 1/1	OW OW	R487 R488 R489 R490 R491	1-216-653-11		1.2K 0	.50% 1/10% % 1/10% % 1/10% % 1/10%	! !
R424 1-216-033-00 R425 1-216-049-00 R426 1-216-039-00 R427 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220 1K 390 220	5% 1/1 5% 1/1 5% 1/1 5% 1/1	OM OM OM OM	R492 R493 R494 R495 R496	1-216-085-00 1-216-295-00 1-216-085-00 1-216-651-11 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	33K 5 0 5 33K 5 1K 0	% 1/10% % 1/10% % 1/10% % 1/10%	
R429 1-216-073-00 R430 1-216-119-00 R431 1-216-097-00 R432 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 820K 100K 47K	5% 1/1 5% 1/1 5% 1/1 5% 1/1	OM OM OM	R497 R498 R499 R500 R502	1-216-653-11 1-216-061-00 1-216-033-00 1-216-689-11 1-216-677-11	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	1.2K 0 3.3K 5 220 5 39K 5	% 1/10W	
R435 1-216-105-00 R436 1-216-113-00 R437 1-216-097-00 R438 1-216-053-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220K 470K 100K 1.5K	5% 1/1 5% 1/1 5% 1/1 5% 1/1	OW OW OW	R503 R504 R505 R506 R506	1-216-677-11 1-216-111-00 1-216-067-00 1-216-073-00 1-216-083-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	12K 0 390K 5 5.6K 5 10K 5	.50% 1/10W .50% 1/10W % 1/10W % 1/10W % 1/10W	
R440 1-216-049-00 R441 1-216-645-11 R442 1-216-647-11	METAL GLAZE METAL CHIP	1K 560 680	5% 1/1 5% 1/1 0.50% 1/1 0.50% 1/1	OM OM	R508 R509	1-216-105-00 1-216-089-91	METAL GLAZE METAL GLAZE	27K 5 220K 5 47K 5		ı

REF.NO. PA		DESCRIPTION				REMARK	REF.NO.	PART	NO.	DESC	RIPTION			***********	REMARK
R511 1- R512 1- R513 1-	-216-099-00 -216-055-00 -216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 120K 1.8K 0	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R586 R587 R588 R589 R590	1-210 1-210 1-210 1-210	5-686-11 5-675-11 5-077-00 5-067-00 5-081-00	METAL	CHIP GLAZE GLAZE GLAZE	30K 10K 15K 5.6K 22K	0.50% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R516 1- R517 1- R518 1- R519 1-	-216-697-11 -214-888-00 -260-123-11 -216-017-00	METAL CHIP METAL CARBON METAL GLAZE		0.50% 1% 5% 5%		F	R591 R592 R593 R594 R595	1-24 1-24 1-21 1-26 1-21	5-683-11 7-688-11 5-647-11 0-104-91 6-689-11	CARBO METAL CARBO METAL	CHIP CHIP N	22K 10 680	0.50% 5% 0.50%	1/10W 1/4W 1/10W 1/2W 1/10W	F
		CARBON METAL GLAZE CARBON METAL OXIDE METAL GLAZE		5% 5% 5% 5%	1/4W 1/10W 1/2W 2W 1/10W	F	R590 R597 R598 R599 R1102	1-24 1-21 1-21 1-21	4-754-00 9-417-11 6-085-00 6-645-11 6-295-00	CARBO METAL METAL METAL	N GLAZE CHIP GLAZE	1K 33K 560		1/10W	F
R528 1 R529 1 R530 1 R531 1	-216-089-91 -216-367-11 -216-077-00		6.8K 47K 47K 0.68 15K	5% 5% 5%	1/10W 2W 1/10W	F	R1104	1-21	6-077-00 6-699-11 6-073-00 6-097-00 6-059-00 6-681-11	METAL METAL	CHIP GLAZE	10K 100K 2.7K	0.50%	1/10W 1/10W 1/10W 1/10W	
R533 1 R534 1 R535 1 R538 1	-247-723-11 -216-085-00 -249-448-11 -216-077-00		2.2K 6.8K 33K 1.2 15K		3W 1/4W 1/10W 1/4W 1/10W	F F	R1108 R1109 R1110 R1113 R1118	1-21 1-21 1-21 1-21 1-21	6-295-00 6-295-00 6-081-00 6-113-00	METAL METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE GLAZE	18K 0 0 22K 470K 8.2K	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R540 1 R541 1 R542 1 R543 1	-216-113-00 -249-383-11 -216-057-00 -212-883-00	METAL GLAZE FUSIBLE	470K 1.5 2.2K 120	5%	1/10W		R1125	1-21	6-049-00	METAL		470K 1K 4.7K 8.2K 1K	57	1/10W 1/10W 1/10W 1/10W 1/10W	
K 549	1-210-011-11	METAL GLAZE METAL GLAZE CARBON METAL GLAZE METAL CHIP	10K 4.7K 2.2K 12K	5% 5% 5% 0.50%	1/10W 1/10W 1/4W 1/10W 1/10W	F	R1132 R1134 R1135 R1136	1-21 1-21 1-21 1-21	6-071-00 6-073-00 6-295-00 6-097-00	METAL METAL METAL METAL	GLAZE GLAZE GLAZE GLAZE GLAZE GLAZE	8.2K 10K 0 100K 1.8K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R551 R552 R553 R554	1-216-077-00 1-216-033-00 1-216-083-00 1-216-095-00	METAL GLAZE METAL GLAZE	1.5K 15K 220 27K 82K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	; ; ; ; ;	R1140 R1141 R1142 R1143	1-2: 1-2: 1-2: 1-2: 1-2:	16-653-11 16-083-00 16-653-11 16-653-11	METAI METAI METAI METAI	CHIP GLAZE CHIP CHIP GLAZE		0.50% 5% 0.50% 0.50% 5%		
R557 R558 R559	1-216-081-00 1-247-711-11 1-216-109-00		22K 680 330K	5% 5% 5%	1/10V 1/4W 1/10V) F)	R1145 R1146 R1147 R1148	1-2 1-2 1-2 1-2	16-067-00 16-057-00 16-057-00 16-065-00	METAL METAL METAL	GLAZE GLAZE GLAZE L GLAZE	5.6K 2.2K 2.2K 4.7K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R561 R563 R564	1-216-091-00 1-216-049-00 1-216-017-00 1-216-107-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE		5% 5% 5% 5% 5%		9 9 9 9	R1150 R1151 R1155 R1163 R1164	1-2 1-2 1-2 1-2	16-037-00 16-081-00 16-133-00 16-033-00 16-049-00	META META META META	L GLAZE L GLAZE L GLAZE L GLAZE L GLAZE	330 22K 3.3M 220 1K	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R568 R569 R571 R572	1-216-081-00 1-216-073-00 1-260-114-11 1-216-065-00 1-216-059-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE	22K 10K 18K 4.7K 2.7K	5% 5% 5% 5%	1/100 1/100 1/2W 1/100 1/100	ń ń	R1165 R1166 R1171 R1172 R1176	1-2 1-2 1-2	16-049-00 16-295-00 16-085-00 16-085-00 16-295-00 16-071-00	META META META	L GLAZE L GLAZE L GLAZE L GLAZE L GLAZE	1K 0 33K 33K 0	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W] -
R574 R576 R578 R580	1-216-071-00 1-216-689-11 1-216-101-00 1-216-693-11 1-216-105-00	METAL GLAZE METAL GLAZE METAL CHIP	8.2K 39K 150K 56K 220K	0.50 5%	1/10 1/10 1/10 1/10 1/10 1/10	W W W	R1177 R1178 R1179 R1180 R1181	1-2 1-2 1-2 1-2	16-295-00 16-041-00 16-089-91 16-295-00	META META META META	L GLAZE L GLAZE L GLAZE L GLAZE L GLAZE	8.2K 0 470 47K 0	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W) } }
R583 R584	1-216-085-00 1-216-039-00 1-216-071-00 1-216-033-00) METAL GLAZE) METAL GLAZE	33K 390 8.2K 220	5% 5% 5%	1/10 1/10 1/10 1/10	₩ ₩	R1182 R1183 R1184	1-2 1-2	16-131-11 16-071-0 16-131-1	L META D META	L GLAZE L GLAZE L GLAZE	2.7M 8.2K 2.7M	5%	1/10W 1/10W 1/10W) J

REF.NO. PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R1185 1-216-071-00 R1186 1-216-131-11 R1187 1-216-071-00 R1188 1-216-131-11 R1189 1-216-071-00 R1190 1-216-131-11 R1191 1-216-071-00 R1192 1-216-131-11 R1193 1-216-025-00 R1194 1-216-085-00 R1195 1-216-085-00 R1196 1-216-085-00 R1197 1-216-085-00 R1198 1-216-085-00 R1304 1-216-085-00 R1305 1-216-085-00 R1306 1-216-085-00 R1307 1-216-097-00 R1308 1-216-097-00 R1310 1-216-097-00 R1311 1-216-097-00 R1311 1-216-097-00 R1312 1-216-097-00 R1313 1-216-097-00 R1314 1-216-097-00 R1315 1-216-097-00 R1316 1-216-097-00 R1317 1-216-097-00 R1318 1-216-097-00 R1318 1-216-097-00 R1319 1-216-095-00 R1319 1-216-085-00 R1319 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 2.7M 8.2K 2.7M 8.2K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1363 R1365 R1366 R1367	1-216-113-00 1-216-131-11 1-216-081-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470K 2.7M 22K 2.2K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R1190 1-216-131-11 R1191 1-216-071-00 R1192 1-216-131-11 R1193 1-216-025-00 R1194 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.7M 8.2K 2.7M 100 33K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1368 R1369 R1370 R1371 R1372	1-216-059-00 1-216-051-00 1-216-105-00 1-216-113-00 1-249-437-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE CARBON	2.7K 1.2K 220K 470K 47K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/4W	
R1195 1-216-025-00 R1196 1-216-085-00 R1197 1-216-025-00 R1198 1-216-085-00 R1304 1-216-689-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 33K 100 33K 39K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1374 R1375 R1376 R1377	1-216-065-00 1-216-101-00 1-216-645-11 1-216-647-11 1-216-055-00	METAL GLAZE METAL CHIP METAL CHIP METAL GLAZE METAL GLAZE	560 680 1.8K	5% 5% 0.50% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1305 1-216-033-00 R1306 1-216-645-11 R1307 1-216-091-00 R1308 1-216-645-11 R1309 1-216-025-00	METAL GLAZE METAL CHIP METAL GLAZE METAL CHIP METAL GLAZE	220 560 56K 560 100	5% 0.50% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1379 R1380 R1381 R1383	1-216-037-00 1-216-645-11 1-216-647-11 1-216-681-11 1-216-091-00	METAL GLAZE METAL CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP	330 560 680 18K	0.50% 0.50% 0.50%	1/10W 1/10W 1/10W 1/10W	
R1310 1-216-025-00 R1311 1-216-089-91 R1312 1-216-027-00 R1313 1-216-097-00 R1314 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 47K 120 100K 22K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1385 R1386 R1387 R1388 R1389	1-216-073-00 1-216-077-00 1-216-653-11 1-216-689-11 1-216-657-11	METAL GLAZE METAL GLAZE METAL CHIP METAL CHIP METAL CHIP	10K 15K 1.2K 39K	5% 5% 0.50% 0.50%	1/10W 1/10W 1/10W 1/10W	
R1316 1-216-065-00 R1317 1-216-041-00 R1318 1-216-061-00 R1319 1-216-085-00 R1320 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 470 3.3K 33K 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1390 R1391 R1392 R1393 R1394	1-216-647-11 1-216-025-00 1-216-041-00 1-216-063-00 1-216-041-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 470 3.9K 470	0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1314 1-216-081-00 R1316 1-216-065-00 R1317 1-216-041-00 R1318 1-216-085-00 R1319 1-216-085-00 R1320 1-216-065-00 R1323 1-216-097-00 R1328 1-216-125-00 R1329 1-216-103-91 R1330 1-216-081-00 R1331 1-216-679-11 R1332 1-216-679-11 R1333 1-216-049-00 R1334 1-216-063-00 R1335 1-249-401-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	1.5M 1.5M 180K 22K 15K	5% 5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		R1395 R1396 R1397 R1398 R1399	1-216-071-00 1-216-071-00 1-216-065-00 1-216-295-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 8.2K 4.7K 0 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1332 1-216-671-11 R1333 1-216-049-00 R1334 1-216-063-00 R1335 1-249-401-11 R1336 1-216-095-00 R1337 1-216-061-00 R1338 1-216-047-11 R1339 1-216-033-00 R1340 1-216-033-00 R1341 1-216-033-00 R1342 1-216-033-00 R1343 1-216-033-00	METAL CHIP METAL GLAZE METAL GLAZE CARBON METAL GLAZE	6.8K 1K 3.9K 47 82K	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/4W 1/10W	F	R1401 R1402 R1403 R1404 R1405	1-216-085-00 1-216-295-00 1-216-651-11 1-216-681-11 1-216-071-00	METAL GLAZE METAL CHIP METAL CHIP METAL CHIP METAL GLAZE	33K 0 1K 18K 8.2K	5% 5% 0.50% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1338 1-216-047-11 R1339 1-216-033-00 R1340 1-216-033-00 R1341 1-216-033-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 680 220 220 220	5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1406 R1407 R1408 R1409 R1410	1-216-653-11 1-216-061-00 1-216-113-00 1-216-295-00 1-216-053-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.2K 3.3K 470K 0 1.5K	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1344 1-216-093-00 R1345 1-216-109-00 R1346 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE	68K 330K 100K	5% 5% 5%	1/10W 1/10W 1/10W		R1414 R1415 R1416 R1417	1-216-057-00 1-216-093-00 1-216-113-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 68K 470K 220	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R1348 1-216-071-00 R1349 1-216-035-00 R1350 1-216-073-00 R1351 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 8.2K 270 10K 220	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1418 R1419 R1420 R1421 R1422 R1423	1-216-033-00 1-216-025-00 1-216-089-91 1-216-649-11 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	220 100 47K 820 33K	5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1352 1-216-065-00 R1353 1-216-065-00 R1354 1-216-089-91 R1355 1-216-033-00 R1356 1-216-105-00 R1357 1-216-101-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 4.7K 47K 220 220K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1423 R1424 R1425 R1426 R1427 R1428	1-216-057-00 1-216-081-00 1-216-013-00 1-216-113-00 1-216-681-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	2.2K 22K 33 470K 18K 3.3K	5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1357 1-216-101-00 R1359 1-216-099-00 R1360 1-216-065-00 R1361 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	150K 120K 4.7K 470K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R1429	1-216-061-00 1-216-668-11 1-216-073-00	METAL GLAZE METAL CHIP METAL GLAZE	3.3K 5.1K 10K	5% 0.50% 5%	1/10W 1/10W 1/10W	

The components identified by shading and mark A are critical for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque 🛆 sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R1432 R1434 R1436 R1437	1-216-073-00 1-216-069-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2M 47K 0 10K 6.8K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1498 R1499 R1500 R1501 R1502	1-216-057-00 1-216-057-00 1-216-647-11 1-216-071-00 1-260-105-11	METAL GLAZE METAL CHIP METAL GLAZE CARBON	2.2K 2.2K 680 8.2K 3.3K 3.9K	5% 0.50%	1/10W 1/2W	
R1439 R1440 R1441 R1442	1-216-033-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 2.7K 470 220 10K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1504 R1505 R1506 R1507	1-216-065-00	METAL CHIP CARBON METAL GLAZE	30K	0.50% 5% 5%	1/4W 1/10W 1/10W	F
R1445	1-216-013-00 1-216-057-00 1-216-071-00 1-216-071-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33 2.2K 8.2K 8.2K 22K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1511	1-216-689-11 1-216-077-00 1-216-360-11 1-216-647-11 1-247-752-11	METAL GLAZE METAL OXIDE	15K 8.2 680	5% 5% 0.50%	1/10W	F
R 1449 R 1450	1-216-085-00 1-216-057-00 1-216-129-00 1-216-093-00 1-216-085-00	METAL GLAZE METAL GLAZE	33K 2.2K 2.2M 68K 33K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1514 R1515 R1518 R1519	1-247-711-11 1-216-350-11 1-215-867-00 1-216-355-11 1-216-007-00	METAL OXIDE METAL OXIDE	680	5% 5% 5% 5%	1/4W 1W 1W 1W 1/10W	F F F
R 1454 R 1455	1-216-013-00 1-216-065-00 1-216-113-00 1-216-129-00 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE	33 4.7K 470K 2.2M 47K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1522 R1523 R1523 R1524 R1525	1-216-029-00 1-249-400-11 1-216-350-11 1-216-427-00	METAL GLAZE CARBON METAL OXIDE METAL OXIDE	150	5% 5%	1/10W 1/4W 1W 1W	F F
R 1 460 R 1 461	1-216-085-00 1-216-133-00 1-216-097-00 1-216-645-11 1-216-645-11	METAL GLAZE METAL GLAZE METAL CHIP	33K	5%	1/10W 1/10W 1/10W 1/10W 1/10W		K1526	1-216-083-00 1-216-089-91 1-249-413-11 1-215-869-11 1-202-829-11	METAL GLAZE	27K 47K 470 1K 8.2K 560K	5% 5% 5% 20%	1/10W 1/10W 1/4W 1W 1/2W	F F
R1463 R1464 R1465	1-216-645-11 1-216-057-00 1-216-097-00 1-216-055-00 1-216-073-00	METAL CHIP METAL GLAZE METAL GLAZE	560 2.2K 100K 1.8K	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R1530 R1531 R1532 R1533	1-216-115-00 1-247-697-11 1-216-059-00 1-249-414-11	CARBON METAL OXIDE SOLID METAL GLAZE CARBON METAL GLAZE CARBON	560K 56 2.7K 560	5% 5% 5%	1/10W 1/4W 1/10W 1/4W	F
R1468 R1469 R1470 R1471	1-249-438-11 1-216-057-00 1-216-057-00 1-216-049-00	CARRON	56K	5%	1/44		! R1537	1-249-389-11	CARBON	4.7	5% 5% 5%	1/4W 1/10W 1/10W	
R1472 R1473 R1474 R1475 R1476	1-216-085-00 1-216-081-00 1-216-687-11 1-216-677-11 1-216-063-00	METAL GLAZE METAL CHIP METAL CHIP METAL CHIP METAL GLAZE	22K 33K 12K 3.9K	5% 5% 0.50% 0.50%	1/10W 1/10W 1/10W 1/10W		R1541 R1542 R1543 R1544	1-216-105-00 1-216-081-00 1-216-111-00 1-216-027-00 1-216-117-00	METAL GLAZE CARBON METAL GLAZE CARBON	220K 22K 390K 120 680K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	! !
R1477 R1478 R1479 R1480	1-216-057-00 1-216-061-00 1-216-295-00 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 3.3K 0 47K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R1545 R1547 R1549 R1550 R1551	1-216-101-00 1-216-393-00 1-260-094-11 1-216-105-00 1-249-393-11	METAL GLAZE METAL OXIDE CARBON METAL GLAZE CARBON	150K 2.2 390 220K 10	5%	1/10W 3W 1/2W 1/10W 1/4W	F
R1481 R1482 R1483 R1484 R1485	1-216-089-91 1-216-081-00 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE	47K 47K 22K 470K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1552 R1554 R1555 R1556 R1557	1-216-049-00 1-216-059-00 1-216-295-00 1-216-071-00 1-218-760-11	METAL GLAZE METAL GLAZE METAL GLAZE	1 K 2.7 K 0 8.2 K 220 K	5% 5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W	i i
R1486 R1487 R1488 R1489 R1490	1-216-121-00 1-216-113-00 1-216-083-00 1-216-069-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1M 470K 27K 6.8K 270	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W)] }	R1558 R1559 R1560 R1561 R1562	1-249-393-11 1-249-393-11 1-216-049-00 1-216-681-11 1-214-964-00	CARBON METAL GLAZE METAL CHIP	10 10 1K 18K 1M	5% 5% 5% 0.50%	1/4W 1/4W 1/10W 1/10W 1/4W	F ∤
R1491 R1492 R1493 R1494	1-216-035-00 1-216-035-00 1-216-083-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	270 270 27K 22K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W) } V	R1563 R1564 R1567 R1574 R1575	1-214-964-00 1-216-681-11 1-216-089-91	METAL CHIP METAL CHIP METAL GLAZE METAL GLAZE	1M 18K 47K 470	1%	1/4W 1/10W 1/10W 1/10W	n) d
R 1495 R 1497		METAL GLAZE		5%	1/10V 1/10V	v V	R1576 R1576 R1577	1-216-025-00	METAL GLAZE	100 100 100	5% 5%	1/104 · 1/104 1/104	W

The components identified by in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.
 Should replacement be required, replace only with the value originally used.

REF.NO. PART NO.					REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R1578 1-216-065-00 R1579 1-216-689-11 R2300 1-216-065-00 R2301 1-216-065-00 R2306 1-216-089-91 R2308 1-216-033-00 R2308 1-216-049-00 R2311 1-216-073-00 R2312 1-216-053-00 R2315 1-216-679-11 R2316 1-216-081-00 R2317 1-216-049-00 R2317 1-216-683-11 R2323 1-216-683-11 R2323 1-216-041-00 R2329 1-216-049-00 R2329 1-216-049-00 R2330 1-216-049-00 R2330 1-216-049-00 R2331 1-216-049-00 R2331 1-216-049-00 R2332 1-216-049-00 R2333 1-216-049-00 R2334 1-216-049-00 R2335 1-216-049-00 R2336 1-216-049-00 R2337 1-216-049-00 R2338 1-216-049-00 R2339 1-216-049-00 R2331 1-216-049-00 R2331 1-216-049-00 R2332 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 39K 4.7K 4.7K 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2383 R2384 R2389 R2390	1-216-033-00 1-216-689-11 1-216-033-00 1-216-647-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	220 39K 220 680	5% 5% 0.50%	1/10W	
R2307 1-216-033-00 R2308 1-216-103-91 R2309 1-216-049-00 R2311 1-216-073-00 R2312 1-216-053-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220 180K 1K 10K 1.5K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2394 R2394 R2396 R2397 R2398	1-216-647-11 1-216-081-00 1-216-041-00 1-216-113-00 1-216-109-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	680 22K 470 470K 330K	0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R2315 1-216-679-11 R2316 1-216-081-00 R2317 1-216-049-00 R2320 1-216-677-11 R2323 1-216-683-11	METAL CHIP METAL GLAZE METAL GLAZE METAL CHIP METAL CHIP	15K 22K 1K 12K 22K	0.50% 5% 5% 0.50% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		R2501 R2502 R2551 R2552 R2553	1-216-073-00 1-216-083-00 1-216-077-00 1-216-091-00 1-216-083-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 27K 15K 56K 33K 27K 1.8K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2325 1-216-063-00 R2326 1-216-041-00 R2327 1-216-059-00 R2328 1-216-049-00 R2329 1-216-059-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.9K 470 2.7K 1K 2.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2555 R2556 R2557 R2558 R2558	1-216-055-00 1-216-051-00 1-216-067-00 1-216-057-00 1-216-039-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.8K 1.2K 5.6K 2.2K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2330 1-216-049-00 R2331 1-216-059-00 R2332 1-216-049-00 R2334 1-216-041-00 R2335 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 2.7K 1K 470 3.3K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2560 R2561 R2562 R2563	1-216-069-00 1-216-001-00 1-216-001-00 1-216-057-00	METAL GLAZE	390 6.8K 10 10 2.2K	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2336 1-216-065-00 R2337 1-216-037-00 R2338 1-216-073-00 R2339 1-216-037-00 R2341 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 330 10K 330 330	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3302 R3303 R3304 R3308 R3310	1-216-065-00 1-216-065-00 1-216-065-00 1-216-097-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 4.7K 4.7K 4.7K 100K	5% 5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2344 1-216-121-00 R2346 1-216-061-00 R2347 1-216-061-00 R2348 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 1M 3.3K 3.3K 3.3K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3311 R3312 R3314 R3315 R3316	1-216-091-00 1-216-105-00 1-216-295-00 1-216-065-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	56K 220K 0 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R2349 1-216-679-11 R2350 1-216-061-00 R2351 1-216-061-00 R2352 1-216-061-00 R2353 1-216-041-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 3.3K 3.3K 3.3K 470	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3317 R3318 R3319 R3321 R3322	1-216-103-91 1-216-065-00 1-216-027-00 1-216-677-11 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CLIP METAL GLAZE	180K 4.7K 120 12K	5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W	
R2354 1-216-025-00 R2354 1-216-681-11 R2356 1-216-089-91 R2357 1-216-095-00 R2358 1-216-025-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	100 18K 47K 82K 100	5% 0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3333 R3337 R3338 R3341	1-216-113-00 1-216-099-00 1-218-759-11 1-216-083-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	170K 120K 200K 27K	5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W	
R2359 1-216-097-00 R2360 1-216-689-11 R2362 1-216-081-00 R2364 1-216-025-00 R2366 1-216-067-00	METAL GLAZE METAL GLAZE METAL GLAZE	100K 39K 22K 100 5.6K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3347 R3348 R3349 R3350 R3351	1-216-025-00 1-216-025-00 1-216-025-00 1-216-113-00 1-216-119-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 100 100 100 470K 820K	5% %%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2367 1-216-093-00 R2369 1-216-083-00 R2370 1-216-081-00 R2371 1-216-049-00 R2372 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE	68K 27K 22K 1K 470K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3365 R3376 R3377 R3378 R3390	1-216-081-00 1-216-081-00 1-216-107-00 1-216-115-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 22K 270K 560K 2.2K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R2374 1-216-097-00 R2375 1-216-089-91 R2376 1-216-089-91 R2377 1-216-033-00 R2378 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE	100K 47K 47K 220 47K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R3394 R3395 R3396 R3397 R3398	1-216-037-00 1-216-089-91 1-249-417-11 1-216-041-00 1-216-101-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE	47K 1K 470 470	5% 5% 5%	1/10W 1/10W 1/4W 1/10W 1/10W	
R2379 1-216-033-00 R2380 1-216-089-91 R2381 1-216-089-91 R2382 1-216-089-91	METAL GLAZE METAL GLAZE	220 47K 47K 47K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R4401 R4402 R4404	1-216-101-00 1-216-085-00 1-216-113-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	150K 33K 470K 10K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	

The components identified by shading and mark ∆ are critical for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.



REF.NO.	PART NO.	DESCRIPTION			REMARK :	REF.NO.	PART NO.	DESCRIPTION			REMARK
R4407 R4408 R4409	1-216-067-00 1-216-061-00 1-216-059-00 1-216-059-00 1-216-059-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	5.6K 5% 3.3K 5% 2.7K 5% 2.7K 5% 2.7K 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C628 C629 C630 C631 C632	1-136-067-00 1-124-887-00 1-102-973-00 1-161-973-00 1-162-599-12	CERAMIC CERAMIC CERAMIC	0.0036MF 0.001MF 100PF 220PF 0.0047MF	3% 10% 5% 10% 20%	2KV 3KV 50V 400V 400V
R4412 R4413 R4415	1-216-113-00 1-216-113-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE	0 5% 0 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C634 C635 C636 C637	1-162-599-12 1-102-125-00 1-124-903-11 1-126-801-11 1-102-030-00	CERAMIC ELECT ELECT	0.0047MF 0.0047MF 1MF 1MF 330PF	20% 10% 20% 20% 10%	400V 50V 50V 50V 500V
	1-223-102-00		> EWOUND 120			C638 C639 C640 C641 C642	1-102-030-00 1-104-783-51 1-128-386-11 1-106-343-00 1-102-030-00	ELECT ELECT MYLAR	330PF 1000MF 1000MF 0.001MF 330PF	10% 20% 20% 10% 10%	500V 25V 25V 100V 500V
7500 7501 <i>₫</i>	<trai 1-426-668-11 1-453-163-11</trai 	NSFORMER> Transformer, Transformer a	FERRITE (HDT SSY, FLYBACK)		C643 C644 C645 C646 C647	1-104-884-11 1-102-030-00 1-162-131-11 1-102-973-00 1-126-385-11	CERAMIC CERAMIC	470MF 330PF 220PF 100PF 390MF	20% 10% 10% 5% 20%	50V 500V 2KV 50V 16V
TH500	1-807-970-11					C648 C649 C650 C651 C652	1-125-494-11 1-126-803-11 1-126-103-11 1-126-101-11 1-124-667-11	ELECT ELECT ELECT ELECT	47MF 470MF 100MF 10MF	20% 20% 20% 20% 20%	160V 16V 16V 16V 50V
X301	CRY 1-579-175-11 1-527-722-00	OSCILLATOR, C	RYSTAL	*****	*******	1 6037	1-136-169-00 1-161-953-71 1-161-953-71 1-161-953-71 1-102-965-00 1-161-953-71	CERMIT	0.22MF 0.0047MF 0.0047MF 0.0047MF 39PF 0.0047MF	5% 20% 20% 20% 20%	50V 400V 400V 400V 50V 400V
	4-363-414-00	G BOARD, COMP	****			C659	1-102-123-00 1-124-791-11 1-130-467-00	CERAMIC	0.0033MF	10% 20% 5%	50V 100V 50V
		PACITOR>				CN601	<00 1-691-960-11	NECTOR>	rnp (bc buyb	n\ 3D	
C601 C602 C603	<u>水</u> 1-161-953-71 水 1-161-953-71 水 1-161-953-71		0.0047MF 0.0047MF 0.0047MF	20% 20% 20% 20%	400V 400V 400V 400V	CN602 CN603	*1-695-561-11 1-508-765-00 *1-573-964-11 *1-564-508-11	PIN, CONNEC' PIN. CONNEC'	FOR (PC BOAR FOR (SMM PIT	D) 7P CH) 3P	
			0.22MF	20% 20%	250V 50V	CN609	*1-506-371-00	PIN, CONNEC	TOR 2P		
C606 C607 C608	1-124-907-11 1-124-798-11 1-129-765-00	ELECT FILM	1MF 0.047MF	20% 10%	160V 200V			ODE>			
C609 C610 C611 C612	1-124-126-00 1-124-902-00 1-130-729-00 1-107-722-11	ELECT	47MF 0.47MF 0.0027MF 470MF	20% 20% 5% 20%	10V 50V 50V 400V	D601 D602 D603 D604 D605	\$-719-510-53 8-719-300-33 8-719-110-90 8-719-110-90 8-719-109-97	DIODE RU-3A DIODE RD39E DIODE RD39E	M SB4 SB4		
C613 C614 C615	▲ 1-104-706-51 1-102-978-00 ▲ 1-104-706-51	FILM CERAMIC FILM	0.22MF 220PF 0.22MF	20% 5% 20%	250V 50V 250V	D606 D607 D608	8-719-118-34 8-719-110-41 8-719-300-33	DIODE RD110 DIODE RD15E DIODE RU-3A	EB SB2 M		
C616 C618 C619 C620 C621	1-162-318-11 1-124-907-11 1-162-116-00 1-162-116-00 1-136-153-00	ELECT CERAMIC CERAMIC	0.001MF 10MF 680PF 680PF 0.01MF	10% 20% 10% 10% 5%	500V 50V 2KV 2KV 50V	D610 D611 D615 D616	8-719-200-02 8-719-300-33 8-719-300-33 8-719-911-19	DIODE RU-3A DIODE RU-3A DIODE 1SS11	M 9		
C622 C623 C624 C625	1-126-773-21 1-162-318-11 1-124-477-11	ELECT CERAMIC ELECT	47MF 0.001MF 47MF	20% 10% 20%	250V 500V 16V	D617 D618 D619	8-719-911-19 8-719-908-03 8-719-110-41	DIODE ISSII DIODE GPO8D DIODE RD15E	9 SB2		
C627	1-161-973-00 1-136-066-00	CERAMIC FILM	220PF 0.003MF	10% 3%	400V 2KV	D620 D621 D622 D623	8-719-045-48 8-719-911-19 8-719-979-58 8-719-045-48	DIODE 18811 DIODE EGP10	9 D		



• * : Selected to yield optimum performance.

Les composants identifies par une trame et une marque Δ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark are critical for safety.

Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK																																																																																																																																																																																						
D625 D626 D628	8-719-016-42 8-719-109-71 8-719-979-50	DIODE RD3.9ESB1	l			R619 R620		METAL OXIDE				F F																																																																																																																																																																																						
D629 D630	8-719-979-85 8-719-911-19	DIODE EGP206				R621 R622 R623	1-249-427-11 1-217-190-21 1-249-393-11	WIREWOUND	6.8K 0.15 10	10%	1/4W 2W 1/4W	F																																																																																																																																																																																						
D631	8-719-911-19	DIODE 1SS119				R624 R625	1-247-887-00 1-247-887-00	CARBON	220K 220K	5% 5% 5%	1/4W 1/4W																																																																																																																																																																																							
	<fer< td=""><td>RITE BEAD></td><td></td><td></td><td></td><td>1</td><td>1-249-436-11 1-249-429-11</td><td>CARBON</td><td>39K 10K</td><td>5% 5%</td><td>1/4W 1/4W</td><td></td></fer<>	RITE BEAD>				1	1-249-436-11 1-249-429-11	CARBON	39K 10K	5% 5%	1/4W 1/4W																																																																																																																																																																																							
FB6014 FB6024	1-543-190-11 1-543-190-11	RITE BEAD> BEAD, FERRITE BEAD, FERRITE FERRITE BEAD 11 BEAD, FERRITE	NUCTOR O	AEIIH		R628 R629	1-214-777-00 1-247-891-00 1-249-424-11	METAL Carbon	100K 330K 3.9K	5% 5% 1% 5% 5%	1/4W 1/4W 1/4W																																																																																																																																																																																							
	1-543-190-11 1-543-190-11	DU.10 , . D	ADUCTUR G.	4,1011		R631	1-249-429-11	CARBON	10K 180K		1/4W																																																																																																																																																																																							
	<10>					R632 R633 R634	1-247-885-00 1-249-412-11 1-211-867-11	CARBON WIREWOUND	390 180	5% 5%	1/4W 1/4W 10W																																																																																																																																																																																							
	8-759-100-75 8-759-255-41					R635	1-249-441-11 1-247-753-11	CARBON	100K	5%	1/4W 1/2W	F																																																																																																																																																																																						
1 C 6 0 3	8-759-927-49 8-759-924-12	IC IR9431				R637 R638 R641	1-216-491-11 1-216-491-11 1-211-868-11	METAL OXIDE	1.2K 56K 56K 2.2K 100	5% 5%	3W 3W 10W	F																																																																																																																																																																																						
	<c01< td=""><td>L></td><td></td><td></td><td></td><td>R642</td><td>1-247-807-31</td><td>CARBON</td><td></td><td></td><td>1/4W</td><td></td></c01<>	L>				R642	1-247-807-31	CARBON			1/4W																																																																																																																																																																																							
L603 L604	1-410-645-31 1-407-365-00	INDUCTOR COIL, CHOKE INDUCTOR	100UH			R643 R644 R645		CARBON CARBON METAL GLAZE	3.3K 1K 8.2M	5% 5%	1/4W 1/4W 1W																																																																																																																																																																																							
L605						R646 R647	1-249-417-11 1-260-121-11	CARBON CARBON	1 K 68 K	5% 5%	1/4W 1/2W																																																																																																																																																																																							
	<ph0< td=""><td>PHOTO COUPLER PHOTO COUPLER</td><td></td><td></td><td></td><td>R648 R649</td><td>1-249-443-11 1-260-097-11</td><td>CARBON CARBON</td><td>0.47 680</td><td>5%</td><td>1/4W 1/2W</td><td>F</td></ph0<>	PHOTO COUPLER PHOTO COUPLER				R648 R649	1-249-443-11 1-260 - 097-11	CARBON CARBON	0.47 680	5%	1/4W 1/2W	F																																																																																																																																																																																						
PH602 PH606	8-749-923-50 8-749-923-50	PHOTO COUPLER PHOTO COUPLER	PC111YS PC111YS			R650 R652 R653	1-249-422-11 1-247-895-00 1-260-124-11	CARBON	2.7K 470K 120K	5%	1/4W 1/4W 1/2W																																																																																																																																																																																							
	<tr <="" td=""><td>ANSISTOR></td><td></td><td></td><td></td><td>R654</td><td>1-215-924-71 1-249-440-11</td><td>METAL OXIDE</td><td>15K</td><td>5%</td><td>3W 1/4W</td><td>F</td></tr> <tr><td>Q601 Q602</td><td>8-729-119-78 8-729-119-80</td><td>TRANSISTOR 250 TRANSISTOR 250</td><td>2785-HFE 2688-LK</td><td></td><td></td><td>R655 R656 R659 R660 R661</td><td>1-247-883-00 1-249-443-11</td><td>CARBON CARBON</td><td>82K 150K 0.47</td><td>5% 5% 5% 1%</td><td>1/4W 1/4W</td><td>F</td></tr> <tr><td>Q603 Q605 Q606</td><td>8-729-119-80 8-729-119-80 8-729-802-14</td><td>ANSISTOR> TRANSISTOR 250 TRANSISTOR 250 TRANSISTOR 250 TRANSISTOR 250 TRANSISTOR 250 TRANSISTOR 250 TRANSISTOR 250</td><td>2688-LK 2688-LK 23460</td><td></td><td></td><td>R660 R661</td><td>1-215-427-00 1-215-412-00</td><td>METAL METAL</td><td>1.8K 430</td><td>1%</td><td>1/4W 1/4W</td><td></td></tr> <tr><td>Q607 Q609</td><td>8-729-140-96 8-729-005-67</td><td>TRANSISTOR 2SO TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI</td><td>774-34</td><td></td><td></td><td>R662 R663</td><td>1-260-123-11 1-260-089-11 1-216-390-71</td><td>CARBON</td><td>100K 150 1.2</td><td>5% 5% 5% 5%</td><td>1/2W 1/2W 3W</td><td>F</td></tr> <tr><td>Q610 Q611</td><td>8-729-209-03 8-729-200-17</td><td>TRANSISTOR 2SO TRANSISTOR 2SO</td><td>2551-RO 41091-0</td><td></td><td></td><td>R665 R666</td><td>1-216-390-71 1-216-368-11</td><td>METAL OXIDE</td><td>1.2 0.82</td><td>5% 5%</td><td>3₩ 2₩</td><td>F F</td></tr> <tr><td></td><td></td><td>SISTOR></td><td></td><td></td><td></td><td>R667 R669</td><td>1-205-943-11 1-215-415-00</td><td>METAL</td><td>1 560</td><td>1%</td><td>20W 1/4W</td><td></td></tr> <tr><td></td><td>↑ 1-260-123-91 ↑ 1-260-123-91</td><td></td><td>100K 5% 100K 5% 6.8K 5%</td><td>1/2W 1/2W</td><td></td><td>R670 R671 R672</td><td>1-249-435-11 1-249-429-11 1-215-469-00</td><td>CARBON CARBON</td><td>33K 10K 100K</td><td>5% 5% 1%</td><td>1/4W 1/4W 1/4W</td><td></td></tr> <tr><td>R603 R604</td><td>1-249-427-11 ▲ 1-214-937-55</td><td>CARBON Metal</td><td>1M 1%</td><td>1/4W 1/2W</td><td></td><td>R673</td><td>1-249-437-11</td><td>CARBON</td><td>47K</td><td>5%</td><td>1/4W 1/4W</td><td></td></tr> <tr><td>R605 R606</td><td>1-249-434-11 1-260-111-11</td><td>CARBON</td><td></td><td>1/4W 1/2W</td><td></td><td>R674 R675 R676</td><td>1-247-889-00 1-249-429-11 1-247-883-00</td><td>CARBON CARBON</td><td>270K 10K 150K</td><td>5% 5%</td><td>1/4W 1/4W</td><td></td></tr> <tr><td>R607 R608 R609</td><td>1-205-943-11 1-260-127-11 1-215-922-11</td><td>CARBON</td><td>10K 5% 1 5% 220K 5% 6.8K 5% 6.8K 5%</td><td>20W 1/2W 3W</td><td>F</td><td>R677</td><td>1-260-120-11 1-249-436-11</td><td></td><td>56K 39K</td><td>5%</td><td>1/2W 1/4W</td><td></td></tr> <tr><td>R610</td><td>1-215-922-11</td><td>METAL OXIDE</td><td></td><td>3₩</td><td>F</td><td>*R690 *R690</td><td>1-214-721-00 1-215-414-00</td><td>METAL METAL</td><td>470 510</td><td>5% 1% 1% 1%</td><td>1/4W 1/4W</td><td></td></tr> <tr><td>R611 R612 R613</td><td>1-202-720-00</td><td>SOLID</td><td>33K 1% 1M 20% 1.2M 20% 3.3K 5%</td><td>1/4W 1/2W 1/2W</td><td></td><td>*R690 *R690</td><td>1-214-723-00 1-214-127-00</td><td>METAL</td><td>560 620</td><td>1%</td><td>1/4W 1/4W</td><td></td></tr> <tr><td>R614 R615</td><td>1-249-423-11 1-260-322-11</td><td>CARBON</td><td>330 5%</td><td>1/4W 1/2W</td><td></td><td>*R690 *R690 *R690</td><td>1-214-725-00 1-215-418-00 1-214-727-00</td><td>) METAL</td><td>680 750 820</td><td>1% 1% 1% 1%</td><td>1/4W 1/4W 1/4W</td><td></td></tr> <tr><td>R616 R617</td><td>1-214-716-00</td><td>) METAL</td><td>560 5% 300 1% 100K 5%</td><td>1/4W 1/4W</td><td></td><td>*R690 *R690</td><td>1-214-728-11 1-214-729-00</td><td>METAL</td><td>910 1K</td><td>17 17</td><td>1/4W 1/4W</td><td></td></tr> <tr><td>R618</td><td>1-249-496-11</td><td>CARBON</td><td>100K 5%</td><td>1/2W</td><td>F</td><td>*R690</td><td>1-214-730-00</td><td>) METAL</td><td>1.1K</td><td>1%</td><td>1/4W</td><td></td></tr>	ANSISTOR>				R654	1-215-924-71 1-249-440-11	METAL OXIDE	15K	5%	3W 1/4W	F	Q601 Q602	8-729-119-78 8-729-119-80	TRANSISTOR 250 TRANSISTOR 250	2785-HFE 2688-LK			R655 R656 R659 R660 R661	1-247-883-00 1-249-443-11	CARBON CARBON	82K 150K 0.47	5% 5% 5% 1%	1/4W 1/4W	F	Q603 Q605 Q606	8-729-119-80 8-729-119-80 8-729-802-14	ANSISTOR> TRANSISTOR 250	2688-LK 2688-LK 23460			R660 R661	1-215-427-00 1-215-412-00	METAL METAL	1.8K 430	1%	1/4W 1/4W		Q607 Q609	8-729-140-96 8-729-005-67	TRANSISTOR 2SO TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI	774-34			R662 R663	1-260-123-11 1-260-089-11 1-216-390-71	CARBON	100K 150 1.2	5% 5% 5% 5%	1/2W 1/2W 3W	F	Q610 Q611	8-729-209-03 8-729-200-17	TRANSISTOR 2SO TRANSISTOR 2SO	2551-RO 41091-0			R665 R666	1-216-390-71 1-216-368-11	METAL OXIDE	1.2 0.82	5% 5%	3₩ 2₩	F F			SISTOR>				R667 R669	1-205-943-11 1-215-415-00	METAL	1 560	1%	20W 1/4W			↑ 1-260-123-91 ↑ 1-260-123-91		100K 5% 100K 5% 6.8K 5%	1/2W 1/2W		R670 R671 R672	1-249-435-11 1-249-429-11 1-215-469-00	CARBON CARBON	33K 10K 100K	5% 5% 1%	1/4W 1/4W 1/4W		R603 R604	1-249-427-11 ▲ 1-214-937-55	CARBON Metal	1M 1%	1/4W 1/2W		R673	1-249-437-11	CARBON	47K	5%	1/4W 1/4W		R605 R606	1-249-434-11 1-260-111-11	CARBON		1/4W 1/2W		R674 R675 R676	1-247-889-00 1-249-429-11 1-247-883-00	CARBON CARBON	270K 10K 150K	5% 5%	1/4W 1/4W		R607 R608 R609	1-205-943-11 1-260-127-11 1-215-922-11	CARBON	10K 5% 1 5% 220K 5% 6.8K 5% 6.8K 5%	20W 1/2W 3W	F	R677	1-260-120-11 1-249-436-11		56K 39K	5%	1/2W 1/4W		R610	1-215-922-11	METAL OXIDE		3₩	F	*R690 *R690	1-214-721-00 1-215-414-00	METAL METAL	470 510	5% 1% 1% 1%	1/4W 1/4W		R611 R612 R613	1-202-720-00	SOLID	33K 1% 1M 20% 1.2M 20% 3.3K 5%	1/4W 1/2W 1/2W		*R690 *R690	1-214-723-00 1-214-127-00	METAL	560 620	1%	1/4W 1/4W		R614 R615	1-249-423-11 1-260-322-11	CARBON	330 5%	1/4W 1/2W		*R690 *R690 *R690	1-214-725-00 1-215-418-00 1-214-727-00) METAL	680 750 820	1% 1% 1% 1%	1/4W 1/4W 1/4W		R616 R617	1-214-716-00) METAL	560 5% 300 1% 100K 5%	1/4W 1/4W		*R690 *R690	1-214-728-11 1-214-729-00	METAL	910 1K	17 17	1/4W 1/4W		R618	1-249-496-11	CARBON	100K 5%	1/2W	F	*R690	1-214-730-00) METAL	1.1K	1%	1/4W	
ANSISTOR>				R654	1-215-924-71 1-249-440-11	METAL OXIDE	15K	5%	3W 1/4W	F																																																																																																																																																																																								
Q601 Q602	8-729-119-78 8-729-119-80	TRANSISTOR 250 TRANSISTOR 250	2785-HFE 2688-LK			R655 R656 R659 R660 R661	1-247-883-00 1-249-443-11	CARBON CARBON	82K 150K 0.47	5% 5% 5% 1%	1/4W 1/4W	F																																																																																																																																																																																						
Q603 Q605 Q606	8-729-119-80 8-729-119-80 8-729-802-14	ANSISTOR> TRANSISTOR 250	2688-LK 2688-LK 23460			R660 R661	1-215-427-00 1-215-412-00	METAL METAL	1.8K 430	1%	1/4W 1/4W																																																																																																																																																																																							
Q607 Q609	8-729-140-96 8-729-005-67	TRANSISTOR 2SO TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI TRANSISTOR 2SI	774-34			R662 R663	1-260-123-11 1-260-089-11 1-216-390-71	CARBON	100K 150 1.2	5% 5% 5% 5%	1/2W 1/2W 3W	F																																																																																																																																																																																						
Q610 Q611	8-729-209-03 8-729-200-17	TRANSISTOR 2SO TRANSISTOR 2SO	2551-RO 41091-0			R665 R666	1-216-390-71 1-216-368-11	METAL OXIDE	1.2 0.82	5% 5%	3₩ 2₩	F F																																																																																																																																																																																						
		SISTOR>				R667 R669	1-205-943-11 1-215-415-00	METAL	1 560	1%	20W 1/4W																																																																																																																																																																																							
	↑ 1-260-123-91 ↑ 1-260-123-91		100K 5% 100K 5% 6.8K 5%	1/2W 1/2W		R670 R671 R672	1-249-435-11 1-249-429-11 1-215-469-00	CARBON CARBON	33K 10K 100K	5% 5% 1%	1/4W 1/4W 1/4W																																																																																																																																																																																							
R603 R604	1-249-427-11 ▲ 1-214-937-55	CARBON Metal	1M 1%	1/4W 1/2W		R673	1-249-437-11	CARBON	47K	5%	1/4W 1/4W																																																																																																																																																																																							
R605 R606	1-249-434-11 1-260-111-11	CARBON		1/4W 1/2W		R674 R675 R676	1-247-889-00 1-249-429-11 1-247-883-00	CARBON CARBON	270K 10K 150K	5% 5%	1/4W 1/4W																																																																																																																																																																																							
R607 R608 R609	1-205-943-11 1-260-127-11 1-215-922-11	CARBON	10K 5% 1 5% 220K 5% 6.8K 5% 6.8K 5%	20W 1/2W 3W	F	R677	1-260-120-11 1-249-436-11		56K 39K	5%	1/2W 1/4W																																																																																																																																																																																							
R610	1-215-922-11	METAL OXIDE		3₩	F	*R690 *R690	1-214-721-00 1-215-414-00	METAL METAL	470 510	5% 1% 1% 1%	1/4W 1/4W																																																																																																																																																																																							
R611 R612 R613	1-202-720-00	SOLID	33K 1% 1M 20% 1.2M 20% 3.3K 5%	1/4W 1/2W 1/2W		*R690 *R690	1-214-723-00 1-214-127-00	METAL	560 620	1%	1/4W 1/4W																																																																																																																																																																																							
R614 R615	1-249-423-11 1-260-322-11	CARBON	330 5%	1/4W 1/2W		*R690 *R690 *R690	1-214-725-00 1-215-418-00 1-214-727-00) METAL	680 750 820	1% 1% 1% 1%	1/4W 1/4W 1/4W																																																																																																																																																																																							
R616 R617	1-214-716-00) METAL	560 5% 300 1% 100K 5%	1/4W 1/4W		*R690 *R690	1-214-728-11 1-214-729-00	METAL	910 1K	17 17	1/4W 1/4W																																																																																																																																																																																							
R618	1-249-496-11	CARBON	100K 5%	1/2W	F	*R690	1-214-730-00) METAL	1.1K	1%	1/4W																																																																																																																																																																																							

The components identified by shading and mark \(\text{\Delta} \) are critical for safety.

Replace only with part number specified.

Les composants identifies par une trame et une marque Δ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

• * : Selected to yield optimum performance.

GC

REF.NO. PART NO.	DESCRIPTION		REMARK		PART NO.	DESCRIPTION	N -		RI	EMARK
*R690 1-214-731-00 *R690 1-214-732-00 *R690 1-214-733-00 *R690 1-215-426-00 *R690 1-214-735-00 *R690 1-214-735-00	METAL 1.3K 1% METAL 1.5K 1% METAL 1.6K 1% METAL 1.8K 1%	1/4W 1/4W 1/4W 1/4W 1/4W		CN702	<cony *1-564-511-51 *1-573-964-11 *1-691-134-11</cony 	PIN, CONNECT	TOR (PC E	BOARD) BOARD)	6P 2P	
*R690 1-214-737-00 *R690 1-214-739-00 *R690 1-214-741-00 *R690 1-214-743-00 *R690 1-214-745-00 *R690 1-214-747-00 *R690 1-214-747-00	METAL 3.3K 1% METAL 3.9K 1% METAL 4.7K 1% METAL 5.6K 1%	1/4W 1/4W 1/4W 1/4W 1/4W 1/4W		D701 D702 D703 D704 D705	<pre></pre> <pre></pre> <pre>8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19</pre>	DIODE 1SS119	9 9 9			
	IABLE RESISTOR> RES, ADJ, CARBON 220 AY>			D706 D707 D708 D709 D713	8-719-911-19 8-719-901-83 8-719-901-83 8-719-901-83 8-719-901-83	DIODE 1SS11' DIODE 1SS83 DIODE 1SS83 DIODE 1SS83 DIODE 1SS83				
RY601& 1-515-601-11	RELAY			D715 D716 D717	8-719-901-83 8-719-901-83 8-719-901-83	DIODE 1883				
	NSFOMER>				<jac< td=""><td>K></td><td></td><td></td><td></td><td></td></jac<>	K>				
T602 A 1-426-716-11 T603 1-437-090-00	TRANSFORMER, LINE FILTE TRANSFORMER, LINE FILTE HDT TRANSFORMER, CONVERTER	R (LFT)		J701 Z	∆ 1-526-819-11		TURE TUB	Ē		
<thi< td=""><td>ERMISTOR></td><td></td><td></td><td>L701</td><td><001 1-410-667-31</td><td>INDUCTOR</td><td>22UH</td><td></td><td></td><td></td></thi<>	ERMISTOR>			L701	<001 1-410-667-31	INDUCTOR	22UH			
TH601 1-807-973-11 TH602 1-807-973-11	THERMISTOR		*	L705	1-412-532-11	NSISTOR>	39UH			
	THERMISTOR, POSITIVE	******	******	9701 9702	8-729-119-78 8-729-119-78	TRANSISTOR	2SC2785- 2SC2785-	HFE		
*A-1331-299-A	C BOARD, COMPLETE			Q703 Q704 Q705	8-729-119-78 8-729-200-17 8-729-200-17	TRANSISTOR TRANSISTOR TRANSISTOR	2SC2785- 2SA1091-	HFE O		
	COVER (MAIN), CV VOL COVER (REAR LID), CV VO	L		Q706 Q707	8-729-200-17 8-729-326-11	TRANSISTOR TRANSISTOR	2SA1091- 2SC2611			
	PACITOR>	108	5000	Q708 Q709 Q710	8-729-326-11 8-729-326-11 8-729-200-17		2SC2611	0		
C701 1-102-157-00 C702 1-102-157-00 C703 1-102-157-00 C704 1-102-121-00 C705 1-126-101-11	CERAMIC 560PF CERAMIC 560PF CERAMIC 0.0022MF ELECT 100MF	10% 10% 10% 10% 20%	500V 500V 500V 50V 16V	Q711 Q712 Q713 Q714 Q715	8-729-200-17 8-729-200-17 8-729-255-12 8-729-255-12 8-729-119-78	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SA1091- 2SC2551- 2SC2551-	0 0 0		
C706 1-102-074-00 C707 1-162-116-00 C708 1-136-601-11 C710 1-101-880-00 C711 1-101-880-00	CERAMIC 680PF FILM 0.01MF CERAMIC 47PF	10% 10% 5% 5% 5%	50V 2KV 630V 50V 50V	Q716 Q717	8-729-119-78 8-729-119-78	TRANSISTOR TRANSISTOR				
C712 1-101-880-00	CERAMIC 47PF	5%	50V	1 0700		SISTOR>	114		1 / 40	
C713 1-123-946-00 C714 1-102-976-00 C715 1-102-976-00 C716 1-102-976-00	CERAMIC 180PF CERAMIC 180PF	20% 5% 5% 5%	250V 50V 50V 50V	R702 R704 R705 R706 R707	1-247-903-00 1-215-405-00 1-215-405-00 1-215-405-00 1-249-431-11	CARBON METAL METAL METAL CARBON	1M 220 220 220 15K	5% 1% 1% 1% 5%	1/4W 1/4W 1/4W 1/4W 1/4W	
C717 1-106-399-00 C718 1-106-399-00 C720 1-108-700-11 C734 1-102-973-00 C735 1-102-816-00 C736 1-102-816-00	MYLAR 0.22MF MYLAR 0.047MF CERAMIC 100PF CERAMIC 120PF	10% 10% 10% 5% 5%	200V 200V 200V 50V 50V	R708 R709 R710 R711 R712	1-249-431-11 1-249-431-11 1-215-391-00 1-215-394-00 1-215-392-00	CARBON CARBON METAL METAL METAL	15K 15K 56 75 62	5% 5% 1% 1%	1/4W 1/4W 1/4W 1/4W 1/4W	



Les composants identifies par une trame et une marque A sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark are critical for safety.
Replace only with part number specified.

REF.NO. PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R715 1-202-818-00 R716 1-216-486-71 R717 1-202-818-00 R718 1-216-486-71 R719 1-202-818-00 R720 1-216-486-71 R722 1-202-833-11 R723 1-202-833-01 R724 1-202-842-11 R725 1-202-719-00	METAL OXIDE SOLID METAL OXIDE SOLID METAL OXIDE SOLID SOLID SOLID	8.2K 1K 8.2K 680K 100K 220K	20% 5% 20% 5% 20%	1/2W 3W 1/2W 3W 1/2W 1/2W 1/2W 1/2W 1/2W	F F	R2138 R2139 R2140 R2141	1-249-414-11 1-249-414-11 1-249-414-11 1-249-414-11 1-249-414-11	CARBON CARBON CARBON	560 560 560 560 560	5% (PV 5% (PV 5% (PV 5% (PV	M-1351Q/1354Q) 1/4W 1/4W 1/4W M-1351Q/1354Q) 1/4W
R731 1-249-409-11 R732 1-249-409-11 R733 1-249-409-11 R734 1-249-409-11 R735 1-249-409-11	CARBON CARBON CARBON CARBON	220 220 220 220 220	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1/4W	F	R2144 R2145 R2147	1-249-414-11 1-249-414-11 1-249-414-11 1-215-427-00 1-215-419-00	CARBON	560 560 560 1.8K 820	(PV 1%	
R736 1-249-409-11 R737 1-247-807-31 R738 1-247-807-31 R739 1-247-807-31 R740 1-249-429-11 R741 1-249-429-11 R742 1-249-429-11	CARBON CARBON CARBON CARBON CARBON CARBON CARBON	10K	5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/4W 1/4W 1/4W 1/4W 1/4W 1/4W	F F	R2150 R2151 R2152	1-215-409-00 1-215-407-00 1-215-404-00	METAL METAL	330 270 200	1% 1% 1% 1%	M-1351Q/1354Q) 1/4W M-1351Q/1354Q) 1/4W 1/4W 1/4W
R747 1-247-725-11 R748 1-247-713-11	METAL OXIDE CARBON CARBON METAL OXIDE	10K 10K 47K 10K 1K 47K 39	555555 55555 55555	1/4W 1/4W 1W 1/4W 1/4W 2W 1/4W	F F	R2154 R2155 R2156 R2157 R2158	1-215-401-11 1-215-399-00 1-215-397-00 1-215-421-00 1-215-416-00 1-215-405-00	METAL METAL METAL METAL METAL	150 120 100 1K 620 360 220	17 17 17 17 17 17	1/4W 1/4W 1/4W 1/4W 1/4W 1/4W
R751 1-247-887-00 R752 1-247-887-00 R753 1-247-887-00	CARBON CARBON CARBON	220K 220K	5% 5%	1/4W 1/4W		R2160	1-215-421-00 <vai< td=""><td>METAL</td><td>1K</td><td>1%</td><td>1/4W</td></vai<>	METAL	1K	1%	1/4W
RV707 1-230-641-11 RV708 1-230-798-21 RV709 1-230-641-11	RIABLE RESISTOR RES, ADJ, MET RES, ADJ, MET RES, ADJ, MET	> AL GLA AL GLA AL GLA	ZE 2.2 ZE 90M ZE 2.2	2M 1 2M	*******	RV2103 RV2105 RV2109 RV2113	1-241-845-11 1-241-845-11 1-241-845-11 1-241-845-11 1-241-846-11	RES, VAR, CA RES, VAR, CA RES, VAR, CA RES, VAR, CA	RBON 20 RBON 20 RBON 20 RBON 20 RBON 20	OK OK OK OK	
	H BOARD, COMF	LETE (<sw< td=""><td>ITCH></td><td></td><td></td><td></td></sw<>	ITCH>			
	H BOARD, COMP	LETE ((PVM-13	350)		S2103 S2104	1-570-101-41 1-570-101-41	SWITCH, KEY SWITCH, KEY SWITCH, KEY SWITCH, KEY SWITCH, KEY	BOARD BOARD	(PVM-1	351Q/1354Q)
<co CN105 *1-564-527-1; CN106 *1-564-526-1;</co 						S2107 S2108 S2109	1-570-969-11 1-570-101-41 1-570-101-41	SWITCH, KEY SWITCH, KEY SWITCH, KEY SWITCH, KEY SWITCH, KEY	BOARD BOARD BOARD	(PVM-1	351Q/13 54Q)
D2102 8-719-920-09 D2103 8-719-812-3			1351 Q /	1354Q)		S2112 S2113 S2114	1-570-101-41 1-570-969-11 1-570-969-11	SWITCH, KEY SWITCH, KEY SWITCH, KEY SWITCH, KEY	BOARD BOARD BOARD	(PVM-1	351Q/1354Q) 351Q/1354Q)
<pre></pre>	CARBON CARBON	1.5K 820 12K 560	5% (P 5% 5%	1/4W 1/4W	1Q/1354Q) 		*A-1388-166-A	J BOARD, CON ************************************	PLETE ****		

PVM-1350/1351Q/1354Q

SONY. SERVICE MANUAL

US Model Canadian Model

PVM-1350

Serial No. 2,003,651 and Higher

Chassis No. SCC-G61D-A

PVM-1351Q Serial No. 2,004,051 and Higher

Chassis No. SCC-G61C-A

PVM-1354Q

Serial No. 2,006,601 and Higher

Chassis No. SCC-G61B-A

SUPPLEMENT-1

File this supplement with the service manual.


INTRODUCTION


Set, having CE mark (Safety mark), have been applied to the above Serial No. and changed G Block.

New G Block shows on next pages.



- G BOARD -





The components identified by shading and mark \triangle are critical for safety. Replace only with part number appointed.

specified.

Les composants identifies par une trame et une marque 🛦 sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.





PVM-1350/1351Q/1354Q

The components identified by shading and mark \triangle are critical for safety.

Replace only with part number specified.

Les composants identifies par une trame et une marque 🐧 sont critiques pour la securite Ne les remplacer que par une piece portant le numero specifie.

REF. NO. PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK	
* A-1316-213-A	G BOARD, COMPLETE (PVM-1351Q) ***********************************			D606 D607 D608 D609 D610	8-719-300-33 8-719-300-33 8-719-911-19 8-719-300-33 8-719-300-33	DIODE RU-3AM		
* A-1316-214-A	(PVM-1454QM) (PVM-2054QM) G BOARD, COMPLETE (PVM-1350) ************************************			D612 D613 D614 D615 D616	8-719-045-48 8-719-971-65 8-719-045-48 8-719-971-65 8-719-300-33	DIODE FML-G12S		
<cap< td=""><td>ACITOR></td><td></td><td></td><td></td><td>D617</td><td>8-719-110-46</td><td>DIODE RD16ESB3</td><td></td></cap<>	ACITOR>				D617	8-719-110-46	DIODE RD16ESB3	
C602 A 1-136-360-51		0.22MF 0.22MF	20% 20%	250V 250V		<fuse></fuse>		
	CERAMIC CERAMIC CERAMIC	0.001MF 0.001MF 0.001MF	10% 10% 10%	400V 400V 400V	i	1-533-189-11	FUSE, GLASS TUBE 1.6A/125V HOLDER, FUSE FUSE, GLASS TUBE 1.6A/125V HOLDER, FUSE	
C608 A. 1-161-953-71	1-161-953-71 CERAMIC 0.0047NF 20% 4		400V 400V	!				
C609 A 1-161-953-71 C610 A 1-161-953-71 C611 A 1-161-953-71	CERAMIC 0.0047MF 207		20% 20% 20%	400V 400V 400V	FR601		RITE BEAD> FERRITE BEAD INDUCTOR 0.45UH	
C612 & 1-137-484-61	FILM	0.47MF	10%	630V	FB602	1-410-396-41	FERRITE BEAD INDUCTOR 0.45UH FERRITE BEAD INDUCTOR 0.45UH	
C613 1-137-484-11 C614 1-129-720-00	FILM FILM	0.47MF 0.033MF	10% 10%	630V 630V	FB604	1-410-396-41	FERRITE BEAD INDUCTOR 0.45UH FERRITE BEAD INDUCTOR 0.45UH	
C615 1-136-619-11 C616 1-124-910-11	FILM ELECT	0.0016MF 47MF	3% 20%	2KV 35V		<1C>		
C617 1-136-557-11 C618 1-126-096-11	FILM ELECT	0.0033MF 10MF	10% 20%	630V 25V	10601	8-749-924-69	IC STR-M6523	
C619 1-124-911-11 C620 1-161-754-00	ELECT CERAMIC	220MF 0.001MF	20% 10%	50 V 2 K V	i	4-382-854-11 8-749-010-47	SCREW (M3X10), P, SW (+); IC60 IC STR-S3115	
C621 1-125-494-11 C622 1-102-038-00	ELECT (BLOCK)	560MF 0.001MF	20%	160V 500V	10603	4-382-854-11 8-759-701-56	SCREW (M3X10), P, SW (+); IC60 IC NJM78M05FA)2
C623 1-126-944-11	ELECT 330	3300MF 0.001MF	OMF 20%	25V 500V	10604	4-382-854-11 8-759-231-53	SCREW (M3X10), P, SW (+); IC603	13
C625 1-124-557-11 C626 1-102-038-00	ELECT CERAMIC	1000MF 0.001MF	20%	25V 500V		4-382-854-11	SCREW (M3X10), P, SW (+); IC60)4
C627 1-124-922-11 C628 1-102-038-00		1000MF 0.001MF	20%	50V 500V		< TIII	MPER>	
C628 1-102-038-00 C629 1-124-922-11 C630 1-124-907-11	ELECT	1000MF 10MF	20% 20%	50V 50V	JW609		INDUCTOR 270UH (PVM-135	3MD)
C631 1-136-853-11	FILM	0.56MF	5%	200V				
C632 1-124-562-11 C633 1-124-122-11 C634 1-124-911-11	ELECT	47MF 100MF 220MF	20% 20% 20%	160V 50V 50V	1601	<00I	COIL, CHOKE 200UH	
C634 1-124-911-11 C636 1-124-910-11 C1602 1-137-484-11	ELECT	47MF 0.47MF	20% 10%	50V 630V	L1601	1-410-679-31 1-421-421-00	INDUCTOR 270UH (PVM-145	3MD)
						< DITC	TO COUNTED	
<pre><connector> CN601 1-691-960-11 PIN. CONNECTOR (PC BOARD) 3P</connector></pre>				PH601		TO COUPLER> PHOTO COUPLER PC111YS		
CN601 1-591-960-11 FIN, CONNECTOR (PC BOARD) 7P CN602 *1-695-561-11 PIN, CONNECTOR (PC BOARD) 7P CN603 *1-508-765-00 PIN, CONNECTOR (5MM PITCH) 3P CN604 *1-564-506-11 PLUG, CONNECTOR 3P CN605 *1-573-964-11 PIN, CONNECTOR (PC BOARD) 6P								
				0601	<transistor> 8-729-140-96 TRANSISTOR 2SD774-34</transistor>			
				Q601 Q603				
<diode></diode>								
D601 & 8-719-032-39 DIODE DSA3A4-F3 D602 & 8-719-032-39 DIODE DSA3A4-F3				REAL A	KES 1-202-885-91	SISTOR> SOLID 1M 20% 1/2W		
D603 & 8-719-032-39 D604 & 8-719-032-39 D605 8-719-971-65	DIODE DSA3A	4-F3 4-F3				1-216-489-11		F

REF.NO.	PART NO.	DESCRIPTION				REMARK
R603 R604 R605	1-216-491-11 1-249-418-11 1-249-415-11	CARBON	56K 1.2K 680	5% 5% 5%	3W 1/4W 1/4W	F
R606 R607 R608 R609 R610	1-207-642-00 1-249-423-11 1-249-426-11 1-249-426-11 1-249-421-11	CARBON CARBON CARBON	0.15 3.3K 5.6K 5.6K 2.2K	10% 5% 5% 5% 5%	3W 1/4W 1/4W 1/4W 1/4W	F
R611 R612 R613 R614 R615	1-249-417-11 1-249-404-00 1-249-419-11 1-249-385-11 1-218-265-11	CARBON CARBON CARBON	1K 82 1.5K 2.2 8.2M	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1W	F
R616 R617 R618 R619 R620	1-216-341-11 1-216-341-11 1-249-443-11 1-216-341-11 1-249-443-11		0.22 0.22 0.47 0.22 0.47	5% 5% 5% 5%	1W 1W 1/4W 1W 1/4W	F F F F
R621 R622 R623 R624 R625	1-215-877-11 1-247-700-11 1-249-417-11 1-216-341-11 1-216-341-11	METAL OXIDE CARBON CARBON METAL OXIDE METAL OXIDE	22K 100 1K 0.22 0.22	5% 5% 5% 5%	1W 1/4W 1/4W 1W 1W	F F
R626 R631 R1602 R1603	1-247-895-00 1-247-807-31 1-215-869-11 1-202-846-00	CARBON CARBON METAL OXIDE SOLID	470K 100 1K 470K	5% 5% 5% 20%	1/4W 1/4W 1W 1/2W	F
	<re< td=""><td>LAY></td><td></td><td></td><td></td><td></td></re<>	LAY>				
RY601▲	. 1-515-738-11	RELAY				
	<tr.< td=""><td>ANSFORMER></td><td></td><td></td><td></td><td></td></tr.<>	ANSFORMER>				
	. 1-426-716-11 . 1-426-716-11 1-427-885-11	TRANSFORMER, TRANSFORMER, TRANSFORMER,	LINE F	ILTER	(LFT)	
	<thi< td=""><td>ERMISTOR></td><td></td><td></td><td></td><td></td></thi<>	ERMISTOR>				
THP6014	1-808-059-3 2	THERMISTOR, F	OSITIV	E		
	<vai< td=""><td>RISTOR></td><td></td><td></td><td></td><td></td></vai<>	RISTOR>				
	1-809-942-71					
******	**********	*********	*****	*****	*****	*******

9-978-399-81

Sony Corporation B & I Systems Company English 95EZ24059-1 Printe(in Japan (2)1995. 5

specified. specified.

The components identified by shading and mark Δ are critical for safety.

Replace only with part number in the composants identifies partial une trame et une marque Δ sont critiques pour la securite.

Ne les remplacer que par une piece portant le numero specifie.

Dec	MO	PART	MO
ner.	. nu.	PARI	NU.

DESCRIPTION

REMARK | REF. NO. PART NO.

DESCRIPTION

REMARK

<SWITCH>

S601 ▲ 1-692-921-11 SWITCH, PUSH (A.C. POWER)

*A-1390-390-A X BOARD, COMPLETE (PVM-1351Q/1354Q) ************

<CONNECTOR>

CN108 *1-564-518-11 PLUG, CONNECTOR 3P

<DIODE>

8-719-023-78 DIODE SEL3810DLC05 8-719-023-78 DIODE SEL3810DLC05 8-719-023-78 DIODE SEL3810DLC05 D001 D002 D003 8-719-023-78 DIODE SEL3810DLC05 D004

> *A-1390-391-A S BOARD, COMPLETE ************

> > <CAPACITOR>

C805	1-102-978-00	CERAMIC	220PF	5%	507
C806	1-136-165-00	FILM	0.1MF	5%	50Y
C807	1-130-477-00	MYLAR	0.0033MF	5%	50V
C810	1-136-165-00	FILM	0.1MF	5%	50V
C811	1-136-165-00	FILM	O. IMF	5%	50V
C812	1-136-175-00	FILM	0.068MF	5%	507
C813	1-124-907-11	ELECT	10MF	20%	507
C818	1-136-165-00	FILM	0.1MF	5%	507

<CONNECTOR>

CN801 *1-565-489-11 CONNECTOR, BOARD TO BOARD 13P

<10>

IC801 8-759-084-09 IC Z8612812PSC

1-410-470-11 INDUCTOR

<COIL>

<RESISTOR> 1-249-435-11 CARBON 1-249-433-11 CARBON 1-215-454-00 METAL 1-215-461-00 METAL 1-249-417-11 CARBON R802 5% 5% 1% 1% 5% 22K 24K 47K 1/4W 1/4W 1/4W R803 R804 RANS RSOS 1-249-417-11 1-249-417-11 1-249-423-11 1-249-418-11 R812 R813 R815 CARBON -1 K 5% 5% 5% 5% 5% 1/44 1/4W 1/4W iĸ 3.3K 1.2K CARBON 1/4W CARBON R816 1-249-418-11 CARBON R817 1-249-418-11 CARBON 1-249-418-11 CARBON 1-249-422-11 CARBON R818 R819

1008

MISCELLANEOUS

Δ1-426-442-21 COIL. DEMAGNETIZATION Δ1-451-329-11 DEFLECTION YOKE (Y14FZA) Δ1-532-746-11 FUSE, GLASS TUBE (4.0A/125V) 1-537-735-11 TERMINAL BOARD ASSY, 1/0 (A)

(PVM-1351Q/1354Q)

1-537-735-21 TERMINAL BOARD ASSY, I/O (B) (PVM-1350)
5PEAKER
9901 A 8-734-822-05 PICTURE TUBE (M34KBE2OX) (PVM-1354Q)
A 8-736-255-05 PICTURE TUBE (A34JHS12X) (PVM-1350/1351Q)

ACCESSORIES AND PACKING MATERIALS **********************

CORD, POWER (7.0A/125V)
CORD, CONNECTION (PVM-1351Q/1354Q)
HOLDER (B), PLUG
MANUAL, INSTRUCTION (PVM-1350)
MANUAL, INSTRUCTION (PVM-1351Q/1354Q) ▲ 1-551-812-11 1-765-268-11 2-990-242-01 3-758-528-21 3-758-531-21 *4-043-759-01 *4-043-760-01 *4-043-761-01 *4-043-762-01 INDIVIDUAL CARTON (PVM-1350)
INDIVIDUAL CARTON (PVM-1354Q)
INDIVIDUAL CARTON (PVM-1354Q)
CUSHION (UPPER) (ASSY)
CUSHION (LOWER) (ASSY) *4-043-763-01 4-044-040-01 LABEL, TALLY (PVM-1351Q/1354Q)**4-381-155-01 BAG, PROTECTION